

---

# The 802.11 subsystems – for kernel developers

Explaining wireless 802.11 networking in the Linux kernel

Johannes Berg <johannes@sipsolutions.net>  
Copyright © 2007-2009 Johannes Berg

This documentation is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License version 2 as published by the Free Software Foundation.

This documentation is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this documentation; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

For more details see the file COPYING in the source distribution of Linux.

## Abstract

These books attempt to give a description of the various subsystems that play a role in 802.11 wireless networking in Linux. Since these books are for kernel developers they attempt to document the structures and functions used in the kernel as well as giving a higher-level overview.

The reader is expected to be familiar with the 802.11 standard as published by the IEEE in 802.11-2007 (or possibly later versions). References to this standard will be given as "802.11-2007 8.1.5".

---

---

# Table of Contents

|  |    |
|--|----|
| The cfg80211 subsystem .....             | vi |
| 1. Device registration .....             | 1  |
| enum ieee80211_band .....                | 2  |
| enum ieee80211_channel_flags .....       | 3  |
| struct ieee80211_channel .....           | 5  |
| enum ieee80211_rate_flags .....          | 7  |
| struct ieee80211_rate .....              | 8  |
| struct ieee80211_sta_ht_cap .....        | 9  |
| struct ieee80211_supported_band .....    | 10 |
| enum cfg80211_signal_type .....          | 11 |
| enum wiphy_params_flags .....            | 12 |
| enum wiphy_flags .....                   | 13 |
| struct wiphy .....                       | 15 |
| struct wireless_dev .....                | 20 |
| wiphy_new .....                          | 23 |
| wiphy_register .....                     | 24 |
| wiphy_unregister .....                   | 25 |
| wiphy_free .....                         | 26 |
| wiphy_name .....                         | 27 |
| wiphy_dev .....                          | 28 |
| wiphy_priv .....                         | 29 |
| priv_to_wiphy .....                      | 30 |
| set_wiphy_dev .....                      | 31 |
| wdev_priv .....                          | 32 |
| struct ieee80211_iface_limit .....       | 33 |
| struct ieee80211_iface_combination ..... | 34 |
| cfg80211_check_combinations .....        | 36 |
| 2. Actions and configuration .....       | 37 |
| struct cfg80211_ops .....                | 38 |
| struct vif_params .....                  | 46 |
| struct key_params .....                  | 47 |
| enum survey_info_flags .....             | 48 |
| struct survey_info .....                 | 49 |
| struct cfg80211_beacon_data .....        | 50 |
| struct cfg80211_ap_settings .....        | 51 |
| struct station_parameters .....          | 53 |
| enum rate_info_flags .....               | 55 |
| struct rate_info .....                   | 56 |
| struct station_info .....                | 57 |
| enum monitor_flags .....                 | 60 |
| enum mpath_info_flags .....              | 61 |
| struct mpath_info .....                  | 62 |
| struct bss_parameters .....              | 63 |
| struct ieee80211_txq_params .....        | 64 |
| struct cfg80211_crypto_settings .....    | 65 |
| struct cfg80211_auth_request .....       | 66 |
| struct cfg80211_assoc_request .....      | 67 |
| struct cfg80211_deauth_request .....     | 68 |
| struct cfg80211_disassoc_request .....   | 69 |
| struct cfg80211_ibss_params .....        | 70 |
| struct cfg80211_connect_params .....     | 72 |

|  |     |
|--|-----|
| struct cfg80211_pmksa .....                    | 74  |
| cfg80211_rx_mlme_mgmt .....                    | 75  |
| cfg80211_auth_timeout .....                    | 76  |
| cfg80211_rx_assoc_resp .....                   | 77  |
| cfg80211_assoc_timeout .....                   | 78  |
| cfg80211_tx_mlme_mgmt .....                    | 79  |
| cfg80211_ibss_joined .....                     | 80  |
| cfg80211_connect_result .....                  | 81  |
| cfg80211_roamed .....                          | 82  |
| cfg80211_disconnected .....                    | 83  |
| cfg80211_ready_on_channel .....                | 84  |
| cfg80211_remain_on_channel_expired .....       | 85  |
| cfg80211_new_sta .....                         | 86  |
| cfg80211_rx_mgmt .....                         | 87  |
| cfg80211_mgmt_tx_status .....                  | 88  |
| cfg80211_cqm_rssi_notify .....                 | 89  |
| cfg80211_cqm_pktloss_notify .....              | 90  |
| cfg80211_michael_mic_failure .....             | 91  |
| 3. Scanning and BSS list handling .....        | 92  |
| struct cfg80211_ssid .....                     | 93  |
| struct cfg80211_scan_request .....             | 94  |
| cfg80211_scan_done .....                       | 96  |
| struct cfg80211_bss .....                      | 97  |
| cfg80211_inform_bss_width_frame .....          | 99  |
| cfg80211_inform_bss_width .....                | 100 |
| cfg80211_unlink_bss .....                      | 101 |
| cfg80211_find_ie .....                         | 102 |
| ieee80211_bss_get_ie .....                     | 103 |
| 4. Utility functions .....                     | 104 |
| ieee80211_channel_to_frequency .....           | 105 |
| ieee80211_frequency_to_channel .....           | 106 |
| ieee80211_get_channel .....                    | 107 |
| ieee80211_get_response_rate .....              | 108 |
| ieee80211_hdrlen .....                         | 109 |
| ieee80211_get_hdrlen_from_skb .....            | 110 |
| struct ieee80211_radiotap_iterator .....       | 111 |
| 5. Data path helpers .....                     | 113 |
| ieee80211_data_to_8023 .....                   | 114 |
| ieee80211_data_from_8023 .....                 | 115 |
| ieee80211_amsdu_to_8023s .....                 | 116 |
| cfg80211_classify8021d .....                   | 117 |
| 6. Regulatory enforcement infrastructure ..... | 118 |
| regulatory_hint .....                          | 119 |
| wiphy_apply_custom_regulatory .....            | 120 |
| freq_reg_info .....                            | 121 |
| 7. RFkill integration .....                    | 122 |
| wiphy_rfkill_set_hw_state .....                | 123 |
| wiphy_rfkill_start_polling .....               | 124 |
| wiphy_rfkill_stop_polling .....                | 125 |
| 8. Test mode .....                             | 126 |
| cfg80211_testmode_alloc_reply_skb .....        | 127 |
| cfg80211_testmode_reply .....                  | 128 |
| cfg80211_testmode_alloc_event_skb .....        | 129 |
| cfg80211_testmode_event .....                  | 130 |

|  |       |
|--|-------|
| The mac80211 subsystem .....                     | cxxxi |
| I. The basic mac80211 driver interface .....     | 1     |
| 1. Basic hardware handling .....                 | 3     |
| struct ieee80211_hw .....                        | 4     |
| enum ieee80211_hw_flags .....                    | 7     |
| SET_IEEE80211_DEV .....                          | 10    |
| SET_IEEE80211_PERM_ADDR .....                    | 11    |
| struct ieee80211_ops .....                       | 12    |
| ieee80211_alloc_hw .....                         | 23    |
| ieee80211_register_hw .....                      | 24    |
| ieee80211_unregister_hw .....                    | 25    |
| ieee80211_free_hw .....                          | 26    |
| 2. PHY configuration .....                       | 27    |
| struct ieee80211_conf .....                      | 28    |
| enum ieee80211_conf_flags .....                  | 30    |
| 3. Virtual interfaces .....                      | 31    |
| struct ieee80211_vif .....                       | 32    |
| 4. Receive and transmit processing .....         | 34    |
| what should be here .....                        | 34    |
| Frame format .....                               | 34    |
| Packet alignment .....                           | 34    |
| Calling into mac80211 from interrupts .....      | 34    |
| functions/definitions .....                      | 35    |
| 5. Frame filtering .....                         | 65    |
| enum ieee80211_filter_flags .....                | 66    |
| 6. The mac80211 workqueue .....                  | 67    |
| ieee80211_queue_work .....                       | 68    |
| ieee80211_queue_delayed_work .....               | 69    |
| II. Advanced driver interface .....              | 70    |
| 7. LED support .....                             | 72    |
| ieee80211_get_tx_led_name .....                  | 73    |
| ieee80211_get_rx_led_name .....                  | 74    |
| ieee80211_get_assoc_led_name .....               | 75    |
| ieee80211_get_radio_led_name .....               | 76    |
| struct ieee80211_tpt_blink .....                 | 77    |
| enum ieee80211_tpt_led_trigger_flags .....       | 78    |
| ieee80211_create_tpt_led_trigger .....           | 79    |
| 8. Hardware crypto acceleration .....            | 80    |
| enum set_key_cmd .....                           | 81    |
| struct ieee80211_key_conf .....                  | 82    |
| enum ieee80211_key_flags .....                   | 83    |
| ieee80211_get_tkip_p1k .....                     | 85    |
| ieee80211_get_tkip_p1k_iv .....                  | 86    |
| ieee80211_get_tkip_p2k .....                     | 87    |
| 9. Powersave support .....                       | 88    |
| 10. Beacon filter support .....                  | 89    |
| ieee80211_beacon_loss .....                      | 90    |
| 11. Multiple queues and QoS support .....        | 91    |
| struct ieee80211_tx_queue_params .....           | 92    |
| 12. Access point mode support .....              | 93    |
| support for powersaving clients .....            | 93    |
| 13. Supporting multiple virtual interfaces ..... | 103   |
| ieee80211_iterate_active_interfaces .....        | 104   |
| ieee80211_iterate_active_interfaces_atomic ..... | 105   |

|   |     |
|---|-----|
| 14. Station handling .....                      | 106 |
| struct ieee80211_sta .....                      | 107 |
| enum sta_notify_cmd .....                       | 109 |
| ieee80211_find_sta .....                        | 110 |
| ieee80211_find_sta_by_ifaddr .....              | 111 |
| 15. Hardware scan offload .....                 | 112 |
| ieee80211_scan_completed .....                  | 113 |
| 16. Aggregation .....                           | 114 |
| TX A-MPDU aggregation .....                     | 114 |
| RX A-MPDU aggregation .....                     | 114 |
| 17. Spatial Multiplexing Powersave (SMPS) ..... | 116 |
| ieee80211_request_smpps .....                   | 117 |
| enum ieee80211_smpps_mode .....                 | 118 |
| III. Rate control interface .....               | 119 |
| 18. Rate Control API .....                      | 121 |
| ieee80211_start_tx_ba_session .....             | 122 |
| ieee80211_start_tx_ba_cb_irqsafe .....          | 123 |
| ieee80211_stop_tx_ba_session .....              | 124 |
| ieee80211_stop_tx_ba_cb_irqsafe .....           | 125 |
| enum ieee80211_rate_control_changed .....       | 126 |
| struct ieee80211_tx_rate_control .....          | 127 |
| rate_control_send_low .....                     | 128 |
| IV. Internals .....                             | 129 |
| 19. Key handling .....                          | 131 |
| Key handling basics .....                       | 131 |
| MORE TBD .....                                  | 131 |
| 20. Receive processing .....                    | 132 |
| 21. Transmit processing .....                   | 133 |
| 22. Station info handling .....                 | 134 |
| Programming information .....                   | 134 |
| STA information lifetime rules .....            | 141 |
| 23. Aggregation .....                           | 143 |
| struct sta_ampdu_mlme .....                     | 144 |
| struct tid_ampdu_tx .....                       | 145 |
| struct tid_ampdu_rx .....                       | 147 |
| 24. Synchronisation .....                       | 149 |

# **The cfg80211 subsystem**

---

# The cfg80211 subsystem

## Abstract

cfg80211 is the configuration API for 802.11 devices in Linux. It bridges userspace and drivers, and offers some utility functionality associated with 802.11. cfg80211 must, directly or indirectly via mac80211, be used by all modern wireless drivers in Linux, so that they offer a consistent API through nl80211. For backward compatibility, cfg80211 also offers wireless extensions to userspace, but hides them from drivers completely.

Additionally, cfg80211 contains code to help enforce regulatory spectrum use restrictions.

---

---

# Table of Contents

|  |    |
|--|----|
| 1. Device registration .....             | 1  |
| enum ieee80211_band .....                | 2  |
| enum ieee80211_channel_flags .....       | 3  |
| struct ieee80211_channel .....           | 5  |
| enum ieee80211_rate_flags .....          | 7  |
| struct ieee80211_rate .....              | 8  |
| struct ieee80211_sta_ht_cap .....        | 9  |
| struct ieee80211_supported_band .....    | 10 |
| enum cfg80211_signal_type .....          | 11 |
| enum wiphy_params_flags .....            | 12 |
| enum wiphy_flags .....                   | 13 |
| struct wiphy .....                       | 15 |
| struct wireless_dev .....                | 20 |
| wiphy_new .....                          | 23 |
| wiphy_register .....                     | 24 |
| wiphy_unregister .....                   | 25 |
| wiphy_free .....                         | 26 |
| wiphy_name .....                         | 27 |
| wiphy_dev .....                          | 28 |
| wiphy_priv .....                         | 29 |
| priv_to_wiphy .....                      | 30 |
| set_wiphy_dev .....                      | 31 |
| wdev_priv .....                          | 32 |
| struct ieee80211_iface_limit .....       | 33 |
| struct ieee80211_iface_combination ..... | 34 |
| cfg80211_check_combinations .....        | 36 |
| 2. Actions and configuration .....       | 37 |
| struct cfg80211_ops .....                | 38 |
| struct vif_params .....                  | 46 |
| struct key_params .....                  | 47 |
| enum survey_info_flags .....             | 48 |
| struct survey_info .....                 | 49 |
| struct cfg80211_beacon_data .....        | 50 |
| struct cfg80211_ap_settings .....        | 51 |
| struct station_parameters .....          | 53 |
| enum rate_info_flags .....               | 55 |
| struct rate_info .....                   | 56 |
| struct station_info .....                | 57 |
| enum monitor_flags .....                 | 60 |
| enum mpath_info_flags .....              | 61 |
| struct mpath_info .....                  | 62 |
| struct bss_parameters .....              | 63 |
| struct ieee80211_txq_params .....        | 64 |
| struct cfg80211_crypto_settings .....    | 65 |
| struct cfg80211_auth_request .....       | 66 |
| struct cfg80211_assoc_request .....      | 67 |
| struct cfg80211_deauth_request .....     | 68 |
| struct cfg80211_disassoc_request .....   | 69 |
| struct cfg80211_ibss_params .....        | 70 |
| struct cfg80211_connect_params .....     | 72 |
| struct cfg80211_pmksa .....              | 74 |



|  |     |
|--|-----|
| cfg80211_rx_mlme_mgmt .....                    | 75  |
| cfg80211_auth_timeout .....                    | 76  |
| cfg80211_rx_assoc_resp .....                   | 77  |
| cfg80211_assoc_timeout .....                   | 78  |
| cfg80211_tx_mlme_mgmt .....                    | 79  |
| cfg80211_ibss_joined .....                     | 80  |
| cfg80211_connect_result .....                  | 81  |
| cfg80211_roamed .....                          | 82  |
| cfg80211_disconnected .....                    | 83  |
| cfg80211_ready_on_channel .....                | 84  |
| cfg80211_remain_on_channel_expired .....       | 85  |
| cfg80211_new_sta .....                         | 86  |
| cfg80211_rx_mgmt .....                         | 87  |
| cfg80211_mgmt_tx_status .....                  | 88  |
| cfg80211_cqm_rssi_notify .....                 | 89  |
| cfg80211_cqm_pktloss_notify .....              | 90  |
| cfg80211_michael_mic_failure .....             | 91  |
| 3. Scanning and BSS list handling .....        | 92  |
| struct cfg80211_ssid .....                     | 93  |
| struct cfg80211_scan_request .....             | 94  |
| cfg80211_scan_done .....                       | 96  |
| struct cfg80211_bss .....                      | 97  |
| cfg80211_inform_bss_width_frame .....          | 99  |
| cfg80211_inform_bss_width .....                | 100 |
| cfg80211_unlink_bss .....                      | 101 |
| cfg80211_find_ie .....                         | 102 |
| ieee80211_bss_get_ie .....                     | 103 |
| 4. Utility functions .....                     | 104 |
| ieee80211_channel_to_frequency .....           | 105 |
| ieee80211_frequency_to_channel .....           | 106 |
| ieee80211_get_channel .....                    | 107 |
| ieee80211_get_response_rate .....              | 108 |
| ieee80211_hdrlen .....                         | 109 |
| ieee80211_get_hdrlen_from_skb .....            | 110 |
| struct ieee80211_radiotap_iterator .....       | 111 |
| 5. Data path helpers .....                     | 113 |
| ieee80211_data_to_8023 .....                   | 114 |
| ieee80211_data_from_8023 .....                 | 115 |
| ieee80211_amsdu_to_8023s .....                 | 116 |
| cfg80211_classify8021d .....                   | 117 |
| 6. Regulatory enforcement infrastructure ..... | 118 |
| regulatory_hint .....                          | 119 |
| wiphy_apply_custom_regulatory .....            | 120 |
| freq_reg_info .....                            | 121 |
| 7. RFkill integration .....                    | 122 |
| wiphy_rfkill_set_hw_state .....                | 123 |
| wiphy_rfkill_start_polling .....               | 124 |
| wiphy_rfkill_stop_polling .....                | 125 |
| 8. Test mode .....                             | 126 |
| cfg80211_testmode_alloc_reply_skb .....        | 127 |
| cfg80211_testmode_reply .....                  | 128 |
| cfg80211_testmode_alloc_event_skb .....        | 129 |
| cfg80211_testmode_event .....                  | 130 |

---

# Chapter 1. Device registration

In order for a driver to use `cfg80211`, it must register the hardware device with `cfg80211`. This happens through a number of hardware capability structs described below.

The fundamental structure for each device is the 'wiphy', of which each instance describes a physical wireless device connected to the system. Each such wiphy can have zero, one, or many virtual interfaces associated with it, which need to be identified as such by pointing the network interface's `ieee80211_ptr` pointer to a struct `wireless_dev` which further describes the wireless part of the interface, normally this struct is embedded in the network interface's private data area. Drivers can optionally allow creating or destroying virtual interfaces on the fly, but without at least one or the ability to create some the wireless device isn't useful.

Each wiphy structure contains device capability information, and also has a pointer to the various operations the driver offers. The definitions and structures here describe these capabilities in detail.

## Name

enum ieee80211\_band — supported frequency bands

## Synopsis

```
enum ieee80211_band {  
    IEEE80211_BAND_2GHZ,  
    IEEE80211_BAND_5GHZ,  
    IEEE80211_BAND_60GHZ,  
    IEEE80211_NUM_BANDS  
};
```

## Constants

|                      |  |
|----------------------|--|
| IEEE80211_BAND_2GHZ  | 2.4GHz ISM band                        |
| IEEE80211_BAND_5GHZ  | around 5GHz band (4.9-5.7)             |
| IEEE80211_BAND_60GHZ | around 60 GHz band (58.32 - 64.80 GHz) |
| IEEE80211_NUM_BANDS  | number of defined bands                |

## Device registration

The bands are assigned this way because the supported bitrates differ in these bands.

## Name

enum ieee80211\_channel\_flags — channel flags

## Synopsis

```
enum ieee80211_channel_flags {
    IEEE80211_CHAN_DISABLED,
    IEEE80211_CHAN_NO_IR,
    IEEE80211_CHAN_RADAR,
    IEEE80211_CHAN_NO_HT40PLUS,
    IEEE80211_CHAN_NO_HT40MINUS,
    IEEE80211_CHAN_NO_OFDM,
    IEEE80211_CHAN_NO_80MHZ,
    IEEE80211_CHAN_NO_160MHZ,
    IEEE80211_CHAN_INDOOR_ONLY,
    IEEE80211_CHAN_GO_CONCURRENT,
    IEEE80211_CHAN_NO_20MHZ,
    IEEE80211_CHAN_NO_10MHZ
};
```

## Constants

|                              |   |
|------------------------------|---|
| IEEE80211_CHAN_DISABLED      | This channel is disabled.   |
| IEEE80211_CHAN_NO_IR         | do not initiate radiation, this includes sending probe requests or beaconing.   |
| IEEE80211_CHAN_RADAR         | Radar detection is required on this channel.  |
| IEEE80211_CHAN_NO_HT40PLUS   | extension channel above this channel is not permitted.  |
| IEEE80211_CHAN_NO_HT40MINUS  | extension channel below this channel is not permitted.  |
| IEEE80211_CHAN_NO_OFDM       | OFDM is not allowed on this channel.  |
| IEEE80211_CHAN_NO_80MHZ      | If the driver supports 80 MHz on the band, this flag indicates that an 80 MHz channel cannot use this channel as the control or any of the secondary channels. This may be due to the driver or due to regulatory bandwidth restrictions.   |
| IEEE80211_CHAN_NO_160MHZ     | If the driver supports 160 MHz on the band, this flag indicates that an 160 MHz channel cannot use this channel as the control or any of the secondary channels. This may be due to the driver or due to regulatory bandwidth restrictions. |
| IEEE80211_CHAN_INDOOR_ONLY   | See NL80211_FREQUENCY_ATTR_INDOOR_ONLY  |
| IEEE80211_CHAN_GO_CONCURRENT | See NL80211_FREQUENCY_ATTR_GO_CONCURRENT  |
| IEEE80211_CHAN_NO_20MHZ      | 20 MHz bandwidth is not permitted on this channel.  |
| IEEE80211_CHAN_NO_10MHZ      | 10 MHz bandwidth is not permitted on this channel.  |

## Description

Channel flags set by the regulatory control code.

## Name

struct ieee80211\_channel — channel definition

## Synopsis

```
struct ieee80211_channel {
    enum ieee80211_band band;
    u16 center_freq;
    u16 hw_value;
    u32 flags;
    int max_antenna_gain;
    int max_power;
    int max_reg_power;
    bool beacon_found;
    u32 orig_flags;
    int orig_mag;
    int orig_mpwr;
    enum nl80211_dfs_state dfs_state;
    unsigned long dfs_state_entered;
    unsigned int dfs_cac_ms;
};
```

## Members

|                   |   |
|-------------------|---|
| band              | band this channel belongs to.   |
| center_freq       | center frequency in MHz   |
| hw_value          | hardware-specific value for the channel   |
| flags             | channel flags from enum ieee80211_channel_flags.  |
| max_antenna_gain  | maximum antenna gain in dBi   |
| max_power         | maximum transmission power (in dBm)   |
| max_reg_power     | maximum regulatory transmission power (in dBm)  |
| beacon_found      | helper to regulatory code to indicate when a beacon has been found on this channel. Use regulatory_hint_found_beacon to enable this, this is useful only on 5 GHz band. |
| orig_flags        | channel flags at registration time, used by regulatory code to support devices with additional restrictions   |
| orig_mag          | internal use  |
| orig_mpwr         | internal use  |
| dfs_state         | current state of this channel. Only relevant if radar is required on this channel.  |
| dfs_state_entered | timestamp (jiffies) when the dfs state was entered.   |
| dfs_cac_ms        | DFS CAC time in milliseconds, this is valid for DFS channels.   |

## Description

This structure describes a single channel for use with `cfg80211`.

## Name

enum ieee80211\_rate\_flags — rate flags

## Synopsis

```
enum ieee80211_rate_flags {  
    IEEE80211_RATE_SHORT_PREAMBLE,  
    IEEE80211_RATE_MANDATORY_A,  
    IEEE80211_RATE_MANDATORY_B,  
    IEEE80211_RATE_MANDATORY_G,  
    IEEE80211_RATE_ERP_G,  
    IEEE80211_RATE_SUPPORTS_5MHZ,  
    IEEE80211_RATE_SUPPORTS_10MHZ  
};
```

## Constants

**IEEE80211\_RATE\_SHORT\_PREAMBLE** Hardware can send with short preamble on this bitrate; only relevant in 2.4GHz band and with CCK rates.

**IEEE80211\_RATE\_MANDATORY\_A** This bitrate is a mandatory rate when used with 802.11a (on the 5 GHz band); filled by the core code when registering the wiphy.

**IEEE80211\_RATE\_MANDATORY\_B** This bitrate is a mandatory rate when used with 802.11b (on the 2.4 GHz band); filled by the core code when registering the wiphy.

**IEEE80211\_RATE\_MANDATORY\_G** This bitrate is a mandatory rate when used with 802.11g (on the 2.4 GHz band); filled by the core code when registering the wiphy.

**IEEE80211\_RATE\_ERP\_G** This is an ERP rate in 802.11g mode.

**IEEE80211\_RATE\_SUPPORTS\_5MHZ** Rate can be used in 5 MHz mode

**IEEE80211\_RATE\_SUPPORTS\_10MHZ** Rate can be used in 10 MHz mode

## Description

Hardware/specification flags for rates. These are structured in a way that allows using the same bitrate structure for different bands/PHY modes.



## Name

struct ieee80211\_rate — bitrate definition

## Synopsis

```
struct ieee80211_rate {  
    u32 flags;  
    u16 bitrate;  
    u16 hw_value;  
    u16 hw_value_short;  
};
```

## Members

|                |   |
|----------------|---|
| flags          | rate-specific flags   |
| bitrate        | bitrate in units of 100 Kbps                                    |
| hw_value       | driver/hardware value for this rate                             |
| hw_value_short | driver/hardware value for this rate when short preamble is used |

## Description

This structure describes a bitrate that an 802.11 PHY can operate with. The two values *hw\_value* and *hw\_value\_short* are only for driver use when pointers to this structure are passed around.

## Name

struct ieee80211\_sta\_ht\_cap — STA's HT capabilities

## Synopsis

```
struct ieee80211_sta_ht_cap {  
    u16 cap;  
    bool ht_supported;  
    u8 ampdu_factor;  
    u8 ampdu_density;  
    struct ieee80211_mcs_info mcs;  
};
```

## Members

|               |  |
|---------------|--|
| cap           | HT capabilities map as described in 802.11n spec |
| ht_supported  | is HT supported by the STA                       |
| ampdu_factor  | Maximum A-MPDU length factor                     |
| ampdu_density | Minimum A-MPDU spacing                           |
| mcs           | Supported MCS rates                              |

## Description

This structure describes most essential parameters needed to describe 802.11n HT capabilities for an STA.

## Name

struct ieee80211\_supported\_band — frequency band definition

## Synopsis

```
struct ieee80211_supported_band {
    struct ieee80211_channel * channels;
    struct ieee80211_rate * bitrates;
    enum ieee80211_band band;
    int n_channels;
    int n_bitrates;
    struct ieee80211_sta_ht_cap ht_cap;
    struct ieee80211_sta_vht_cap vht_cap;
};
```

## Members

|            |   |
|------------|---|
| channels   | Array of channels the hardware can operate in in this band.   |
| bitrates   | Array of bitrates the hardware can operate with in this band. Must be sorted to give a valid “supported rates” IE, i.e. CCK rates first, then OFDM. |
| band       | the band this structure represents  |
| n_channels | Number of channels in <i>channels</i>   |
| n_bitrates | Number of bitrates in <i>bitrates</i>   |
| ht_cap     | HT capabilities in this band  |
| vht_cap    | VHT capabilities in this band   |

## Description

This structure describes a frequency band a wiphy is able to operate in.

## Name

enum cfg80211\_signal\_type — signal type

## Synopsis

```
enum cfg80211_signal_type {  
    CFG80211_SIGNAL_TYPE_NONE,  
    CFG80211_SIGNAL_TYPE_MBM,  
    CFG80211_SIGNAL_TYPE_UNSPEC  
};
```

## Constants

CFG80211\_SIGNAL\_TYPE\_NONE no signal strength information available

CFG80211\_SIGNAL\_TYPE\_MBM signal strength in mBm (100\*dBm)

CFG80211\_SIGNAL\_TYPE\_UNSPEC signal strength, increasing from 0 through 100

## Name

enum wiphy\_params\_flags — set\_wiphy\_params bitfield values

## Synopsis

```
enum wiphy_params_flags {  
    WIPHY_PARAM_RETRY_SHORT,  
    WIPHY_PARAM_RETRY_LONG,  
    WIPHY_PARAM_FRAG_THRESHOLD,  
    WIPHY_PARAM_RTS_THRESHOLD,  
    WIPHY_PARAM_COVERAGE_CLASS,  
    WIPHY_PARAM_DYN_ACK  
};
```

## Constants

WIPHY\_PARAM\_RETRY\_SHORT wiphy->retry\_short has changed

WIPHY\_PARAM\_RETRY\_LONG wiphy->retry\_long has changed

WIPHY\_PARAM\_FRAG\_THRESHOLD wiphy->frag\_threshold has changed

WIPHY\_PARAM\_RTS\_THRESHOLD wiphy->rts\_threshold has changed

WIPHY\_PARAM\_COVERAGE\_CLASS coverage class changed

WIPHY\_PARAM\_DYN\_ACK dynack has been enabled

## Name

enum wiphy\_flags — wiphy capability flags

## Synopsis

```
enum wiphy_flags {
    WIPHY_FLAG_NETNS_OK,
    WIPHY_FLAG_PS_ON_BY_DEFAULT,
    WIPHY_FLAG_4ADDR_AP,
    WIPHY_FLAG_4ADDR_STATION,
    WIPHY_FLAG_CONTROL_PORT_PROTOCOL,
    WIPHY_FLAG_IBSS_RSN,
    WIPHY_FLAG_MESH_AUTH,
    WIPHY_FLAG_SUPPORTS_SCHED_SCAN,
    WIPHY_FLAG_SUPPORTS_FW_ROAM,
    WIPHY_FLAG_AP_UAPSD,
    WIPHY_FLAG_SUPPORTS_TDLS,
    WIPHY_FLAG_TDLS_EXTERNAL_SETUP,
    WIPHY_FLAG_HAVE_AP_SME,
    WIPHY_FLAG_REPORTS_OBSS,
    WIPHY_FLAG_AP_PROBE_RESP_OFFLOAD,
    WIPHY_FLAG_OFFCHAN_TX,
    WIPHY_FLAG_HAS_REMAIN_ON_CHANNEL,
    WIPHY_FLAG_SUPPORTS_5_10_MHZ,
    WIPHY_FLAG_HAS_CHANNEL_SWITCH
};
```

## Constants

|                                  |   |
|----------------------------------|---|
| WIPHY_FLAG_NETNS_OK              | if not set, do not allow changing the netns of this wiphy at all  |
| WIPHY_FLAG_PS_ON_BY_DEFAULT      | Set to true, powersave will be enabled by default -- this flag will be set depending on the kernel's default on <code>wiphy_new</code> , but can be changed by the driver if it has a good reason to override the default |
| WIPHY_FLAG_4ADDR_AP              | supports 4addr mode even on AP (with a single station on a VLAN interface)  |
| WIPHY_FLAG_4ADDR_STATION         | supports 4addr mode even as a station   |
| WIPHY_FLAG_CONTROL_PORT_PROTOCOL | The device supports setting the control port protocol ethertype. The device also honours the <code>control_port_no_encrypt</code> flag.   |
| WIPHY_FLAG_IBSS_RSN              | The device supports IBSS RSN.   |
| WIPHY_FLAG_MESH_AUTH             | The device supports mesh authentication by routing auth frames to userspace. See <code>NL80211_MESH_SETUP_USERSPACE_AUTH</code> .   |
| WIPHY_FLAG_SUPPORTS_SCHED_SCAN   | The device supports scheduled scans.  |
| WIPHY_FLAG_SUPPORTS_FW_ROAM      | The device supports roaming feature in the firmware.  |
| WIPHY_FLAG_AP_UAPSD              | The device supports uapsd on AP.  |

**WIPHY\_FLAG\_SUPPORTS\_TDLS** The device supports TDLS (802.11z) operation.

**WIPHY\_FLAG\_TDLS\_EXTERNAL\_SETUP** Device does not handle TDLS (802.11z) link setup/discovery operations internally. Setup, discovery and teardown packets should be sent through the *NL80211\_CMD\_TDLS\_MGMT* command. When this flag is not set, *NL80211\_CMD\_TDLS\_OPER* should be used for asking the driver/firmware to perform a TDLS operation.

**WIPHY\_FLAG\_HAVE\_AP\_SME** device integrates AP SME

**WIPHY\_FLAG\_REPORTS\_OBSS** the device will report beacons from other BSSes when there are virtual interfaces in AP mode by calling *cfg80211\_report\_obss\_beacon*.

**WIPHY\_FLAG\_AP\_PROBE\_RESP\_OFFLOAD** When operating as an AP, the device responds to probe-requests in hardware.

**WIPHY\_FLAG\_OFFCHAN\_TX** Device supports direct off-channel TX.

**WIPHY\_FLAG\_HAS\_REMAIN\_ON\_CHANNEL** Device supports remain-on-channel call.

**WIPHY\_FLAG\_SUPPORTS\_5\_10\_MHZ** Device supports 5 MHz and 10 MHz channels.

**WIPHY\_FLAG\_HAS\_CHANNEL\_SWITCH** Device supports channel switch in beaconing mode (AP, IBSS, Mesh, ...).

## Name

struct wiphy — wireless hardware description

## Synopsis

```
struct wiphy {
    u8 perm_addr[ETH_ALEN];
    u8 addr_mask[ETH_ALEN];
    struct mac_address * addresses;
    const struct ieee80211_txrx_stypes * mgmt_stypes;
    const struct ieee80211_iface_combination * iface_combinations;
    int n_iface_combinations;
    u16 software_iftypes;
    u16 n_addresses;
    u16 interface_modes;
    u16 max_acl_mac_addrs;
    u32 flags;
    u32 regulatory_flags;
    u32 features;
    u8 ext_features[DIV_ROUND_UP(NUM_NL80211_EXT_FEATURES# 8)];
    u32 ap_sme_capa;
    enum cfg80211_signal_type signal_type;
    int bss_priv_size;
    u8 max_scan_ssids;
    u8 max_sched_scan_ssids;
    u8 max_match_sets;
    u16 max_scan_ie_len;
    u16 max_sched_scan_ie_len;
    int n_cipher_suites;
    const u32 * cipher_suites;
    u8 retry_short;
    u8 retry_long;
    u32 frag_threshold;
    u32 rts_threshold;
    u8 coverage_class;
    char fw_version[ETHTOOL_FWVERS_LEN];
    u32 hw_version;
#ifdef CONFIG_PM
    const struct wiphy_wowlan_support * wowlan;
    struct cfg80211_wowlan * wowlan_config;
#endif
    u16 max_remain_on_channel_duration;
    u8 max_num_pmkids;
    u32 available_antennas_tx;
    u32 available_antennas_rx;
    u32 probe_resp_offload;
    const u8 * extended_capabilities;
    const u8 * extended_capabilities_mask;
    u8 extended_capabilities_len;
    const void * privid;
    struct ieee80211_supported_band * bands[IEEE80211_NUM_BANDS];
    void (* reg_notifier) (struct wiphy *wiphy, struct regulatory_request *request);
};
```



```
const struct ieee80211_regdomain __rcu * regd;
struct device dev;
bool registered;
struct dentry * debugfsdir;
const struct ieee80211_ht_cap * ht_capa_mod_mask;
const struct ieee80211_vht_cap * vht_capa_mod_mask;
possible_net_t _net;
#ifdef CONFIG_CFG80211_WEXT
const struct iw_handler_def * wext;
#endif
const struct wiphy_coalesce_support * coalesce;
const struct wiphy_vendor_command * vendor_commands;
const struct nl80211_vendor_cmd_info * vendor_events;
int n_vendor_commands;
int n_vendor_events;
u16 max_ap_assoc_sta;
u8 max_num_csa_counters;
u8 max_adj_channel_rssi_comp;
char priv[0];
};
```

## Members

|                      |  |
|----------------------|--|
| perm_addr[ETH_ALEN]  | permanent MAC address of this device   |
| addr_mask[ETH_ALEN]  | If the device supports multiple MAC addresses by masking, set this to a mask with variable bits set to 1, e.g. if the last four bits are variable then set it to 00-00-00-00-00-0f. The actual variable bits shall be determined by the interfaces added, with interfaces not matching the mask being rejected to be brought up. |
| addresses            | If the device has more than one address, set this pointer to a list of addresses (6 bytes each). The first one will be used by default for perm_addr. In this case, the mask should be set to all-zeroes. In this case it is assumed that the device can handle the same number of arbitrary MAC addresses.                      |
| mgmt_types           | bitmasks of frame subtypes that can be subscribed to or transmitted through nl80211, points to an array indexed by interface type  |
| iface_combinations   | Valid interface combinations array, should not list single interface types.  |
| n_iface_combinations | number of entries in <i>iface_combinations</i> array.  |
| software_iftypes     | bitmask of software interface types, these are not subject to any restrictions since they are purely managed in SW.  |
| n_addresses          | number of addresses in <i>addresses</i> .  |
| interface_modes      | bitmask of interfaces types valid for this wiphy, must be set by driver  |
| max_acl_mac_addrs    | Maximum number of MAC addresses that the device supports for ACL.  |

|  |  |
|--|--|
| flags  | wiphy flags, see enum wiphy_flags  |
| regulatory_flags                               | wiphy regulatory flags, see enum ieee80211_regulatory_flags  |
| features                                       | features advertised to nl80211, see enum nl80211_feature_flags.  |
| ext_features[DIV_ROUND_UP(NUM_ExtFeatures, 8)] | features advertised to nl80211, see enum nl80211_ext_feature_index.  |
| ap_sme_capa                                    | AP SME capabilities, flags from enum nl80211_ap_sme_features.  |
| signal_type                                    | signal type reported in struct cfg80211_bss.   |
| bss_priv_size                                  | each BSS struct has private data allocated with it, this variable determines its size  |
| max_scan_ssids                                 | maximum number of SSIDs the device can scan for in any given scan  |
| max_sched_scan_ssids                           | maximum number of SSIDs the device can scan for in any given scheduled scan  |
| max_match_sets                                 | maximum number of match sets the device can handle when performing a scheduled scan, 0 if filtering is not supported.  |
| max_scan_ie_len                                | maximum length of user-controlled IEs device can add to probe request frames transmitted during a scan, must not include fixed IEs like supported rates          |
| max_sched_scan_ie_len                          | same as max_scan_ie_len, but for scheduled scans   |
| n_cipher_suites                                | number of supported cipher suites  |
| cipher_suites                                  | supported cipher suites  |
| retry_short                                    | Retry limit for short frames (dot11ShortRetryLimit)  |
| retry_long                                     | Retry limit for long frames (dot11LongRetryLimit)  |
| frag_threshold                                 | Fragmentation threshold (dot11FragmentationThreshold); -1 = fragmentation disabled, only odd values >= 256 used  |
| rts_threshold                                  | RTS threshold (dot11RTSThreshold); -1 = RTS/CTS disabled   |
| coverage_class                                 | current coverage class   |
| fw_version[ETHTOOL_FWVERS_LEN]                 | firmware version for ethtool reporting   |
| hw_version                                     | hardware version for ethtool reporting   |
| wowlan   | WoWLAN support information   |
| wowlan_config                                  | current WoWLAN configuration; this should usually not be used since access to it is necessarily racy, use the parameter passed to the suspend operation instead. |
| max_remain_on_channel_duration                 | Maximum time a remain-on-channel operation may request, if implemented.  |

|   |   |
|---|---|
| <code>max_num_pmkids</code>             | maximum number of PMKIDs supported by device  |
| <code>available_antennas_tx</code>      | bitmap of antennas which are available to be configured as TX antennas. Antenna configuration commands will be rejected unless this or <code>available_antennas_rx</code> is set.   |
| <code>available_antennas_rx</code>      | bitmap of antennas which are available to be configured as RX antennas. Antenna configuration commands will be rejected unless this or <code>available_antennas_tx</code> is set.   |
| <code>probe_resp_offload</code>         | Bitmap of supported protocols for probe response offloading. See enum <code>nl80211_probe_resp_offload_support_attr</code> . Only valid when the wiphy flag <code>WIPHY_FLAG_AP_PROBE_RESP_OFFLOAD</code> is set.   |
| <code>extended_capabilities</code>      | extended capabilities supported by the driver, additional capabilities might be supported by userspace; these are the 802.11 extended capabilities ("Extended Capabilities element") and are in the same format as in the information element. See 802.11-2012 8.4.2.29 for the defined fields. |
| <code>extended_capabilities_mask</code> | mask of the valid values  |
| <code>extended_capabilities_len</code>  | length of the extended capabilities   |
| <code>privid</code>                     | a pointer that drivers can use to identify if an arbitrary wiphy is theirs, e.g. in global notifiers  |
| <code>bands[IEEE80211_NUM_BANDS]</code> | information about bands/channels supported by this device   |
| <code>reg_notifier</code>               | the driver's regulatory notification callback, note that if your driver uses <code>wiphy_apply_custom_regulatory</code> the <code>reg_notifier</code> 's request can be passed as NULL  |
| <code>regd</code>                       | the driver's regulatory domain, if one was requested via the <code>regulatory_hint</code> API. This can be used by the driver on the <code>reg_notifier</code> if it chooses to ignore future regulatory domain changes caused by other drivers.  |
| <code>dev</code>                        | (virtual) struct device for this wiphy  |
| <code>registered</code>                 | helps synchronize suspend/resume with wiphy unregister  |
| <code>debugfsdir</code>                 | debugfs directory used for this wiphy, will be renamed automatically on wiphy renames   |
| <code>ht_capa_mod_mask</code>           | Specify what ht_cap values can be over-ridden. If null, then none can be over-ridden.   |
| <code>vht_capa_mod_mask</code>          | Specify what VHT capabilities can be over-ridden. If null, then none can be over-ridden.  |
| <code>_net</code>                       | the network namespace this wiphy currently lives in   |
| <code>wext</code>                       | wireless extension handlers   |
| <code>coalesce</code>                   | packet coalescing support information   |

|                           |  |
|---------------------------|--|
| vendor_commands           | array of vendor commands supported by the hardware   |
| vendor_events             | array of vendor events supported by the hardware   |
| n_vendor_commands         | number of vendor commands  |
| n_vendor_events           | number of vendor events  |
| max_ap_assoc_sta          | maximum number of associated stations supported in AP mode (including P2P GO) or 0 to indicate no such limit is advertised. The driver is allowed to advertise a theoretical limit that it can reach in some cases, but may not always reach.  |
| max_num_csa_counters      | Number of supported csa_counters in beacons and probe responses. This value should be set if the driver wishes to limit the number of csa counters. Default (0) means infinite.  |
| max_adj_channel_rssi_comp | max offset of between the channel on which the frame was sent and the channel on which the frame was heard for which the reported rssi is still valid. If a driver is able to compensate the low rssi when a frame is heard on different channel, then it should set this variable to the maximal offset for which it can compensate. This value should be set in MHz. |
| priv[0]                   | driver private data (sized according to wiphy_new parameter)   |

## Name

struct wireless\_dev — wireless device state

## Synopsis

```
struct wireless_dev {
    struct wiphy * wiphy;
    enum nl80211_iftype iftype;
    struct list_head list;
    struct net_device * netdev;
    u32 identifier;
    struct list_head mgmt_registrations;
    spinlock_t mgmt_registrations_lock;
    struct mutex mtx;
    bool use_4addr;
    bool p2p_started;
    u8 address[ETH_ALEN];
    u8 ssid[IEEE80211_MAX_SSID_LEN];
    u8 ssid_len;
    u8 mesh_id_len;
    u8 mesh_id_up_len;
    struct cfg80211_conn * conn;
    struct cfg80211_cached_keys * connect_keys;
    struct list_head event_list;
    spinlock_t event_lock;
    struct cfg80211_internal_bss * current_bss;
    struct cfg80211_chan_def preset_chandef;
    struct cfg80211_chan_def chandef;
    bool ibss_fixed;
    bool ibss_dfs_possible;
    bool ps;
    int ps_timeout;
    int beacon_interval;
    u32 ap_unexpected_nlportid;
    bool cac_started;
    unsigned long cac_start_time;
    unsigned int cac_time_ms;
    u32 owner_nlportid;
#ifdef CONFIG_CFG80211_WEXT
    struct wext;
#endif
};
```

## Members

|        |   |
|--------|---|
| wiphy  | pointer to hardware description                             |
| iftype | interface type  |
| list   | (private) Used to collect the interfaces                    |
| netdev | (private) Used to reference back to the netdev, may be NULL |

|                              |   |
|------------------------------|---|
| identifier                   | (private) Identifier used in nl80211 to identify this wireless device if it has no netdev   |
| mgmt_registrations           | list of registrations for management frames   |
| mgmt_registrations_lock      | lock for the list   |
| mtx                          | mutex used to lock data in this struct, may be used by drivers and some API functions require it held   |
| use_4addr                    | indicates 4addr mode is used on this interface, must be set by driver (if supported) on add_interface BEFORE registering the netdev and may otherwise be used by driver read-only, will be update by cfg80211 on change_interface |
| p2p_started                  | true if this is a P2P Device that has been started  |
| address[ETH_ALEN]            | The address for this device, valid only if <i>netdev</i> is NULL  |
| ssid[IEEE80211_MAX_SSID_LEN] | (private) Used by the internal configuration code   |
| ssid_len                     | (private) Used by the internal configuration code   |
| mesh_id_len                  | (private) Used by the internal configuration code   |
| mesh_id_up_len               | (private) Used by the internal configuration code   |
| conn                         | (private) cfg80211 software SME connection state machine data   |
| connect_keys                 | (private) keys to set after connection is established   |
| event_list                   | (private) list for internal event processing  |
| event_lock                   | (private) lock for event list   |
| current_bss                  | (private) Used by the internal configuration code   |
| preset_chandef               | (private) Used by the internal configuration code to track the channel to be used for AP later  |
| chandef                      | (private) Used by the internal configuration code to track the user-set channel definition.   |
| ibss_fixed                   | (private) IBSS is using fixed BSSID   |
| ibss_dfs_possible            | (private) IBSS may change to a DFS channel  |
| ps                           | powersave mode is enabled   |
| ps_timeout                   | dynamic powersave timeout   |
| beacon_interval              | beacon interval used on this device for transmitting beacons, 0 when not valid  |
| ap_unexpected_nlportid       | (private) netlink port ID of application registered for unexpected class 3 frames (AP mode)   |
| cac_started                  | true if DFS channel availability check has been started   |

|                             |  |
|-----------------------------|--|
| <code>cac_start_time</code> | timestamp (jiffies) when the dfs state was entered.            |
| <code>cac_time_ms</code>    | CAC time in ms   |
| <code>owner_nlportid</code> | (private) owner socket port ID                                 |
| <code>wext</code>           | (private) Used by the internal wireless extensions compat code |

## Description

For netdevs, this structure must be allocated by the driver that uses the `ieee80211_ptr` field in `struct net_device` (this is intentional so it can be allocated along with the `netdev`.) It need not be registered then as `netdev` registration will be intercepted by `cfg80211` to see the new wireless device.

For non-netdev uses, it must also be allocated by the driver in response to the `cfg80211` callbacks that require it, as there's no `netdev` registration in that case it may not be allocated outside of callback operations that return it.

## Name

wiphy\_new — create a new wiphy for use with cfg80211

## Synopsis

```
struct wiphy * wiphy_new (const struct cfg80211_ops * ops, int
sizeof_priv);
```

## Arguments

*ops*                    The configuration operations for this device

*sizeof\_priv*    The size of the private area to allocate

## Description

Create a new wiphy and associate the given operations with it. *sizeof\_priv* bytes are allocated for private use.

## Return

A pointer to the new wiphy. This pointer must be assigned to each netdev's ieee80211\_ptr for proper operation.



## Name

`wiphy_register` — register a wiphy with cfg80211

## Synopsis

```
int wiphy_register (struct wiphy * wiphy);
```

## Arguments

*wiphy* The wiphy to register.

## Return

A non-negative wiphy index or a negative error code.

## Name

wiphy\_unregister — deregister a wiphy from cfg80211

## Synopsis

```
void wiphy_unregister (struct wiphy * wiphy);
```

## Arguments

*wiphy* The wiphy to unregister.

## Description

After this call, no more requests can be made with this priv pointer, but the call may sleep to wait for an outstanding request that is being handled.

## Name

wiphy\_free — free wiphy

## Synopsis

```
void wiphy_free (struct wiphy * wiphy);
```

## Arguments

*wiphy* The wiphy to free

## Name

wiphy\_name — get wiphy name

## Synopsis

```
const char * wiphy_name (const struct wiphy * wiphy);
```

## Arguments

*wiphy* The wiphy whose name to return

## Return

The name of *wiphy*.

## Name

wiphy\_dev — get wiphy dev pointer

## Synopsis

```
struct device * wiphy_dev (struct wiphy * wiphy);
```

## Arguments

*wiphy* The wiphy whose device struct to look up

## Return

The dev of *wiphy*.

## Name

wiphy\_priv — return priv from wiphy

## Synopsis

```
void * wiphy_priv (struct wiphy * wiphy);
```

## Arguments

*wiphy* the wiphy whose priv pointer to return

## Return

The priv of *wiphy*.

## Name

`priv_to_wiphy` — return the wiphy containing the `priv`

## Synopsis

```
struct wiphy * priv_to_wiphy (void * priv);
```

## Arguments

*priv* a pointer previously returned by `wiphy_priv`

## Return

The wiphy of *priv*.

## Name

`set_wiphy_dev` — set device pointer for wiphy

## Synopsis

```
void set_wiphy_dev (struct wiphy * wiphy, struct device * dev);
```

## Arguments

*wiphy*    The wiphy whose device to bind

*dev*      The device to parent it to



## Name

`wdev_priv` — return wiphy priv from `wireless_dev`

## Synopsis

```
void * wdev_priv (struct wireless_dev * wdev);
```

## Arguments

*wdev*    The wireless device whose wiphy's priv pointer to return

## Return

The wiphy priv of *wdev*.

## Name

struct ieee80211\_iface\_limit — limit on certain interface types

## Synopsis

```
struct ieee80211_iface_limit {  
    u16 max;  
    u16 types;  
};
```

## Members

|       |   |
|-------|---|
| max   | maximum number of interfaces of these types |
| types | interface types (bits)                      |

## Name

struct ieee80211\_iface\_combination — possible interface combination

## Synopsis

```
struct ieee80211_iface_combination {
    const struct ieee80211_iface_limit * limits;
    u32 num_different_channels;
    u16 max_interfaces;
    u8 n_limits;
    bool beacon_int_infra_match;
    u8 radar_detect_widths;
    u8 radar_detect_regions;
};
```

## Members

|                        |   |
|------------------------|---|
| limits                 | limits for the given interface types  |
| num_different_channels | can use up to this many different channels  |
| max_interfaces         | maximum number of interfaces in total allowed in this group   |
| n_limits               | number of limitations   |
| beacon_int_infra_match | In this combination, the beacon intervals between infrastructure and AP types must match. This is required only in special cases. |
| radar_detect_widths    | bitmap of channel widths supported for radar detection  |
| radar_detect_regions   | bitmap of regions supported for radar detection   |

## Description

With this structure the driver can describe which interface combinations it supports concurrently.

## Examples

1. Allow #STA <= 1, #AP <= 1, matching BI, channels = 1, 2 total:

```
struct ieee80211_iface_limit limits1[] = {
    { .max = 1, .types = BIT(NL80211_IFTYPE_STATION), },
    { .max = 1, .types = BIT(NL80211_IFTYPE_AP), },
};
struct ieee80211_iface_combination combination1 = {
    .limits = limits1,
    .n_limits = ARRAY_SIZE(limits1),
    .max_interfaces = 2,
    .beacon_int_infra_match = true,
};
```

2. Allow  $\#\{\text{AP}, \text{P2P-GO}\} \leq 8$ , channels = 1, 8 total:

```
struct ieee80211_iface_limit limits2[] = {
{ .max = 8, .types = BIT(NL80211_IFTYPE_AP) |
  BIT(NL80211_IFTYPE_P2P_GO), },
};
struct ieee80211_iface_combination combination2 = {
  .limits = limits2,
  .n_limits = ARRAY_SIZE(limits2),
  .max_interfaces = 8,
  .num_different_channels = 1,
};
```

3. Allow  $\#\text{STA} \leq 1$ ,  $\#\{\text{P2P-client}, \text{P2P-GO}\} \leq 3$  on two channels, 4 total.

This allows for an infrastructure connection and three P2P connections.

```
struct ieee80211_iface_limit limits3[] = {
{ .max = 1, .types = BIT(NL80211_IFTYPE_STATION), },
{ .max = 3, .types = BIT(NL80211_IFTYPE_P2P_GO) |
  BIT(NL80211_IFTYPE_P2P_CLIENT), },
};
struct ieee80211_iface_combination combination3 = {
  .limits = limits3,
  .n_limits = ARRAY_SIZE(limits3),
  .max_interfaces = 4,
  .num_different_channels = 2,
};
```

## Name

cfg80211\_check\_combinations — check interface combinations

## Synopsis

```
int    cfg80211_check_combinations (struct wiphy * wiphy, const
int    num_different_channels, const u8  radar_detect, const int
iftype_num[NUM_NL80211_IFTYPES]);
```

## Arguments

|  |   |
|--|---|
| <i>wiphy</i>                           | the wiphy   |
| <i>num_different_channels</i>          | the number of different channels we want to use for verification  |
| <i>radar_detect</i>                    | a bitmap where each bit corresponds to a channel width where radar detection is needed, as in the definition of struct <code>ieee80211_iface_combination.radar_detect_widths</code> |
| <i>iftype_num[NUM_NL80211_IFTYPES]</i> | array with the numbers of interfaces of each interface type. The index is the interface type as specified in enum <code>nl80211_iftype</code> .                                     |

## Description

This function can be called by the driver to check whether a combination of interfaces and their types are allowed according to the interface combinations.

---

## Chapter 2. Actions and configuration

Each wireless device and each virtual interface offer a set of configuration operations and other actions that are invoked by userspace. Each of these actions is described in the operations structure, and the parameters these operations use are described separately.

Additionally, some operations are asynchronous and expect to get status information via some functions that drivers need to call.

Scanning and BSS list handling with its associated functionality is described in a separate chapter.

## Name

struct cfg80211\_ops — backend description for wireless configuration

## Synopsis

```
struct cfg80211_ops {
    int (* suspend) (struct wiphy *wiphy, struct cfg80211_wowlan *wow);
    int (* resume) (struct wiphy *wiphy);
    void (* set_wakeup) (struct wiphy *wiphy, bool enabled);
    struct wireless_dev * (* add_virtual_intf) (struct wiphy *wiphy, const char *name,
    int (* del_virtual_intf) (struct wiphy *wiphy, struct wireless_dev *wdev);
    int (* change_virtual_intf) (struct wiphy *wiphy, struct net_device *dev, enum nl80211_iftype type,
    int (* add_key) (struct wiphy *wiphy, struct net_device *netdev, u8 key_index, bool replace, const u8 *key,
    int (* get_key) (struct wiphy *wiphy, struct net_device *netdev, u8 key_index, bool replace, const u8 *key,
    int (* del_key) (struct wiphy *wiphy, struct net_device *netdev, u8 key_index, bool replace, const u8 *key,
    int (* set_default_key) (struct wiphy *wiphy, struct net_device *netdev, u8 key_index, bool replace, const u8 *key,
    int (* set_default_mgmt_key) (struct wiphy *wiphy, struct net_device *netdev, u8 key_index, bool replace, const u8 *key,
    int (* start_ap) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_ap_params *params);
    int (* change_beacon) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_beacon_params *params);
    int (* stop_ap) (struct wiphy *wiphy, struct net_device *dev);
    int (* add_station) (struct wiphy *wiphy, struct net_device *dev, const u8 *mac, struct station_params *params);
    int (* del_station) (struct wiphy *wiphy, struct net_device *dev, struct station_params *params);
    int (* change_station) (struct wiphy *wiphy, struct net_device *dev, const u8 *mac, struct station_params *params);
    int (* get_station) (struct wiphy *wiphy, struct net_device *dev, const u8 *mac, struct station_params *params);
    int (* dump_station) (struct wiphy *wiphy, struct net_device *dev, int idx, u8 *mac, struct station_params *params);
    int (* add_mpath) (struct wiphy *wiphy, struct net_device *dev, const u8 *dst, const u8 *src, u8 *next_hop);
    int (* del_mpath) (struct wiphy *wiphy, struct net_device *dev, const u8 *dst);
    int (* change_mpath) (struct wiphy *wiphy, struct net_device *dev, const u8 *dst, const u8 *src, u8 *next_hop);
    int (* get_mpath) (struct wiphy *wiphy, struct net_device *dev, u8 *dst, u8 *src, u8 *next_hop);
    int (* dump_mpath) (struct wiphy *wiphy, struct net_device *dev, int idx, u8 *dst, u8 *src, u8 *next_hop);
    int (* get_mpp) (struct wiphy *wiphy, struct net_device *dev, u8 *dst, u8 *src, u8 *next_hop);
    int (* dump_mpp) (struct wiphy *wiphy, struct net_device *dev, int idx, u8 *dst, u8 *src, u8 *next_hop);
    int (* get_mesh_config) (struct wiphy *wiphy, struct net_device *dev, struct mesh_config *config);
    int (* update_mesh_config) (struct wiphy *wiphy, struct net_device *dev, u32 mask, struct mesh_config *config);
    int (* join_mesh) (struct wiphy *wiphy, struct net_device *dev, const struct mesh_config *config);
    int (* leave_mesh) (struct wiphy *wiphy, struct net_device *dev);
    int (* join_ocb) (struct wiphy *wiphy, struct net_device *dev, struct ocb_setup *params);
    int (* leave_ocb) (struct wiphy *wiphy, struct net_device *dev);
    int (* change_bss) (struct wiphy *wiphy, struct net_device *dev, struct bss_params *params);
    int (* set_txq_params) (struct wiphy *wiphy, struct net_device *dev, struct ieee80211_txq_params *params);
    int (* libertas_set_mesh_channel) (struct wiphy *wiphy, struct net_device *dev, struct libertas_mesh_channel *params);
    int (* set_monitor_channel) (struct wiphy *wiphy, struct cfg80211_chan_def *chand_def);
    int (* scan) (struct wiphy *wiphy, struct cfg80211_scan_request *request);
    int (* auth) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_auth_params *params);
    int (* assoc) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_assoc_params *params);
    int (* deauth) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_deauth_params *params);
    int (* disassoc) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_disassoc_params *params);
    int (* connect) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_connect_params *params);
    int (* disconnect) (struct wiphy *wiphy, struct net_device *dev, u16 reason_code);
    int (* join_ibss) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_ibss_params *params);
    int (* leave_ibss) (struct wiphy *wiphy, struct net_device *dev);
    int (* set_mcast_rate) (struct wiphy *wiphy, struct net_device *dev, int rate[IEEE80211_NUM_MCS]);
}
```

```

int (* set_wiphy_params) (struct wiphy *wiphy, u32 changed);
int (* set_tx_power) (struct wiphy *wiphy, struct wireless_dev *wdev, enum nl80211_tx_power_flag type, int dbm);
int (* get_tx_power) (struct wiphy *wiphy, struct wireless_dev *wdev, int *dbm);
int (* set_wds_peer) (struct wiphy *wiphy, struct net_device *dev, const u8 *addr);
void (* rfkill_poll) (struct wiphy *wiphy);
#ifdef CONFIG_NL80211_TESTMODE
int (* testmode_cmd) (struct wiphy *wiphy, struct wireless_dev *wdev, void *data, unsigned int len);
int (* testmode_dump) (struct wiphy *wiphy, struct sk_buff *skb, struct netlink_callback *cb);
#endif
int (* set_bitrate_mask) (struct wiphy *wiphy, struct net_device *dev, const u8 *rates, u32 rates_mask);
int (* dump_survey) (struct wiphy *wiphy, struct net_device *netdev, int idx, struct survey_info *survey_info);
int (* set_pmksa) (struct wiphy *wiphy, struct net_device *netdev, struct cfg80211_pmksa *pmksa);
int (* del_pmksa) (struct wiphy *wiphy, struct net_device *netdev, struct cfg80211_pmksa *pmksa);
int (* flush_pmksa) (struct wiphy *wiphy, struct net_device *netdev);
int (* remain_on_channel) (struct wiphy *wiphy, struct wireless_dev *wdev, struct cfg80211_remain_on_channel_req *req);
int (* cancel_remain_on_channel) (struct wiphy *wiphy, struct wireless_dev *wdev, struct cfg80211_remain_on_channel_req *req);
int (* mgmt_tx) (struct wiphy *wiphy, struct wireless_dev *wdev, struct cfg80211_mgmt_tx_params *params, u64 cookie);
int (* mgmt_tx_cancel_wait) (struct wiphy *wiphy, struct wireless_dev *wdev, u64 cookie);
int (* set_power_mgmt) (struct wiphy *wiphy, struct net_device *dev, bool enabled);
int (* set_cqm_rssi_config) (struct wiphy *wiphy, struct net_device *dev, s32 rssi_threshold, u32 time_delta);
int (* set_cqm_txe_config) (struct wiphy *wiphy, struct net_device *dev, u32 rate, u32 tx_time_delta);
void (* mgmt_frame_register) (struct wiphy *wiphy, struct wireless_dev *wdev, u16 frame_type);
int (* set_antenna) (struct wiphy *wiphy, u32 tx_ant, u32 rx_ant);
int (* get_antenna) (struct wiphy *wiphy, u32 *tx_ant, u32 *rx_ant);
int (* sched_scan_start) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_sched_scan_req *req);
int (* sched_scan_stop) (struct wiphy *wiphy, struct net_device *dev);
int (* set_rekey_data) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_rekey_data *data);
int (* tdls_mgmt) (struct wiphy *wiphy, struct net_device *dev, const u8 *peer, u16 cmd, const u8 *data, u16 data_len);
int (* tdls_oper) (struct wiphy *wiphy, struct net_device *dev, const u8 *peer, enum nl80211_tdls_operation cmd);
int (* probe_client) (struct wiphy *wiphy, struct net_device *dev, const u8 *peer, struct cfg80211_probe_client_req *req);
int (* set_noack_map) (struct wiphy *wiphy, struct net_device *dev, u16 noack_map);
int (* get_channel) (struct wiphy *wiphy, struct wireless_dev *wdev, struct cfg80211_channel_request *req);
int (* start_p2p_device) (struct wiphy *wiphy, struct wireless_dev *wdev);
void (* stop_p2p_device) (struct wiphy *wiphy, struct wireless_dev *wdev);
int (* set_mac_acl) (struct wiphy *wiphy, struct net_device *dev, const struct cfg80211_mac_acl *acl);
int (* start_radar_detection) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_radar_detection_req *req);
int (* update_ft_ies) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_ft_ies_req *req);
int (* crit_proto_start) (struct wiphy *wiphy, struct wireless_dev *wdev, enum nl80211_crit_proto crit_proto);
void (* crit_proto_stop) (struct wiphy *wiphy, struct wireless_dev *wdev);
int (* set_coalesce) (struct wiphy *wiphy, struct cfg80211_coalesce *coalesce);
int (* channel_switch) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_channel_switch_req *req);
int (* set_qos_map) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_qos_map *map);
int (* set_ap_chanwidth) (struct wiphy *wiphy, struct net_device *dev, struct cfg80211_ap_chanwidth_req *req);
int (* add_tx_ts) (struct wiphy *wiphy, struct net_device *dev, u8 tsid, const u8 *data, u16 data_len);
int (* del_tx_ts) (struct wiphy *wiphy, struct net_device *dev, u8 tsid, const u8 *data, u16 data_len);
int (* tdls_channel_switch) (struct wiphy *wiphy, struct net_device *dev, const u8 *peer, struct cfg80211_tdls_channel_switch_req *req);
void (* tdls_cancel_channel_switch) (struct wiphy *wiphy, struct net_device *dev, const u8 *peer);
};

```



## Members

|                                   |  |
|-----------------------------------|--|
| <code>suspend</code>              | wiphy device needs to be suspended. The variable <i>wow</i> will be NULL or contain the enabled Wake-on-Wireless triggers that are configured for the device.  |
| <code>resume</code>               | wiphy device needs to be resumed   |
| <code>set_wakeup</code>           | Called when WoWLAN is enabled/disabled, use this callback to call <code>device_set_wakeup_enable</code> to enable/disable wakeup from the device.  |
| <code>add_virtual_intf</code>     | create a new virtual interface with the given name, must set the struct <code>wireless_dev</code> 's iftype. Beware: You must create the new netdev in the wiphy's network namespace! Returns the struct <code>wireless_dev</code> , or an <code>ERR_PTR</code> . For P2P device wdevs, the driver must also set the address member in the wdev. |
| <code>del_virtual_intf</code>     | remove the virtual interface   |
| <code>change_virtual_intf</code>  | change type/configuration of virtual interface, keep the struct <code>wireless_dev</code> 's iftype updated.   |
| <code>add_key</code>              | add a key with the given parameters. <i>mac_addr</i> will be NULL when adding a group key.   |
| <code>get_key</code>              | get information about the key with the given parameters. <i>mac_addr</i> will be NULL when requesting information for a group key. All pointers given to the <i>callback</i> function need not be valid after it returns. This function should return an error if it is not possible to retrieve the key, -ENOENT if it doesn't exist.           |
| <code>del_key</code>              | remove a key given the <i>mac_addr</i> (NULL for a group key) and <i>key_index</i> , return -ENOENT if the key doesn't exist.  |
| <code>set_default_key</code>      | set the default key on an interface  |
| <code>set_default_mgmt_key</code> | set the default management frame key on an interface   |
| <code>start_ap</code>             | Start acting in AP mode defined by the parameters.   |
| <code>change_beacon</code>        | Change the beacon parameters for an access point mode interface. This should reject the call when AP mode wasn't started.  |
| <code>stop_ap</code>              | Stop being an AP, including stopping beaconing.  |
| <code>add_station</code>          | Add a new station.   |
| <code>del_station</code>          | Remove a station   |
| <code>change_station</code>       | Modify a given station. Note that flags changes are not much validated in cfg80211, in particular the auth/assoc/authorized flags might come to the driver in invalid combinations -- make sure to check them, also against the existing state! Drivers must call <code>cfg80211_check_station_change</code> to validate the information.        |

|  |   |
|--|---|
| <code>get_station</code>               | get station information for the station identified by <i>mac</i>  |
| <code>dump_station</code>              | dump station callback -- resume dump at index <i>idx</i>  |
| <code>add_mpath</code>                 | add a fixed mesh path   |
| <code>del_mpath</code>                 | delete a given mesh path  |
| <code>change_mpath</code>              | change a given mesh path  |
| <code>get_mpath</code>                 | get a mesh path for the given parameters  |
| <code>dump_mpath</code>                | dump mesh path callback -- resume dump at index <i>idx</i>  |
| <code>get_mpp</code>                   | get a mesh proxy path for the given parameters  |
| <code>dump_mpp</code>                  | dump mesh proxy path callback -- resume dump at index <i>idx</i>  |
| <code>get_mesh_config</code>           | Get the current mesh configuration  |
| <code>update_mesh_config</code>        | Update mesh parameters on a running mesh. The mask is a bitfield which tells us which parameters to set, and which to leave alone.  |
| <code>join_mesh</code>                 | join the mesh network with the specified parameters (invoked with the <code>wireless_dev</code> mutex held)   |
| <code>leave_mesh</code>                | leave the current mesh network (invoked with the <code>wireless_dev</code> mutex held)  |
| <code>join_ocb</code>                  | join the OCB network with the specified parameters (invoked with the <code>wireless_dev</code> mutex held)  |
| <code>leave_ocb</code>                 | leave the current OCB network (invoked with the <code>wireless_dev</code> mutex held)   |
| <code>change_bss</code>                | Modify parameters for a given BSS.  |
| <code>set_txq_params</code>            | Set TX queue parameters   |
| <code>libertas_set_mesh_channel</code> | Only for backward compatibility for <code>libertas</code> , as it doesn't implement <code>join_mesh</code> and needs to set the channel to join the mesh instead.   |
| <code>set_monitor_channel</code>       | Set the monitor mode channel for the device. If other interfaces are active this callback should reject the configuration. If no interfaces are active or the device is down, the channel should be stored for when a monitor interface becomes active.                             |
| <code>scan</code>                      | Request to do a scan. If returning zero, the scan request is given the driver, and will be valid until passed to <code>cfg80211_scan_done</code> . For scan results, call <code>cfg80211_inform_bss</code> ; you can call this outside the <code>scan/scan_done</code> bracket too. |
| <code>auth</code>                      | Request to authenticate with the specified peer (invoked with the <code>wireless_dev</code> mutex held)   |
| <code>assoc</code>                     | Request to (re)associate with the specified peer (invoked with the <code>wireless_dev</code> mutex held)  |

|                  |   |
|------------------|---|
| deauth           | Request to deauthenticate from the specified peer (invoked with the wireless_dev mutex held)  |
| disassoc         | Request to disassociate from the specified peer (invoked with the wireless_dev mutex held)  |
| connect          | Connect to the ESS with the specified parameters. When connected, call <code>cfg80211_connect_result</code> with status code <code>WLAN_STATUS_SUCCESS</code> . If the connection fails for some reason, call <code>cfg80211_connect_result</code> with the status from the AP. (invoked with the wireless_dev mutex held)  |
| disconnect       | Disconnect from the BSS/ESS. (invoked with the wireless_dev mutex held)   |
| join_ibss        | Join the specified IBSS (or create if necessary). Once done, call <code>cfg80211_ibss_joined</code> , also call that function when changing BSSID due to a merge. (invoked with the wireless_dev mutex held)  |
| leave_ibss       | Leave the IBSS. (invoked with the wireless_dev mutex held)  |
| set_mcast_rate   | Set the specified multicast rate (only if vif is in ADHOC or MESH mode)   |
| set_wiphy_params | Notify that wiphy parameters have changed; <i>changed</i> bitfield (see enum <code>wiphy_params_flags</code> ) describes which values have changed. The actual parameter values are available in struct <code>wiphy</code> . If returning an error, no value should be changed.   |
| set_tx_power     | set the transmit power according to the parameters, the power passed is in mBm, to get dBm use <code>MBM_TO_DBM</code> . The wdev may be NULL if power was set for the wiphy, and will always be NULL unless the driver supports per-vif TX power (as advertised by the nl80211 feature flag.)  |
| get_tx_power     | store the current TX power into the dbm variable; return 0 if successful  |
| set_wds_peer     | set the WDS peer for a WDS interface  |
| rkill_poll       | polls the hw rkill line, use <code>cfg80211</code> reporting functions to adjust rkill hw state   |
| testmode_cmd     | run a test mode command; <code>wdev</code> may be NULL  |
| testmode_dump    | Implement a test mode dump. The <code>cb-&gt;args[2]</code> and up may be used by the function, but 0 and 1 must not be touched. Additionally, return error codes other than <code>-ENOBUFS</code> and <code>-ENOENT</code> will terminate the dump and return to userspace with an error, so be careful. If any data was passed in from userspace then the <code>data/len</code> arguments will be present and point to the data contained in <code>NL80211_ATTR_TESTDATA</code> . |
| set_bitrate_mask | set the bitrate mask configuration  |
| dump_survey      | get site survey information.  |

|                          |   |
|--------------------------|---|
| set_pmksa                | Cache a PMKID for a BSSID. This is mostly useful for fullmac devices running firmwares capable of generating the (re) association RSN IE. It allows for faster roaming between WPA2 BSSIDs.   |
| del_pmksa                | Delete a cached PMKID.  |
| flush_pmksa              | Flush all cached PMKIDs.  |
| remain_on_channel        | Request the driver to remain awake on the specified channel for the specified duration to complete an off-channel operation (e.g., public action frame exchange). When the driver is ready on the requested channel, it must indicate this with an event notification by calling <code>cfg80211_ready_on_channel</code> .   |
| cancel_remain_on_channel | Cancel an on-going remain-on-channel operation. This allows the operation to be terminated prior to timeout based on the duration value.  |
| mgmt_tx                  | Transmit a management frame.  |
| mgmt_tx_cancel_wait      | Cancel the wait time from transmitting a management frame on another channel  |
| set_power_mgmt           | Configure WLAN power management. A timeout value of -1 allows the driver to adjust the dynamic ps timeout value.  |
| set_cqm_rssi_config      | Configure connection quality monitor RSSI threshold.  |
| set_cqm_txe_config       | Configure connection quality monitor TX error thresholds.   |
| mgmt_frame_register      | Notify driver that a management frame type was registered. Note that this callback may not sleep, and cannot run concurrently with itself.  |
| set_antenna              | Set antenna configuration (tx_ant, rx_ant) on the device. Parameters are bitmaps of allowed antennas to use for TX/RX. Drivers may reject TX/RX mask combinations they cannot support by returning -EINVAL (also see <code>nl80211.h NL80211_ATTR_WIPHY_ANTENNA_TX</code> ).  |
| get_antenna              | Get current antenna configuration from device (tx_ant, rx_ant).   |
| sched_scan_start         | Tell the driver to start a scheduled scan.  |
| sched_scan_stop          | Tell the driver to stop an ongoing scheduled scan. This call must stop the scheduled scan and be ready for starting a new one before it returns, i.e. <code>sched_scan_start</code> may be called immediately after that again and should not fail in that case. The driver should not call <code>cfg80211_sched_scan_stopped</code> for a requested stop (when this method returns 0.) |
| set_rekey_data           | give the data necessary for GTK rekeying to the driver  |
| tdls_mgmt                | Transmit a TDLS management frame.   |
| tdls_oper                | Perform a high-level TDLS operation (e.g. TDLS link setup).   |

|                       |  |
|-----------------------|--|
| probe_client          | probe an associated client, must return a cookie that it later passes to <code>cfg80211_probe_status</code> .  |
| set_noack_map         | Set the NoAck Map for the TIDs.  |
| get_channel           | Get the current operating channel for the virtual interface. For monitor interfaces, it should return NULL unless there's a single current monitoring channel.   |
| start_p2p_device      | Start the given P2P device.  |
| stop_p2p_device       | Stop the given P2P device.   |
| set_mac_acl           | Sets MAC address control list in AP and P2P GO mode. Parameters include ACL policy, an array of MAC address of stations and the number of MAC addresses. If there is already a list in driver this new list replaces the existing one. Driver has to clear its ACL when number of MAC addresses entries is passed as 0. Drivers which advertise the support for MAC based ACL have to implement this callback.   |
| start_radar_detection | Start radar detection in the driver.   |
| update_ft_ies         | Provide updated Fast BSS Transition information to the driver. If the SME is in the driver/firmware, this information can be used in building Authentication and Reassociation Request frames.   |
| crit_proto_start      | Indicates a critical protocol needs more link reliability for a given duration (milliseconds). The protocol is provided so the driver can take the most appropriate actions.   |
| crit_proto_stop       | Indicates critical protocol no longer needs increased link reliability. This operation can not fail.   |
| set_coalesce          | Set coalesce parameters.   |
| channel_switch        | initiate channel-switch procedure (with CSA). Driver is responsible for verifying if the switch is possible. Since this is inherently tricky driver may decide to disconnect an interface later with <code>cfg80211_stop_iface</code> . This doesn't mean driver can accept everything. It should do it's best to verify requests and reject them as soon as possible.   |
| set_qos_map           | Set QoS mapping information to the driver  |
| set_ap_chanwidth      | Set the AP (including P2P GO) mode channel width for the given interface This is used e.g. for dynamic HT 20/40 MHz channel width changes during the lifetime of the BSS.  |
| add_tx_ts             | validate (if <code>admitted_time</code> is 0) or add a TX TS to the device with the given parameters; action frame exchange has been handled by userspace so this just has to modify the TX path to take the TS into account. If the <code>admitted_time</code> is 0 just validate the parameters to make sure the session can be created at all; it is valid to just always return success for that but that may result in inefficient behaviour (handshake with the peer followed by immediate teardown when the addition is later rejected) |

|   |  |
|---|--|
| <code>del_tx_ts</code>                  | remove an existing TX TS   |
| <code>tdls_channel_switch</code>        | Start channel-switching with a TDLS peer. The driver is responsible for continually initiating channel-switching operations and returning to the base channel for communication with the AP. |
| <code>tdls_cancel_channel_switch</code> | Stop channel-switching with a TDLS peer. Both peers must be on the base channel when the call completes.   |

## Description

This struct is registered by fullmac card drivers and/or wireless stacks in order to handle configuration requests on their interfaces.

All callbacks except where otherwise noted should return 0 on success or a negative error code.

All operations are currently invoked under `rtnl` for consistency with the wireless extensions but this is subject to reevaluation as soon as this code is used more widely and we have a first user without `wext`.

## Name

struct vif\_params — describes virtual interface parameters

## Synopsis

```
struct vif_params {  
    int use_4addr;  
    u8 macaddr[ETH_ALEN];  
};
```

## Members

|                   |  |
|-------------------|--|
| use_4addr         | use 4-address frames   |
| macaddr[ETH_ALEN] | address to use for this virtual interface. If this parameter is set to zero address the driver may determine the address as needed. This feature is only fully supported by drivers that enable the NL80211_FEATURE_MAC_ON_CREATE flag. Others may support creating * only p2p devices with specified MAC. |

## Name

struct key\_params — key information

## Synopsis

```
struct key_params {  
    const u8 * key;  
    const u8 * seq;  
    int key_len;  
    int seq_len;  
    u32 cipher;  
};
```

## Members

|         |   |
|---------|---|
| key     | key material  |
| seq     | sequence counter (IV/PN) for TKIP and CCMP keys, only used with the <code>get_key</code> callback, must be in little endian, length given by <i>seq_len</i> . |
| key_len | length of key material  |
| seq_len | length of <i>seq</i> .  |
| cipher  | cipher suite selector   |

## Description

Information about a key



## Name

enum survey\_info\_flags — survey information flags

## Synopsis

```
enum survey_info_flags {  
    SURVEY_INFO_NOISE_DBM,  
    SURVEY_INFO_IN_USE,  
    SURVEY_INFO_TIME,  
    SURVEY_INFO_TIME_BUSY,  
    SURVEY_INFO_TIME_EXT_BUSY,  
    SURVEY_INFO_TIME_RX,  
    SURVEY_INFO_TIME_TX,  
    SURVEY_INFO_TIME_SCAN  
};
```

## Constants

|                           |   |
|---------------------------|---|
| SURVEY_INFO_NOISE_DBM     | noise (in dBm) was filled in              |
| SURVEY_INFO_IN_USE        | channel is currently being used           |
| SURVEY_INFO_TIME          | active time (in ms) was filled in         |
| SURVEY_INFO_TIME_BUSY     | busy time was filled in                   |
| SURVEY_INFO_TIME_EXT_BUSY | extension channel busy time was filled in |
| SURVEY_INFO_TIME_RX       | receive time was filled in                |
| SURVEY_INFO_TIME_TX       | transmit time was filled in               |
| SURVEY_INFO_TIME_SCAN     | scan time was filled in                   |

## Description

Used by the driver to indicate which info in struct survey\_info it has filled in during the get\_survey.

## Name

struct survey\_info — channel survey response

## Synopsis

```
struct survey_info {
    struct ieee80211_channel * channel;
    u64 time;
    u64 time_busy;
    u64 time_ext_busy;
    u64 time_rx;
    u64 time_tx;
    u64 time_scan;
    u32 filled;
    s8 noise;
};
```

## Members

|               |   |
|---------------|---|
| channel       | the channel this survey record reports, may be NULL for a single record to report global statistics |
| time          | amount of time in ms the radio was turn on (on the channel)   |
| time_busy     | amount of time the primary channel was sensed busy  |
| time_ext_busy | amount of time the extension channel was sensed busy  |
| time_rx       | amount of time the radio spent receiving data   |
| time_tx       | amount of time the radio spent transmitting data  |
| time_scan     | amount of time the radio spent for scanning   |
| filled        | bitflag of flags from enum survey_info_flags  |
| noise         | channel noise in dBm. This and all following fields are optional                                    |

## Description

Used by `dump_survey` to report back per-channel survey information.

This structure can later be expanded with things like channel duty cycle etc.

## Name

struct cfg80211\_beacon\_data — beacon data

## Synopsis

```
struct cfg80211_beacon_data {
    const u8 * head;
    const u8 * tail;
    const u8 * beacon_ies;
    const u8 * proberesp_ies;
    const u8 * assocresp_ies;
    const u8 * probe_resp;
    size_t head_len;
    size_t tail_len;
    size_t beacon_ies_len;
    size_t proberesp_ies_len;
    size_t assocresp_ies_len;
    size_t probe_resp_len;
};
```

## Members

|                   |  |
|-------------------|--|
| head              | head portion of beacon (before TIM IE) or NULL if not changed                    |
| tail              | tail portion of beacon (after TIM IE) or NULL if not changed                     |
| beacon_ies        | extra information element(s) to add into Beacon frames or NULL                   |
| proberesp_ies     | extra information element(s) to add into Probe Response frames or NULL           |
| assocresp_ies     | extra information element(s) to add into (Re)Association Response frames or NULL |
| probe_resp        | probe response template (AP mode only)   |
| head_len          | length of <i>head</i>  |
| tail_len          | length of <i>tail</i>  |
| beacon_ies_len    | length of <i>beacon_ies</i> in octets  |
| proberesp_ies_len | length of <i>proberesp_ies</i> in octets   |
| assocresp_ies_len | length of <i>assocresp_ies</i> in octets   |
| probe_resp_len    | length of probe response template ( <i>probe_resp</i> )                          |

## Name

struct cfg80211\_ap\_settings — AP configuration

## Synopsis

```
struct cfg80211_ap_settings {
    struct cfg80211_chan_def chandef;
    struct cfg80211_beacon_data beacon;
    int beacon_interval;
    int dtim_period;
    const u8 * ssid;
    size_t ssid_len;
    enum nl80211_hidden_ssid hidden_ssid;
    struct cfg80211_crypto_settings crypto;
    bool privacy;
    enum nl80211_auth_type auth_type;
    enum nl80211_smpps_mode smpps_mode;
    int inactivity_timeout;
    u8 p2p_ctwindow;
    bool p2p_opp_ps;
    const struct cfg80211_acl_data * acl;
};
```

## Members

|                    |  |
|--------------------|--|
| chandef            | defines the channel to use   |
| beacon             | beacon data  |
| beacon_interval    | beacon interval  |
| dtim_period        | DTIM period  |
| ssid               | SSID to be used in the BSS (note: may be NULL if not provided from user space) |
| ssid_len           | length of <i>ssid</i>  |
| hidden_ssid        | whether to hide the SSID in Beacon/Probe Response frames                       |
| crypto             | crypto settings  |
| privacy            | the BSS uses privacy   |
| auth_type          | Authentication type (algorithm)  |
| smpps_mode         | SMPS mode  |
| inactivity_timeout | time in seconds to determine station's inactivity.                             |
| p2p_ctwindow       | P2P CT Window  |
| p2p_opp_ps         | P2P opportunistic PS   |

acl

ACL configuration used by the drivers which has support for MAC address based access control

## Description

Used to configure an AP interface.

## Name

struct station\_parameters — station parameters

## Synopsis

```
struct station_parameters {
    const u8 * supported_rates;
    struct net_device * vlan;
    u32 sta_flags_mask;
    u32 sta_flags_set;
    u32 sta_modify_mask;
    int listen_interval;
    u16 aid;
    u8 supported_rates_len;
    u8 plink_action;
    u8 plink_state;
    const struct ieee80211_ht_cap * ht_capa;
    const struct ieee80211_vht_cap * vht_capa;
    u8 uapsd_queues;
    u8 max_sp;
    enum nl80211_mesh_power_mode local_pm;
    u16 capability;
    const u8 * ext_capab;
    u8 ext_capab_len;
    const u8 * supported_channels;
    u8 supported_channels_len;
    const u8 * supported_oper_classes;
    u8 supported_oper_classes_len;
    u8 opmode_notif;
    bool opmode_notif_used;
};
```

## Members

|                     |  |
|---------------------|--|
| supported_rates     | supported rates in IEEE 802.11 format (or NULL for no change)  |
| vlan                | vlan interface station should belong to  |
| sta_flags_mask      | station flags that changed (bitmask of BIT(NL80211_STA_FLAG...))   |
| sta_flags_set       | station flags values (bitmask of BIT(NL80211_STA_FLAG...))   |
| sta_modify_mask     | bitmap indicating which parameters changed (for those that don't have a natural “no change” value), see enum station_parameters_apply_mask |
| listen_interval     | listen interval or -1 for no change  |
| aid                 | AID or zero for no change  |
| supported_rates_len | number of supported rates  |

|                            |  |
|----------------------------|--|
| plink_action               | plink action to take   |
| plink_state                | set the peer link state for a station  |
| ht_capa                    | HT capabilities of station   |
| vht_capa                   | VHT capabilities of station  |
| uapsd_queues               | bitmap of queues configured for uapsd. same format as the AC bitmap in the QoS info field      |
| max_sp                     | max Service Period. same format as the MAX_SP in the QoS info field (but already shifted down) |
| local_pm                   | local link-specific mesh power save mode (no change when set to unknown)                       |
| capability                 | station capability   |
| ext_capab                  | extended capabilities of the station   |
| ext_capab_len              | number of extended capabilities  |
| supported_channels         | supported channels in IEEE 802.11 format   |
| supported_channels_len     | number of supported channels   |
| supported_oper_classes     | supported oper classes in IEEE 802.11 format   |
| supported_oper_classes_len | number of supported operating classes  |
| opmode_notif               | operating mode field from Operating Mode Notification  |
| opmode_notif_used          | information if operating mode field is used  |

## Description

Used to change and create a new station.

## Name

enum rate\_info\_flags — bitrate info flags

## Synopsis

```
enum rate_info_flags {  
    RATE_INFO_FLAGS_MCS,  
    RATE_INFO_FLAGS_VHT_MCS,  
    RATE_INFO_FLAGS_SHORT_GI,  
    RATE_INFO_FLAGS_60G  
};
```

## Constants

|                          |                               |
|--------------------------|-------------------------------|
| RATE_INFO_FLAGS_MCS      | mcs field filled with HT MCS  |
| RATE_INFO_FLAGS_VHT_MCS  | mcs field filled with VHT MCS |
| RATE_INFO_FLAGS_SHORT_GI | 400ns guard interval          |
| RATE_INFO_FLAGS_60G      | 60GHz MCS                     |

## Description

Used by the driver to indicate the specific rate transmission type for 802.11n transmissions.



## Name

struct rate\_info — bitrate information

## Synopsis

```
struct rate_info {  
    u8 flags;  
    u8 mcs;  
    u16 legacy;  
    u8 nss;  
    u8 bw;  
};
```

## Members

|        |   |
|--------|---|
| flags  | bitflag of flags from enum rate_info_flags      |
| mcs    | mcs index if struct describes a 802.11n bitrate |
| legacy | bitrate in 100kbit/s for 802.11abg              |
| nss    | number of streams (VHT only)                    |
| bw     | bandwidth (from enum rate_info_bw)              |

## Description

Information about a receiving or transmitting bitrate

## Name

struct station\_info — station information

## Synopsis

```
struct station_info {
    u32 filled;
    u32 connected_time;
    u32 inactive_time;
    u64 rx_bytes;
    u64 tx_bytes;
    u16 llid;
    u16 plid;
    u8 plink_state;
    s8 signal;
    s8 signal_avg;
    u8 chains;
    s8 chain_signal[IEEE80211_MAX_CHAINS];
    s8 chain_signal_avg[IEEE80211_MAX_CHAINS];
    struct rate_info txrate;
    struct rate_info rxrate;
    u32 rx_packets;
    u32 tx_packets;
    u32 tx_retries;
    u32 tx_failed;
    u32 rx_dropped_misc;
    struct sta_bss_parameters bss_param;
    struct nl80211_sta_flag_update sta_flags;
    int generation;
    const u8 * assoc_req_ies;
    size_t assoc_req_ies_len;
    u32 beacon_loss_count;
    s64 t_offset;
    enum nl80211_mesh_power_mode local_pm;
    enum nl80211_mesh_power_mode peer_pm;
    enum nl80211_mesh_power_mode nonpeer_pm;
    u32 expected_throughput;
    u64 rx_beacon;
    u8 rx_beacon_signal_avg;
    struct cfg80211_tid_stats pertid[IEEE80211_NUM_TIDS + 1];
};
```

## Members

|                |  |
|----------------|--|
| filled         | bitflag of flags using the bits of enum nl80211_sta_info to indicate the relevant values in this struct for them |
| connected_time | time(in secs) since a station is last connected  |
| inactive_time  | time since last station activity (tx/rx) in milliseconds   |
| rx_bytes       | bytes (size of MPDUs) received from this station   |

|  |   |
|--|---|
| tx_bytes                               | bytes (size of MPDUs) transmitted to this station   |
| llid                                   | mesh local link id  |
| plid                                   | mesh peer link id   |
| plink_state                            | mesh peer link state  |
| signal                                 | The signal strength, type depends on the wiphy's signal_type. For CFG80211_SIGNAL_TYPE_MBM, value is expressed in _dBm_.  |
| signal_avg                             | Average signal strength, type depends on the wiphy's signal_type. For CFG80211_SIGNAL_TYPE_MBM, value is expressed in _dBm_.  |
| chains                                 | bitmask for filled values in <i>chain_signal</i> , <i>chain_signal_avg</i>  |
| chain_signal[IEEE80211_MAX_CHAINS]     | chain signal strength of last received packet in dBm  |
| chain_signal_avg[IEEE80211_MAX_CHAINS] | signal strength average in dBm  |
| txrate                                 | current unicast bitrate from this station   |
| rxrate                                 | current unicast bitrate to this station   |
| rx_packets                             | packets (MSDUs & MMPDUs) received from this station   |
| tx_packets                             | packets (MSDUs & MMPDUs) transmitted to this station  |
| tx_retries                             | cumulative retry counts (MPDUs)   |
| tx_failed                              | number of failed transmissions (MPDUs) (retries exceeded, no ACK)   |
| rx_dropped_misc                        | Dropped for un-specified reason.  |
| bss_param                              | current BSS parameters  |
| sta_flags                              | station flags mask & values   |
| generation                             | generation number for nl80211 dumps. This number should increase every time the list of stations changes, i.e. when a station is added or removed, so that userspace can tell whether it got a consistent snapshot.                     |
| assoc_req_ies                          | IEs from (Re)Association Request. This is used only when in AP mode with drivers that do not use user space MLME/SME implementation. The information is provided for the <i>cfg80211_new_sta</i> calls to notify user space of the IEs. |
| assoc_req_ies_len                      | Length of <i>assoc_req_ies</i> buffer in octets.  |
| beacon_loss_count                      | Number of times beacon loss event has triggered.  |
| t_offset                               | Time offset of the station relative to this host.   |
| local_pm                               | local mesh STA power save mode  |

|  |   |
|--|---|
| <code>peer_pm</code>                         | peer mesh STA power save mode   |
| <code>nonpeer_pm</code>                      | non-peer mesh STA power save mode   |
| <code>expected_throughput</code>             | expected throughput in kbps (including 802.11 headers) towards this station.  |
| <code>rx_beacon</code>                       | number of beacons received from this peer   |
| <code>rx_beacon_signal_avg</code>            | signal strength average (in dBm) for beacons received from this peer  |
| <code>per tid[IEEE80211_NUM_TIDS + 1]</code> | per-TID statistics, see struct <code>cfg80211_tid_stats</code> , using the last (IEEE80211_NUM_TIDS) index for MSDUs not encapsulated in QoS-MPDUs. |

## Description

Station information filled by driver for `get_station` and `dump_station`.

## Name

enum monitor\_flags — monitor flags

## Synopsis

```
enum monitor_flags {  
    MONITOR_FLAG_FCSFAIL,  
    MONITOR_FLAG_PLCPFAIL,  
    MONITOR_FLAG_CONTROL,  
    MONITOR_FLAG_OTHER_BSS,  
    MONITOR_FLAG_COOK_FRAMES,  
    MONITOR_FLAG_ACTIVE  
};
```

## Constants

|                          |  |
|--------------------------|--|
| MONITOR_FLAG_FCSFAIL     | pass frames with bad FCS                       |
| MONITOR_FLAG_PLCPFAIL    | pass frames with bad PLCP                      |
| MONITOR_FLAG_CONTROL     | pass control frames                            |
| MONITOR_FLAG_OTHER_BSS   | disable BSSID filtering                        |
| MONITOR_FLAG_COOK_FRAMES | report frames after processing                 |
| MONITOR_FLAG_ACTIVE      | active monitor, ACKs frames on its MAC address |

## Description

Monitor interface configuration flags. Note that these must be the bits according to the nl80211 flags.

## Name

enum mpath\_info\_flags — mesh path information flags

## Synopsis

```
enum mpath_info_flags {
    MPATH_INFO_FRAME_QLEN,
    MPATH_INFO_SN,
    MPATH_INFO_METRIC,
    MPATH_INFO_EXPTIME,
    MPATH_INFO_DISCOVERY_TIMEOUT,
    MPATH_INFO_DISCOVERY_RETRIES,
    MPATH_INFO_FLAGS
};
```

## Constants

|                              |                                 |
|------------------------------|---------------------------------|
| MPATH_INFO_FRAME_QLEN        | <i>frame_qlen</i> filled        |
| MPATH_INFO_SN                | <i>sn</i> filled                |
| MPATH_INFO_METRIC            | <i>metric</i> filled            |
| MPATH_INFO_EXPTIME           | <i>exptime</i> filled           |
| MPATH_INFO_DISCOVERY_TIMEOUT | <i>discovery_timeout</i> filled |
| MPATH_INFO_DISCOVERY_RETRIES | <i>discovery_retries</i> filled |
| MPATH_INFO_FLAGS             | <i>flags</i> filled             |

## Description

Used by the driver to indicate which info in struct mpath\_info it has filled in during `get_station` or `dump_station`.

## Name

struct mpath\_info — mesh path information

## Synopsis

```
struct mpath_info {
    u32 filled;
    u32 frame_qlen;
    u32 sn;
    u32 metric;
    u32 exptime;
    u32 discovery_timeout;
    u8 discovery_retries;
    u8 flags;
    int generation;
};
```

## Members

|                   |   |
|-------------------|---|
| filled            | bitfield of flags from enum mpath_info_flags  |
| frame_qlen        | number of queued frames for this destination  |
| sn                | target sequence number  |
| metric            | metric (cost) of this mesh path   |
| exptime           | expiration time for the mesh path from now, in msec   |
| discovery_timeout | total mesh path discovery timeout, in msec  |
| discovery_retries | mesh path discovery retries   |
| flags             | mesh path flags   |
| generation        | generation number for nl80211 dumps. This number should increase every time the list of mesh paths changes, i.e. when a station is added or removed, so that userspace can tell whether it got a consistent snapshot. |

## Description

Mesh path information filled by driver for `get_mpath` and `dump_mpath`.

## Name

struct bss\_parameters — BSS parameters

## Synopsis

```
struct bss_parameters {
    int use_cts_prot;
    int use_short_preamble;
    int use_short_slot_time;
    const u8 * basic_rates;
    u8 basic_rates_len;
    int ap_isolate;
    int ht_opmode;
    s8 p2p_ctwindow;
    s8 p2p_opp_ps;
};
```

## Members

|                     |   |
|---------------------|---|
| use_cts_prot        | Whether to use CTS protection (0 = no, 1 = yes, -1 = do not change)                 |
| use_short_preamble  | Whether the use of short preambles is allowed (0 = no, 1 = yes, -1 = do not change) |
| use_short_slot_time | Whether the use of short slot time is allowed (0 = no, 1 = yes, -1 = do not change) |
| basic_rates         | basic rates in IEEE 802.11 format (or NULL for no change)                           |
| basic_rates_len     | number of basic rates   |
| ap_isolate          | do not forward packets between connected stations                                   |
| ht_opmode           | HT Operation mode (u16 = opmode, -1 = do not change)                                |
| p2p_ctwindow        | P2P CT Window (-1 = no change)  |
| p2p_opp_ps          | P2P opportunistic PS (-1 = no change)   |

## Description

Used to change BSS parameters (mainly for AP mode).



## Name

struct ieee80211\_txq\_params — TX queue parameters

## Synopsis

```
struct ieee80211_txq_params {  
    enum nl80211_ac ac;  
    u16 txop;  
    u16 cwmin;  
    u16 cwmax;  
    u8 aifs;  
};
```

## Members

|       |   |
|-------|---|
| ac    | AC identifier   |
| txop  | Maximum burst time in units of 32 usecs, 0 meaning disabled                   |
| cwmin | Minimum contention window [a value of the form $2^n-1$ in the range 1..32767] |
| cwmax | Maximum contention window [a value of the form $2^n-1$ in the range 1..32767] |
| aifs  | Arbitration interframe space [0..255]   |

## Name

struct cfg80211\_crypto\_settings — Crypto settings

## Synopsis

```
struct cfg80211_crypto_settings {
    u32 wpa_versions;
    u32 cipher_group;
    int n_ciphers_pairwise;
    u32 ciphers_pairwise[NL80211_MAX_NR_CIPHER_SUITES];
    int n_akm_suites;
    u32 akm_suites[NL80211_MAX_NR_AKM_SUITES];
    bool control_port;
    __be16 control_port_ethertype;
    bool control_port_no_encrypt;
};
```

## Members

|  |   |
|--|---|
| wpa_versions                                   | indicates which, if any, WPA versions are enabled (from enum nl80211_wpa_versions)  |
| cipher_group                                   | group key cipher suite (or 0 if unset)  |
| n_ciphers_pairwise                             | number of AP supported unicast ciphers  |
| ciphers_pairwise[NL80211_MAX_NR_CIPHER_SUITES] | unicast key cipher suites   |
| n_akm_suites                                   | number of AKM suites  |
| akm_suites[NL80211_MAX_NR_AKM_SUITES]          | AKM suites  |
| control_port                                   | Whether user space controls IEEE 802.1X port, i.e., sets/clears NL80211_STA_FLAG_AUTHORIZED. If true, the driver is required to assume that the port is unauthorized until authorized by user space. Otherwise, port is marked authorized by default. |
| control_port_ethertype                         | the control port protocol that should be allowed through even on unauthorized ports   |
| control_port_no_encrypt                        | TRUE to prevent encryption of control port protocol frames.   |

## Name

struct cfg80211\_auth\_request — Authentication request data

## Synopsis

```
struct cfg80211_auth_request {
    struct cfg80211_bss * bss;
    const u8 * ie;
    size_t ie_len;
    enum nl80211_auth_type auth_type;
    const u8 * key;
    u8 key_len;
    u8 key_idx;
    const u8 * sae_data;
    size_t sae_data_len;
};
```

## Members

|              |   |
|--------------|---|
| bss          | The BSS to authenticate with, the callee must obtain a reference to it if it needs to keep it.          |
| ie           | Extra IEs to add to Authentication frame or NULL  |
| ie_len       | Length of ie buffer in octets   |
| auth_type    | Authentication type (algorithm)   |
| key          | WEP key for shared key authentication   |
| key_len      | length of WEP key for shared key authentication   |
| key_idx      | index of WEP key for shared key authentication  |
| sae_data     | Non-IE data to use with SAE or NULL. This starts with Authentication transaction sequence number field. |
| sae_data_len | Length of sae_data buffer in octets   |

## Description

This structure provides information needed to complete IEEE 802.11 authentication.

## Name

struct cfg80211\_assoc\_request — (Re)Association request data

## Synopsis

```
struct cfg80211_assoc_request {
    struct cfg80211_bss * bss;
    const u8 * ie;
    const u8 * prev_bssid;
    size_t ie_len;
    struct cfg80211_crypto_settings crypto;
    bool use_mfp;
    u32 flags;
    struct ieee80211_ht_cap ht_capa;
    struct ieee80211_ht_cap ht_capa_mask;
    struct ieee80211_vht_cap vht_capa;
    struct ieee80211_vht_cap vht_capa_mask;
};
```

## Members

|               |   |
|---------------|---|
| bss           | The BSS to associate with. If the call is successful the driver is given a reference that it must give back to <code>cfg80211_send_rx_assoc</code> or to <code>cfg80211_assoc_timeout</code> . To ensure proper refcounting, new association requests while already associating must be rejected. |
| ie            | Extra IEs to add to (Re)Association Request frame or NULL   |
| prev_bssid    | previous BSSID, if not NULL use reassociate frame   |
| ie_len        | Length of ie buffer in octets   |
| crypto        | crypto settings   |
| use_mfp       | Use management frame protection (IEEE 802.11w) in this association  |
| flags         | See enum <code>cfg80211_assoc_req_flags</code>  |
| ht_capa       | HT Capabilities over-rides. Values set in <code>ht_capa_mask</code> will be used in <code>ht_capa</code> . Unsupported values will be ignored.  |
| ht_capa_mask  | The bits of <code>ht_capa</code> which are to be used.  |
| vht_capa      | VHT capability override   |
| vht_capa_mask | VHT capability mask indicating which fields to use  |

## Description

This structure provides information needed to complete IEEE 802.11 (re)association.

## Name

struct cfg80211\_deauth\_request — Deauthentication request data

## Synopsis

```
struct cfg80211_deauth_request {  
    const u8 * bssid;  
    const u8 * ie;  
    size_t ie_len;  
    u16 reason_code;  
    bool local_state_change;  
};
```

## Members

|                    |   |
|--------------------|---|
| bssid              | the BSSID of the BSS to deauthenticate from                   |
| ie                 | Extra IEs to add to Deauthentication frame or NULL            |
| ie_len             | Length of ie buffer in octets                                 |
| reason_code        | The reason code for the deauthentication                      |
| local_state_change | if set, change local state only and do not set a deauth frame |

## Description

This structure provides information needed to complete IEEE 802.11 deauthentication.

## Name

struct cfg80211\_disassoc\_request — Disassociation request data

## Synopsis

```
struct cfg80211_disassoc_request {
    struct cfg80211_bss * bss;
    const u8 * ie;
    size_t ie_len;
    u16 reason_code;
    bool local_state_change;
};
```

## Members

|                    |   |
|--------------------|---|
| bss                | the BSS to disassociate from  |
| ie                 | Extra IEs to add to Disassociation frame or NULL  |
| ie_len             | Length of ie buffer in octets   |
| reason_code        | The reason code for the disassociation  |
| local_state_change | This is a request for a local state only, i.e., no Disassociation frame is to be transmitted. |

## Description

This structure provides information needed to complete IEEE 802.11 disassociation.

## Name

struct cfg80211\_ibss\_params — IBSS parameters

## Synopsis

```
struct cfg80211_ibss_params {
    const u8 * ssid;
    const u8 * bssid;
    struct cfg80211_chan_def chandef;
    const u8 * ie;
    u8 ssid_len;
    u8 ie_len;
    u16 beacon_interval;
    u32 basic_rates;
    bool channel_fixed;
    bool privacy;
    bool control_port;
    bool userspace_handles_dfs;
    int mcast_rate[IEEE80211_NUM_BANDS];
    struct ieee80211_ht_cap ht_capa;
    struct ieee80211_ht_cap ht_capa_mask;
};
```

## Members

|                       |   |
|-----------------------|---|
| ssid                  | The SSID, will always be non-null.  |
| bssid                 | Fixed BSSID requested, maybe be NULL, if set do not search for IBSSs with a different BSSID.  |
| chandef               | defines the channel to use if no other IBSS to join can be found  |
| ie                    | information element(s) to include in the beacon   |
| ssid_len              | The length of the SSID, will always be non-zero.  |
| ie_len                | length of that  |
| beacon_interval       | beacon interval to use  |
| basic_rates           | bitmap of basic rates to use when creating the IBSS   |
| channel_fixed         | The channel should be fixed -- do not search for IBSSs to join on other channels.   |
| privacy               | this is a protected network, keys will be configured after joining  |
| control_port          | whether user space controls IEEE 802.1X port, i.e., sets/clears NL80211_STA_FLAG_AUTHORIZED. If true, the driver is required to assume that the port is unauthorized until authorized by user space. Otherwise, port is marked authorized by default. |
| userspace_handles_dfs | whether user space controls DFS operation, i.e. changes the channel when a radar is detected. This is required to operate on DFS channels.  |

|              |  |
|--------------|--|
| mcast_rate   | IEEE80211_NUM_BANDS 4r-band multicast rate index + 1 (0: disabled)   |
| ht_capa      | HT Capabilities over-rides. Values set in ht_capa_mask will be used in ht_capa. Un-supported values will be ignored. |
| ht_capa_mask | The bits of ht_capa which are to be used.  |

## Description

This structure defines the IBSS parameters for the `join_ibss` method.



## Name

struct cfg80211\_connect\_params — Connection parameters

## Synopsis

```
struct cfg80211_connect_params {
    struct ieee80211_channel * channel;
    struct ieee80211_channel * channel_hint;
    const u8 * bssid;
    const u8 * bssid_hint;
    const u8 * ssid;
    size_t ssid_len;
    enum nl80211_auth_type auth_type;
    const u8 * ie;
    size_t ie_len;
    bool privacy;
    enum nl80211_mfp mfp;
    struct cfg80211_crypto_settings crypto;
    const u8 * key;
    u8 key_len;
    u8 key_idx;
    u32 flags;
    int bg_scan_period;
    struct ieee80211_ht_cap ht_capa;
    struct ieee80211_ht_cap ht_capa_mask;
    struct ieee80211_vht_cap vht_capa;
    struct ieee80211_vht_cap vht_capa_mask;
};
```

## Members

|              |  |
|--------------|--|
| channel      | The channel to use or NULL if not specified (auto-select based on scan results)  |
| channel_hint | The channel of the recommended BSS for initial connection or NULL if not specified   |
| bssid        | The AP BSSID or NULL if not specified (auto-select based on scan results)  |
| bssid_hint   | The recommended AP BSSID for initial connection to the BSS or NULL if not specified. Unlike the <i>bssid</i> parameter, the driver is allowed to ignore this <i>bssid_hint</i> if it has knowledge of a better BSS to use. |
| ssid         | SSID   |
| ssid_len     | Length of ssid in octets   |
| auth_type    | Authentication type (algorithm)  |
| ie           | IEs for association request  |
| ie_len       | Length of assoc_ie in octets   |
| privacy      | indicates whether privacy-enabled APs should be used   |

|                |   |
|----------------|---|
| mfp            | indicate whether management frame protection is used  |
| crypto         | crypto settings   |
| key            | WEP key for shared key authentication   |
| key_len        | length of WEP key for shared key authentication   |
| key_idx        | index of WEP key for shared key authentication  |
| flags          | See enum <code>cfg80211_assoc_req_flags</code>  |
| bg_scan_period | Background scan period in seconds or -1 to indicate that default value is to be used.   |
| ht_capa        | HT Capabilities over-rides. Values set in <code>ht_capa_mask</code> will be used in <code>ht_capa</code> . Un-supported values will be ignored. |
| ht_capa_mask   | The bits of <code>ht_capa</code> which are to be used.  |
| vht_capa       | VHT Capability overrides  |
| vht_capa_mask  | The bits of <code>vht_capa</code> which are to be used.   |

## Description

This structure provides information needed to complete IEEE 802.11 authentication and association.

## Name

struct cfg80211\_pmksa — PMK Security Association

## Synopsis

```
struct cfg80211_pmksa {  
    const u8 * bssid;  
    const u8 * pmkid;  
};
```

## Members

bssid     The AP's BSSID.

pmkid     The PMK material itself.

## Description

This structure is passed to the set/del\_pmksa method for PMKSA caching.

## Name

`cfg80211_rx_mlme_mgmt` — notification of processed MLME management frame

## Synopsis

```
void cfg80211_rx_mlme_mgmt (struct net_device * dev, const u8 * buf,  
size_t len);
```

## Arguments

*dev* network device

*buf* authentication frame (header + body)

*len* length of the frame data

## Description

This function is called whenever an authentication, disassociation or deauthentication frame has been received and processed in station mode.

## After being asked to authenticate via `cfg80211_ops`

`:auth` the driver must call either this function or `cfg80211_auth_timeout`.

## After being asked to associate via `cfg80211_ops`

`:assoc` the driver must call either this function or `cfg80211_auth_timeout`. While connected, the driver must call this for received and processed disassociation and deauthentication frames. If the frame couldn't be used because it was unprotected, the driver must call the function `cfg80211_rx_unprot_mlme_mgmt` instead.

This function may sleep. The caller must hold the corresponding `wdev`'s mutex.

## Name

`cfg80211_auth_timeout` — notification of timed out authentication

## Synopsis

```
void cfg80211_auth_timeout (struct net_device * dev, const u8 * addr);
```

## Arguments

*dev*    network device

*addr*   The MAC address of the device with which the authentication timed out

## Description

This function may sleep. The caller must hold the corresponding wdev's mutex.

## Name

`cfg80211_rx_assoc_resp` — notification of processed association response

## Synopsis

```
void cfg80211_rx_assoc_resp (struct net_device * dev, struct
cfg80211_bss * bss, const u8 * buf, size_t len, int uapsd_queues);
```

## Arguments

|                     |   |
|---------------------|---|
| <i>dev</i>          | network device  |
| <i>bss</i>          | the BSS that association was requested with, ownership of the pointer moves to <code>cfg80211</code> in this call |
| <i>buf</i>          | authentication frame (header + body)  |
| <i>len</i>          | length of the frame data  |
| <i>uapsd_queues</i> | bitmap of ACs configured to uapsd. -1 if n/a.   |

## After being asked to associate via `cfg80211_ops`

:assoc the driver must call either this function or `cfg80211_auth_timeout`.

This function may sleep. The caller must hold the corresponding `wdev`'s mutex.

## Name

`cfg80211_assoc_timeout` — notification of timed out association

## Synopsis

```
void    cfg80211_assoc_timeout    (struct net_device * dev, struct
cfg80211_bss * bss);
```

## Arguments

*dev* network device

*bss* The BSS entry with which association timed out.

## Description

This function may sleep. The caller must hold the corresponding wdev's mutex.

## Name

`cfg80211_tx_mlme_mgmt` — notification of transmitted deauth/disassoc frame

## Synopsis

```
void cfg80211_tx_mlme_mgmt (struct net_device * dev, const u8 * buf,  
size_t len);
```

## Arguments

*dev* network device

*buf* 802.11 frame (header + body)

*len* length of the frame data

## Description

This function is called whenever deauthentication has been processed in station mode. This includes both received deauthentication frames and locally generated ones. This function may sleep. The caller must hold the corresponding `wdev`'s mutex.



## Name

`cfg80211_ibss_joined` — notify `cfg80211` that device joined an IBSS

## Synopsis

```
void cfg80211_ibss_joined (struct net_device * dev, const u8 * bssid,  
struct ieee80211_channel * channel, gfp_t gfp);
```

## Arguments

|                |                                |
|----------------|--------------------------------|
| <i>dev</i>     | network device                 |
| <i>bssid</i>   | the BSSID of the IBSS joined   |
| <i>channel</i> | the channel of the IBSS joined |
| <i>gfp</i>     | allocation flags               |

## Description

This function notifies `cfg80211` that the device joined an IBSS or switched to a different BSSID. Before this function can be called, either a beacon has to have been received from the IBSS, or one of the `cfg80211_inform_bss{,_frame}` functions must have been called with the locally generated beacon -- this guarantees that there is always a scan result for this IBSS. `cfg80211` will handle the rest.

## Name

`cfg80211_connect_result` — notify `cfg80211` of connection result

## Synopsis

```
void cfg80211_connect_result (struct net_device * dev, const u8 * bssid,  
const u8 * req_ie, size_t req_ie_len, const u8 * resp_ie, size_t  
resp_ie_len, u16 status, gfp_t gfp);
```

## Arguments

|                    |  |
|--------------------|--|
| <i>dev</i>         | network device   |
| <i>bssid</i>       | the BSSID of the AP  |
| <i>req_ie</i>      | association request IEs (maybe be NULL)  |
| <i>req_ie_len</i>  | association request IEs length   |
| <i>resp_ie</i>     | association response IEs (may be NULL)   |
| <i>resp_ie_len</i> | assoc response IEs length  |
| <i>status</i>      | status code, 0 for successful connection, use <code>WLAN_STATUS_UNSPECIFIED_FAILURE</code> if your device cannot give you the real status code for failures. |
| <i>gfp</i>         | allocation flags   |

## Description

It should be called by the underlying driver whenever `connect` has succeeded.

## Name

`cfg80211_roamed` — notify `cfg80211` of roaming

## Synopsis

```
void cfg80211_roamed (struct net_device * dev, struct ieee80211_channel  
* channel, const u8 * bssid, const u8 * req_ie, size_t req_ie_len, const  
u8 * resp_ie, size_t resp_ie_len, gfp_t gfp);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>dev</i>         | network device                          |
| <i>channel</i>     | the channel of the new AP               |
| <i>bssid</i>       | the BSSID of the new AP                 |
| <i>req_ie</i>      | association request IEs (maybe be NULL) |
| <i>req_ie_len</i>  | association request IEs length          |
| <i>resp_ie</i>     | association response IEs (may be NULL)  |
| <i>resp_ie_len</i> | assoc response IEs length               |
| <i>gfp</i>         | allocation flags                        |

## Description

It should be called by the underlying driver whenever it roamed from one AP to another while connected.

## Name

`cfg80211_disconnected` — notify `cfg80211` that connection was dropped

## Synopsis

```
void cfg80211_disconnected (struct net_device * dev, u16 reason, const  
u8 * ie, size_t ie_len, gfp_t gfp);
```

## Arguments

*dev*        network device

*reason*    reason code for the disconnection, set it to 0 if unknown

*ie*        information elements of the deauth/disassoc frame (may be NULL)

*ie\_len*    length of IEs

*gfp*       allocation flags

## Description

After it calls this function, the driver should enter an idle state and not try to connect to any AP any more.

## Name

`cfg80211_ready_on_channel` — notification of `remain_on_channel` start

## Synopsis

```
void cfg80211_ready_on_channel (struct wireless_dev * wdev, u64 cookie,  
struct ieee80211_channel * chan, unsigned int duration, gfp_t gfp);
```

## Arguments

|                 |   |
|-----------------|---|
| <i>wdev</i>     | wireless device   |
| <i>cookie</i>   | the request cookie  |
| <i>chan</i>     | The current channel (from <code>remain_on_channel</code> request)         |
| <i>duration</i> | Duration in milliseconds that the driver intends to remain on the channel |
| <i>gfp</i>      | allocation flags  |

## Name

cfg80211\_remain\_on\_channel\_expired — remain\_on\_channel duration expired

## Synopsis

```
void cfg80211_remain_on_channel_expired (struct wireless_dev * wdev,  
u64 cookie, struct ieee80211_channel * chan, gfp_t gfp);
```

## Arguments

*wdev*      wireless device

*cookie*    the request cookie

*chan*      The current channel (from remain\_on\_channel request)

*gfp*       allocation flags

## Name

`cfg80211_new_sta` — notify userspace about station

## Synopsis

```
void cfg80211_new_sta (struct net_device * dev, const u8 * mac_addr,  
struct station_info * sinfo, gfp_t gfp);
```

## Arguments

|                 |                         |
|-----------------|-------------------------|
| <i>dev</i>      | the netdev              |
| <i>mac_addr</i> | the station's address   |
| <i>sinfo</i>    | the station information |
| <i>gfp</i>      | allocation flags        |

## Name

`cfg80211_rx_mgmt` — notification of received, unprocessed management frame

## Synopsis

```
bool cfg80211_rx_mgmt (struct wireless_dev * wdev, int freq, int sig_dbm,  
const u8 * buf, size_t len, u32 flags);
```

## Arguments

|                |   |
|----------------|---|
| <i>wdev</i>    | wireless device receiving the frame                         |
| <i>freq</i>    | Frequency on which the frame was received in MHz            |
| <i>sig_dbm</i> | signal strength in mBm, or 0 if unknown                     |
| <i>buf</i>     | Management frame (header + body)                            |
| <i>len</i>     | length of the frame data                                    |
| <i>flags</i>   | flags, as defined in enum <code>nl80211_rxmgmt_flags</code> |

## Description

This function is called whenever an Action frame is received for a station mode interface, but is not processed in kernel.

## Return

`true` if a user space application has registered for this frame. For action frames, that makes it responsible for rejecting unrecognized action frames; `false` otherwise, in which case for action frames the driver is responsible for rejecting the frame.



## Name

`cfg80211_mgmt_tx_status` — notification of TX status for management frame

## Synopsis

```
void cfg80211_mgmt_tx_status (struct wireless_dev * wdev, u64 cookie,  
const u8 * buf, size_t len, bool ack, gfp_t gfp);
```

## Arguments

|               |   |
|---------------|---|
| <i>wdev</i>   | wireless device receiving the frame                   |
| <i>cookie</i> | Cookie returned by <code>cfg80211_ops::mgmt_tx</code> |
| <i>buf</i>    | Management frame (header + body)                      |
| <i>len</i>    | length of the frame data                              |
| <i>ack</i>    | Whether frame was acknowledged                        |
| <i>gfp</i>    | context flags   |

## Description

This function is called whenever a management frame was requested to be

## transmitted with `cfg80211_ops`

`:mgmt_tx` to report the TX status of the transmission attempt.

## Name

`cfg80211_cqm_rssi_notify` — connection quality monitoring rssi event

## Synopsis

```
void    cfg80211_cqm_rssi_notify (struct net_device * dev, enum
nl80211_cqm_rssi_threshold_event rssi_event, gfp_t gfp);
```

## Arguments

|                   |                          |
|-------------------|--------------------------|
| <i>dev</i>        | network device           |
| <i>rssi_event</i> | the triggered RSSI event |
| <i>gfp</i>        | context flags            |

## Description

This function is called when a configured connection quality monitoring rssi threshold reached event occurs.

## Name

`cfg80211_cqm_pktloss_notify` — notify userspace about packetloss to peer

## Synopsis

```
void cfg80211_cqm_pktloss_notify (struct net_device * dev, const u8 *  
peer, u32 num_packets, gfp_t gfp);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>dev</i>         | network device  |
| <i>peer</i>        | peer's MAC address  |
| <i>num_packets</i> | how many packets were lost -- should be a fixed threshold but probably no less than maybe 50, or maybe a throughput dependent threshold (to account for temporary interference) |
| <i>gfp</i>         | context flags   |

## Name

`cfg80211_michael_mic_failure` — notification of Michael MIC failure (TKIP)

## Synopsis

```
void cfg80211_michael_mic_failure (struct net_device * dev, const u8  
* addr, enum nl80211_key_type key_type, int key_id, const u8 * tsc,  
gfp_t gfp);
```

## Arguments

|                 |  |
|-----------------|--|
| <i>dev</i>      | network device   |
| <i>addr</i>     | The source MAC address of the frame                                  |
| <i>key_type</i> | The key type that the received frame used                            |
| <i>key_id</i>   | Key identifier (0..3). Can be -1 if missing.                         |
| <i>tsc</i>      | The TSC value of the frame that generated the MIC failure (6 octets) |
| <i>gfp</i>      | allocation flags   |

## Description

This function is called whenever the local MAC detects a MIC failure in a received frame. This matches with `MLME-MICHAELMICFAILURE.indication` primitive.

---

## Chapter 3. Scanning and BSS list handling

The scanning process itself is fairly simple, but `cfg80211` offers quite a bit of helper functionality. To start a scan, the scan operation will be invoked with a scan definition. This scan definition contains the channels to scan, and the SSIDs to send probe requests for (including the wildcard, if desired). A passive scan is indicated by having no SSIDs to probe. Additionally, a scan request may contain extra information elements that should be added to the probe request. The IEs are guaranteed to be well-formed, and will not exceed the maximum length the driver advertised in the `wiphy` structure.

When scanning finds a BSS, `cfg80211` needs to be notified of that, because it is responsible for maintaining the BSS list; the driver should not maintain a list itself. For this notification, various functions exist.

Since drivers do not maintain a BSS list, there are also a number of functions to search for a BSS and obtain information about it from the BSS structure `cfg80211` maintains. The BSS list is also made available to userspace.

## Name

struct cfg80211\_ssid — SSID description

## Synopsis

```
struct cfg80211_ssid {  
    u8 ssid[IEEE80211_MAX_SSID_LEN];  
    u8 ssid_len;  
};
```

## Members

ssid[IEEE80211\_MAX\_SSID\_LEN] the SSID

ssid\_len                                      length of the ssid

## Name

struct cfg80211\_scan\_request — scan request description

## Synopsis

```
struct cfg80211_scan_request {
    struct cfg80211_ssid * ssids;
    int n_ssids;
    u32 n_channels;
    enum nl80211_bss_scan_width scan_width;
    const u8 * ie;
    size_t ie_len;
    u32 flags;
    u32 rates[IEEE80211_NUM_BANDS];
    struct wireless_dev * wdev;
    u8 mac_addr[ETH_ALEN];
    u8 mac_addr_mask[ETH_ALEN];
    struct wiphy * wiphy;
    unsigned long scan_start;
    bool aborted;
    bool notified;
    bool no_cck;
    struct ieee80211_channel * channels[0];
};
```

## Members

|                            |  |
|----------------------------|--|
| ssids                      | SSIDs to scan for (active scan only)   |
| n_ssids                    | number of SSIDs  |
| n_channels                 | total number of channels to scan   |
| scan_width                 | channel width for scanning   |
| ie                         | optional information element(s) to add into Probe Request or NULL  |
| ie_len                     | length of ie in octets   |
| flags                      | bit field of flags controlling operation   |
| rates[IEEE80211_NUM_BANDS] | bitmap of rates to advertise for each band   |
| wdev                       | the wireless device to scan for  |
| mac_addr[ETH_ALEN]         | MAC address used with randomisation  |
| mac_addr_mask[ETH_ALEN]    | MAC address mask used with randomisation, bits that are 0 in the mask should be randomised, bits that are 1 should be taken from the <i>mac_addr</i> |
| wiphy                      | the wiphy this was for   |
| scan_start                 | time (in jiffies) when the scan started  |

|             |  |
|-------------|--|
| aborted     | (internal) scan request was notified as aborted          |
| notified    | (internal) scan request was notified as done or aborted  |
| no_cck      | used to send probe requests at non CCK rate in 2GHz band |
| channels[0] | channels to scan on.                                     |



## Name

`cfg80211_scan_done` — notify that scan finished

## Synopsis

```
void cfg80211_scan_done (struct cfg80211_scan_request * request, bool  
aborted);
```

## Arguments

*request* the corresponding scan request

*aborted* set to true if the scan was aborted for any reason, userspace will be notified of that

## Name

struct cfg80211\_bss — BSS description

## Synopsis

```
struct cfg80211_bss {
    struct ieee80211_channel * channel;
    enum nl80211_bss_scan_width scan_width;
    const struct cfg80211_bss_ies __rcu * ies;
    const struct cfg80211_bss_ies __rcu * beacon_ies;
    const struct cfg80211_bss_ies __rcu * probesp_ies;
    struct cfg80211_bss * hidden_beacon_bss;
    s32 signal;
    u16 beacon_interval;
    u16 capability;
    u8 bssid[ETH_ALEN];
    u8 priv[0];
};
```

## Members

|                   |   |
|-------------------|---|
| channel           | channel this BSS is on  |
| scan_width        | width of the control channel  |
| ies               | the information elements (Note that there is no guarantee that these are well-formed!); this is a pointer to either the beacon_ies or probesp_ies depending on whether Probe Response frame has been received. It is always non-NULL.   |
| beacon_ies        | the information elements from the last Beacon frame (implementation note: if <i>hidden_beacon_bss</i> is set this struct doesn't own the beacon_ies, but they're just pointers to the ones from the <i>hidden_beacon_bss</i> struct)  |
| probsp_ies        | the information elements from the last Probe Response frame   |
| hidden_beacon_bss | in case this BSS struct represents a probe response from a BSS that hides the SSID in its beacon, this points to the BSS struct that holds the beacon data. <i>beacon_ies</i> is still valid, of course, and points to the same data as <i>hidden_beacon_bss</i> -> <i>beacon_ies</i> in that case. |
| signal            | signal strength value (type depends on the wiphy's signal_type)   |
| beacon_interval   | the beacon interval as from the frame   |
| capability        | the capability field in host byte order   |
| bssid[ETH_ALEN]   | BSSID of the BSS  |
| priv[0]           | private area for driver use, has at least wiphy->bss_priv_size bytes  |

## Description

This structure describes a BSS (which may also be a mesh network) for use in scan results and similar.

## Name

`cfg80211_inform_bss_width_frame` — inform `cfg80211` of a received BSS frame

## Synopsis

```
struct    cfg80211_bss    *    cfg80211_inform_bss_width_frame (struct
wiphy    *    wiphy,    struct    ieee80211_channel    *    rx_channel,    enum
nl80211_bss_scan_width scan_width, struct ieee80211_mgmt * mgmt, size_t
len, s32 signal, gfp_t gfp);
```

## Arguments

|                   |   |
|-------------------|---|
| <i>wiphy</i>      | the wiphy reporting the BSS   |
| <i>rx_channel</i> | The channel the frame was received on                                     |
| <i>scan_width</i> | width of the control channel  |
| <i>mgmt</i>       | the management frame (probe response or beacon)                           |
| <i>len</i>        | length of the management frame  |
| <i>signal</i>     | the signal strength, type depends on the wiphy's <code>signal_type</code> |
| <i>gfp</i>        | context flags   |

## Description

This informs `cfg80211` that BSS information was found and the BSS should be updated/added.

## Return

A referenced struct, must be released with `cfg80211_put_bss`! Or NULL on error.

## Name

`cfg80211_inform_bss_width` — inform `cfg80211` of a new BSS

## Synopsis

```
struct cfg80211_bss * cfg80211_inform_bss_width (struct wiphy * wiphy,  
struct ieee80211_channel * rx_channel, enum nl80211_bss_scan_width  
scan_width, enum cfg80211_bss_frame_type ftype, const u8 * bssid, u64  
tsf, u16 capability, u16 beacon_interval, const u8 * ie, size_t ielen,  
s32 signal, gfp_t gfp);
```

## Arguments

|                        |   |
|------------------------|---|
| <i>wiphy</i>           | the wiphy reporting the BSS   |
| <i>rx_channel</i>      | The channel the frame was received on                                     |
| <i>scan_width</i>      | width of the control channel  |
| <i>ftype</i>           | frame type (if known)   |
| <i>bssid</i>           | the BSSID of the BSS  |
| <i>tsf</i>             | the TSF sent by the peer in the beacon/probe response (or 0)              |
| <i>capability</i>      | the capability field sent by the peer                                     |
| <i>beacon_interval</i> | the beacon interval announced by the peer                                 |
| <i>ie</i>              | additional IEs sent by the peer   |
| <i>ielen</i>           | length of the additional IEs  |
| <i>signal</i>          | the signal strength, type depends on the wiphy's <code>signal_type</code> |
| <i>gfp</i>             | context flags   |

## Description

This informs `cfg80211` that BSS information was found and the BSS should be updated/added.

## Return

A referenced struct, must be released with `cfg80211_put_bss`! Or NULL on error.

## Name

`cfg80211_unlink_bss` — unlink BSS from internal data structures

## Synopsis

```
void cfg80211_unlink_bss (struct wiphy * wiphy, struct cfg80211_bss *  
bss);
```

## Arguments

*wiphy*    the wiphy

*bss*       the bss to remove

## Description

This function removes the given BSS from the internal data structures thereby making it no longer show up in scan results etc. Use this function when you detect a BSS is gone. Normally BSSes will also time out, so it is not necessary to use this function at all.

## Name

`cfg80211_find_ie` — find information element in data

## Synopsis

```
const u8 * cfg80211_find_ie (u8 eid, const u8 * ies, int len);
```

## Arguments

*eid* element ID

*ies* data consisting of IEs

*len* length of data

## Return

NULL if the element ID could not be found or if the element is invalid (claims to be longer than the given data), or a pointer to the first byte of the requested element, that is the byte containing the element ID.

## Note

There are no checks on the element length other than having to fit into the given data.

## Name

ieee80211\_bss\_get\_ie — find IE with given ID

## Synopsis

```
const u8 * ieee80211_bss_get_ie (struct cfg80211_bss * bss, u8 ie);
```

## Arguments

*bss*    the bss to search

*ie*     the IE ID

## Description

Note that the return value is an RCU-protected pointer, so `rcu_read_lock` must be held when calling this function.

## Return

NULL if not found.



---

# Chapter 4. Utility functions

`cfg80211` offers a number of utility functions that can be useful.

## Name

ieee80211\_channel\_to\_frequency — convert channel number to frequency

## Synopsis

```
int ieee80211_channel_to_frequency (int chan, enum ieee80211_band band);
```

## Arguments

*chan* channel number

*band* band, necessary due to channel number overlap

## Return

The corresponding frequency (in MHz), or 0 if the conversion failed.

## Name

ieee80211\_frequency\_to\_channel — convert frequency to channel number

## Synopsis

```
int ieee80211_frequency_to_channel (int freq);
```

## Arguments

*freq* center frequency

## Return

The corresponding channel, or 0 if the conversion failed.

## Name

`ieee80211_get_channel` — get channel struct from wiphy for specified frequency

## Synopsis

```
struct ieee80211_channel * ieee80211_get_channel (struct wiphy * wiphy,  
int freq);
```

## Arguments

*wiphy* the struct wiphy to get the channel for

*freq* the center frequency of the channel

## Return

The channel struct from *wiphy* at *freq*.

## Name

ieee80211\_get\_response\_rate — get basic rate for a given rate

## Synopsis

```
struct ieee80211_rate * ieee80211_get_response_rate (struct
ieee80211_supported_band * sband, u32 basic_rates, int bitrate);
```

## Arguments

|                    |  |
|--------------------|--|
| <i>sband</i>       | the band to look for rates in                |
| <i>basic_rates</i> | bitmap of basic rates                        |
| <i>bitrate</i>     | the bitrate for which to find the basic rate |

## Return

The basic rate corresponding to a given bitrate, that is the next lower bitrate contained in the basic rate map, which is, for this function, given as a bitmap of indices of rates in the band's bitrate table.

## Name

`ieee80211_hdrlen` — get header length in bytes from frame control

## Synopsis

```
unsigned int __attribute__((const)) ieee80211_hdrlen (__le16 fc);
```

## Arguments

*fc* frame control field in little-endian format

## Return

The header length in bytes.

## Name

ieee80211\_get\_hdrlen\_from\_skb — get header length from data

## Synopsis

```
unsigned int ieee80211_get_hdrlen_from_skb (const struct sk_buff * skb);
```

## Arguments

*skb* the frame

## Description

Given an skb with a raw 802.11 header at the data pointer this function returns the 802.11 header length.

## Return

The 802.11 header length in bytes (not including encryption headers). Or 0 if the data in the sk\_buff is too short to contain a valid 802.11 header.

## Name

struct ieee80211\_radiotap\_iterator — tracks walk thru present radiotap args

## Synopsis

```
struct ieee80211_radiotap_iterator {
    struct ieee80211_radiotap_header * _rheader;
    const struct ieee80211_radiotap_vendor_namespaces * _vns;
    const struct ieee80211_radiotap_namespace * current_namespace;
    unsigned char * _arg;
    unsigned char * _next_ns_data;
    __le32 * _next_bitmap;
    unsigned char * this_arg;
    int this_arg_index;
    int this_arg_size;
    int is_radiotap_ns;
    int _max_length;
    int _arg_index;
    uint32_t _bitmap_shifter;
    int _reset_on_ext;
};
```

## Members

|                                |  |
|--------------------------------|--|
| <code>_rheader</code>          | pointer to the radiotap header we are walking through  |
| <code>_vns</code>              | vendor namespace definitions   |
| <code>current_namespace</code> | pointer to the current namespace definition (or internally NULL if the current namespace is unknown)   |
| <code>_arg</code>              | next argument pointer  |
| <code>_next_ns_data</code>     | beginning of the next namespace's data   |
| <code>_next_bitmap</code>      | internal pointer to next present u32   |
| <code>this_arg</code>          | pointer to current radiotap arg; it is valid after each call to <code>ieee80211_radiotap_iterator_next</code> but also after <code>ieee80211_radiotap_iterator_init</code> where it will point to the beginning of the actual data portion |
| <code>this_arg_index</code>    | index of current arg, valid after each successful call to <code>ieee80211_radiotap_iterator_next</code>  |
| <code>this_arg_size</code>     | length of the current arg, for convenience   |
| <code>is_radiotap_ns</code>    | indicates whether the current namespace is the default radiotap namespace or not   |
| <code>_max_length</code>       | length of radiotap header in cpu byte ordering   |
| <code>_arg_index</code>        | next argument index  |



|                              |   |
|------------------------------|---|
| <code>_bitmap_shifter</code> | internal shifter for curr u32 bitmap, b0 set == arg present           |
| <code>_reset_on_ext</code>   | internal; reset the arg index to 0 when going to the next bitmap word |

## Description

Describes the radiotap parser state. Fields prefixed with an underscore must not be used by users of the parser, only by the parser internally.

---

# Chapter 5. Data path helpers

In addition to generic utilities, `cfg80211` also offers functions that help implement the data path for devices that do not do the 802.11/802.3 conversion on the device.

## Name

ieee80211\_data\_to\_8023 — convert an 802.11 data frame to 802.3

## Synopsis

```
int ieee80211_data_to_8023 (struct sk_buff * skb, const u8 * addr, enum  
nl80211_iftype iftype);
```

## Arguments

*skb*        the 802.11 data frame  
*addr*       the device MAC address  
*iftype*    the virtual interface type

## Return

0 on success. Non-zero on error.

## Name

ieee80211\_data\_from\_8023 — convert an 802.3 frame to 802.11

## Synopsis

```
int ieee80211_data_from_8023 (struct sk_buff * skb, const u8 * addr,  
enum nl80211_iftype iftype, const u8 * bssid, bool qos);
```

## Arguments

|               |  |
|---------------|--|
| <i>skb</i>    | the 802.3 frame  |
| <i>addr</i>   | the device MAC address                                     |
| <i>iftype</i> | the virtual interface type                                 |
| <i>bssid</i>  | the network bssid (used only for iftype STATION and ADHOC) |
| <i>qos</i>    | build 802.11 QoS data frame                                |

## Return

0 on success, or a negative error code.

## Name

ieee80211\_amsdu\_to\_8023s — decode an IEEE 802.11n A-MSDU frame

## Synopsis

```
void ieee80211_amsdu_to_8023s (struct sk_buff * skb, struct sk_buff_head  
* list, const u8 * addr, enum nl80211_iftype iftype, const unsigned int  
extra_headroom, bool has_80211_header);
```

## Arguments

|                         |   |
|-------------------------|---|
| <i>skb</i>              | The input IEEE 802.11n A-MSDU frame.  |
| <i>list</i>             | The output list of 802.3 frames. It must be allocated and initialized by by the caller. |
| <i>addr</i>             | The device MAC address.   |
| <i>iftype</i>           | The device interface type.  |
| <i>extra_headroom</i>   | The hardware extra headroom for SKBs in the <i>list</i> .                               |
| <i>has_80211_header</i> | Set it true if SKB is with IEEE 802.11 header.  |

## Description

Decode an IEEE 802.11n A-MSDU frame and convert it to a list of 802.3 frames. The *list* will be empty if the decode fails. The *skb* is consumed after the function returns.

## Name

`cfg80211_classify8021d` — determine the 802.1p/1d tag for a data frame

## Synopsis

```
unsigned int cfg80211_classify8021d (struct sk_buff * skb, struct
cfg80211_qos_map * qos_map);
```

## Arguments

*skb*            the data frame

*qos\_map*       Interworking QoS mapping or NULL if not in use

## Return

The 802.1p/1d tag.

---

## Chapter 6. Regulatory enforcement infrastructure

TODO

## Name

`regulatory_hint` — driver hint to the wireless core a regulatory domain

## Synopsis

```
int regulatory_hint (struct wiphy * wiphy, const char * alpha2);
```

## Arguments

*wiphy*     the wireless device giving the hint (used only for reporting conflicts)

*alpha2*   the ISO/IEC 3166 alpha2 the driver claims its regulatory domain should be in. If *rd* is set this should be NULL. Note that if you set this to NULL you should still set *rd->alpha2* to some accepted alpha2.

## Description

Wireless drivers can use this function to hint to the wireless core what it believes should be the current regulatory domain by giving it an ISO/IEC 3166 alpha2 country code it knows its regulatory domain should be in or by providing a completely build regulatory domain. If the driver provides an ISO/IEC 3166 alpha2 userspace will be queried for a regulatory domain structure for the respective country.

The *wiphy* must have been registered to `cfg80211` prior to this call. For `cfg80211` drivers this means you must first use `wiphy_register`, for `mac80211` drivers you must first use `ieee80211_register_hw`.

Drivers should check the return value, its possible you can get an `-ENOMEM`.

## Return

0 on success. `-ENOMEM`.



## Name

wiphy\_apply\_custom\_regulatory — apply a custom driver regulatory domain

## Synopsis

```
void wiphy_apply_custom_regulatory (struct wiphy * wiphy, const struct  
ieee80211_regdomain * regd);
```

## Arguments

*wiphy* the wireless device we want to process the regulatory domain on

*regd* the custom regulatory domain to use for this wiphy

## Description

Drivers can sometimes have custom regulatory domains which do not apply to a specific country. Drivers can use this to apply such custom regulatory domains. This routine must be called prior to wiphy registration. The custom regulatory domain will be trusted completely and as such previous default channel settings will be disregarded. If no rule is found for a channel on the regulatory domain the channel will be disabled. Drivers using this for a wiphy should also set the wiphy flag `REGULATORY_CUSTOM_REG` or `cfg80211` will set it for the wiphy that called this helper.

## Name

`freq_reg_info` — get regulatory information for the given frequency

## Synopsis

```
const struct ieee80211_reg_rule * freq_reg_info (struct wiphy * wiphy,  
u32 center_freq);
```

## Arguments

*wiphy*                    the wiphy for which we want to process this rule for

*center\_freq*    Frequency in KHz for which we want regulatory information for

## Description

Use this function to get the regulatory rule for a specific frequency on a given wireless device. If the device has a specific regulatory domain it wants to follow we respect that unless a country IE has been received and processed already.

## Return

A valid pointer, or, when an error occurs, for example if no rule can be found, the return value is encoded using `ERR_PTR`. Use `IS_ERR` to check and `PTR_ERR` to obtain the numeric return value. The numeric return value will be `-ERANGE` if we determine the given `center_freq` does not even have a regulatory rule for a frequency range in the `center_freq`'s band. See `freq_in_rule_band` for our current definition of a band -- this is purely subjective and right now it's 802.11 specific.

---

# Chapter 7. RFkill integration

RFkill integration in `cfg80211` is almost invisible to drivers, as `cfg80211` automatically registers an `rfkill` instance for each wireless device it knows about. Soft kill is also translated into disconnecting and turning all interfaces off, drivers are expected to turn off the device when all interfaces are down.

However, devices may have a hard RFkill line, in which case they also need to interact with the `rfkill` subsystem, via `cfg80211`. They can do this with a few helper functions documented [here](#).

## Name

wiphy\_rfkill\_set\_hw\_state — notify cfg80211 about hw block state

## Synopsis

```
void wiphy_rfkill_set_hw_state (struct wiphy * wiphy, bool blocked);
```

## Arguments

*wiphy*      the wiphy

*blocked*    block status

## Name

wiphy\_rfkill\_start\_polling — start polling rfkill

## Synopsis

```
void wiphy_rfkill_start_polling (struct wiphy * wiphy);
```

## Arguments

*wiphy* the wiphy

## Name

wiphy\_rfkill\_stop\_polling — stop polling rfkill

## Synopsis

```
void wiphy_rfkill_stop_polling (struct wiphy * wiphy);
```

## Arguments

*wiphy* the wiphy

---

# Chapter 8. Test mode

Test mode is a set of utility functions to allow drivers to interact with driver-specific tools to aid, for instance, factory programming.

This chapter describes how drivers interact with it, for more information see the nl80211 book's chapter on it.

## Name

`cfg80211_testmode_alloc_reply_skb` — allocate testmode reply

## Synopsis

```
struct sk_buff * cfg80211_testmode_alloc_reply_skb (struct wiphy *  
wiphy, int approxlen);
```

## Arguments

*wiphy*            the wiphy

*approxlen*    an upper bound of the length of the data that will be put into the skb

## Description

This function allocates and pre-fills an skb for a reply to the testmode command. Since it is intended for a reply, calling it outside of the *testmode\_cmd* operation is invalid.

The returned skb is pre-filled with the wiphy index and set up in a way that any data that is put into the skb (with `skb_put`, `nla_put` or similar) will end up being within the `NL80211_ATTR_TESTDATA` attribute, so all that needs to be done with the skb is adding data for the corresponding userspace tool which can then read that data out of the testdata attribute. You must not modify the skb in any other way.

When done, call `cfg80211_testmode_reply` with the skb and return its error code as the result of the *testmode\_cmd* operation.

## Return

An allocated and pre-filled skb. NULL if any errors happen.



## Name

`cfg80211_testmode_reply` — send the reply skb

## Synopsis

```
int cfg80211_testmode_reply (struct sk_buff * skb);
```

## Arguments

*skb* The skb, must have been allocated with `cfg80211_testmode_alloc_reply_skb`

## Description

Since calling this function will usually be the last thing before returning from the `testmode_cmd` you should return the error code. Note that this function consumes the skb regardless of the return value.

## Return

An error code or 0 on success.

## Name

`cfg80211_testmode_alloc_event_skb` — allocate testmode event

## Synopsis

```
struct sk_buff * cfg80211_testmode_alloc_event_skb (struct wiphy *  
wiphy, int approxlen, gfp_t gfp);
```

## Arguments

*wiphy*            the wiphy

*approxlen*    an upper bound of the length of the data that will be put into the skb

*gfp*            allocation flags

## Description

This function allocates and pre-fills an skb for an event on the testmode multicast group.

The returned skb is set up in the same way as with `cfg80211_testmode_alloc_reply_skb` but prepared for an event. As there, you should simply add data to it that will then end up in the `NL80211_ATTR_TESTDATA` attribute. Again, you must not modify the skb in any other way.

When done filling the skb, call `cfg80211_testmode_event` with the skb to send the event.

## Return

An allocated and pre-filled skb. NULL if any errors happen.

## Name

`cfg80211_testmode_event` — send the event

## Synopsis

```
void cfg80211_testmode_event (struct sk_buff * skb, gfp_t gfp);
```

## Arguments

*skb* The skb, must have been allocated with `cfg80211_testmode_alloc_event_skb`

*gfp* allocation flags

## Description

This function sends the given *skb*, which must have been allocated by `cfg80211_testmode_alloc_event_skb`, as an event. It always consumes it.

# **The mac80211 subsystem**

---

# The mac80211 subsystem

## Abstract

mac80211 is the Linux stack for 802.11 hardware that implements only partial functionality in hard- or firmware. This document defines the interface between mac80211 and low-level hardware drivers.

If you're reading this document and not the header file itself, it will be incomplete because not all documentation has been converted yet.

---

---

# Table of Contents

|  |     |
|--|-----|
| I. The basic mac80211 driver interface .....     | 1   |
| 1. Basic hardware handling .....                 | 3   |
| struct ieee80211_hw .....                        | 4   |
| enum ieee80211_hw_flags .....                    | 7   |
| SET_IEEE80211_DEV .....                          | 10  |
| SET_IEEE80211_PERM_ADDR .....                    | 11  |
| struct ieee80211_ops .....                       | 12  |
| ieee80211_alloc_hw .....                         | 23  |
| ieee80211_register_hw .....                      | 24  |
| ieee80211_unregister_hw .....                    | 25  |
| ieee80211_free_hw .....                          | 26  |
| 2. PHY configuration .....                       | 27  |
| struct ieee80211_conf .....                      | 28  |
| enum ieee80211_conf_flags .....                  | 30  |
| 3. Virtual interfaces .....                      | 31  |
| struct ieee80211_vif .....                       | 32  |
| 4. Receive and transmit processing .....         | 34  |
| what should be here .....                        | 34  |
| Frame format .....                               | 34  |
| Packet alignment .....                           | 34  |
| Calling into mac80211 from interrupts .....      | 34  |
| functions/definitions .....                      | 35  |
| 5. Frame filtering .....                         | 65  |
| enum ieee80211_filter_flags .....                | 66  |
| 6. The mac80211 workqueue .....                  | 67  |
| ieee80211_queue_work .....                       | 68  |
| ieee80211_queue_delayed_work .....               | 69  |
| II. Advanced driver interface .....              | 70  |
| 7. LED support .....                             | 72  |
| ieee80211_get_tx_led_name .....                  | 73  |
| ieee80211_get_rx_led_name .....                  | 74  |
| ieee80211_get_assoc_led_name .....               | 75  |
| ieee80211_get_radio_led_name .....               | 76  |
| struct ieee80211_tpt_blink .....                 | 77  |
| enum ieee80211_tpt_led_trigger_flags .....       | 78  |
| ieee80211_create_tpt_led_trigger .....           | 79  |
| 8. Hardware crypto acceleration .....            | 80  |
| enum set_key_cmd .....                           | 81  |
| struct ieee80211_key_conf .....                  | 82  |
| enum ieee80211_key_flags .....                   | 83  |
| ieee80211_get_tkip_p1k .....                     | 85  |
| ieee80211_get_tkip_p1k_iv .....                  | 86  |
| ieee80211_get_tkip_p2k .....                     | 87  |
| 9. Powersave support .....                       | 88  |
| 10. Beacon filter support .....                  | 89  |
| ieee80211_beacon_loss .....                      | 90  |
| 11. Multiple queues and QoS support .....        | 91  |
| struct ieee80211_tx_queue_params .....           | 92  |
| 12. Access point mode support .....              | 93  |
| support for powersaving clients .....            | 93  |
| 13. Supporting multiple virtual interfaces ..... | 103 |

|  |     |
|--|-----|
| ieee80211_iterate_active_interfaces .....        | 104 |
| ieee80211_iterate_active_interfaces_atomic ..... | 105 |
| 14. Station handling .....                       | 106 |
| struct ieee80211_sta .....                       | 107 |
| enum sta_notify_cmd .....                        | 109 |
| ieee80211_find_sta .....                         | 110 |
| ieee80211_find_sta_by_ifaddr .....               | 111 |
| 15. Hardware scan offload .....                  | 112 |
| ieee80211_scan_completed .....                   | 113 |
| 16. Aggregation .....                            | 114 |
| TX A-MPDU aggregation .....                      | 114 |
| RX A-MPDU aggregation .....                      | 114 |
| 17. Spatial Multiplexing Powersave (SMPS) .....  | 116 |
| ieee80211_request_smpps .....                    | 117 |
| enum ieee80211_smpps_mode .....                  | 118 |
| III. Rate control interface .....                | 119 |
| 18. Rate Control API .....                       | 121 |
| ieee80211_start_tx_ba_session .....              | 122 |
| ieee80211_start_tx_ba_cb_irqsafe .....           | 123 |
| ieee80211_stop_tx_ba_session .....               | 124 |
| ieee80211_stop_tx_ba_cb_irqsafe .....            | 125 |
| enum ieee80211_rate_control_changed .....        | 126 |
| struct ieee80211_tx_rate_control .....           | 127 |
| rate_control_send_low .....                      | 128 |
| IV. Internals .....                              | 129 |
| 19. Key handling .....                           | 131 |
| Key handling basics .....                        | 131 |
| MORE TBD .....                                   | 131 |
| 20. Receive processing .....                     | 132 |
| 21. Transmit processing .....                    | 133 |
| 22. Station info handling .....                  | 134 |
| Programming information .....                    | 134 |
| STA information lifetime rules .....             | 141 |
| 23. Aggregation .....                            | 143 |
| struct sta_ampdu_mlme .....                      | 144 |
| struct tid_ampdu_tx .....                        | 145 |
| struct tid_ampdu_rx .....                        | 147 |
| 24. Synchronisation .....                        | 149 |

---

# **Part I. The basic mac80211 driver interface**

You should read and understand the information contained within this part of the book while implementing a driver. In some chapters, advanced usage is noted, that may be skipped at first.

This part of the book only covers station and monitor mode functionality, additional information required to implement the other modes is covered in the second part of the book.

---



---

# Table of Contents

|   |    |
|---|----|
| 1. Basic hardware handling .....            | 3  |
| struct ieee80211_hw .....                   | 4  |
| enum ieee80211_hw_flags .....               | 7  |
| SET_IEEE80211_DEV .....                     | 10 |
| SET_IEEE80211_PERM_ADDR .....               | 11 |
| struct ieee80211_ops .....                  | 12 |
| ieee80211_alloc_hw .....                    | 23 |
| ieee80211_register_hw .....                 | 24 |
| ieee80211_unregister_hw .....               | 25 |
| ieee80211_free_hw .....                     | 26 |
| 2. PHY configuration .....                  | 27 |
| struct ieee80211_conf .....                 | 28 |
| enum ieee80211_conf_flags .....             | 30 |
| 3. Virtual interfaces .....                 | 31 |
| struct ieee80211_vif .....                  | 32 |
| 4. Receive and transmit processing .....    | 34 |
| what should be here .....                   | 34 |
| Frame format .....                          | 34 |
| Packet alignment .....                      | 34 |
| Calling into mac80211 from interrupts ..... | 34 |
| functions/definitions .....                 | 35 |
| 5. Frame filtering .....                    | 65 |
| enum ieee80211_filter_flags .....           | 66 |
| 6. The mac80211 workqueue .....             | 67 |
| ieee80211_queue_work .....                  | 68 |
| ieee80211_queue_delayed_work .....          | 69 |

---

# Chapter 1. Basic hardware handling

TBD

This chapter shall contain information on getting a hw struct allocated and registered with mac80211.

Since it is required to allocate rates/modes before registering a hw struct, this chapter shall also contain information on setting up the rate/mode structs.

Additionally, some discussion about the callbacks and the general programming model should be in here, including the definition of ieee80211\_ops which will be referred to a lot.

Finally, a discussion of hardware capabilities should be done with references to other parts of the book.

## Name

struct ieee80211\_hw — hardware information and state

## Synopsis

```
struct ieee80211_hw {
    struct ieee80211_conf conf;
    struct wiphy * wiphy;
    const char * rate_control_algorithm;
    void * priv;
    u32 flags;
    unsigned int extra_tx_headroom;
    unsigned int extra_beacon_tailroom;
    int vif_data_size;
    int sta_data_size;
    int chanctx_data_size;
    int txq_data_size;
    u16 queues;
    u16 max_listen_interval;
    s8 max_signal;
    u8 max_rates;
    u8 max_report_rates;
    u8 max_rate_tries;
    u8 max_rx_aggregation_subframes;
    u8 max_tx_aggregation_subframes;
    u8 offchannel_tx_hw_queue;
    u8 radiotap_mcs_details;
    u16 radiotap_vht_details;
    netdev_features_t netdev_features;
    u8 uapsd_queues;
    u8 uapsd_max_sp_len;
    u8 n_cipher_schemes;
    const struct ieee80211_cipher_scheme * cipher_schemes;
    int txq_ac_max_pending;
};
```

## Members

|                        |   |
|------------------------|---|
| conf                   | struct ieee80211_conf, device configuration, don't use.   |
| wiphy                  | This points to the struct wiphy allocated for this 802.11 PHY. You must fill in the <i>perm_addr</i> and <i>dev</i> members of this structure using SET_IEEE80211_DEV and SET_IEEE80211_PERM_ADDR. Additionally, all supported bands (with channels, bitrates) are registered here. |
| rate_control_algorithm | rate control algorithm for this hardware. If unset (NULL), the default algorithm will be used. Must be set before calling ieee80211_register_hw.  |
| priv                   | pointer to private area that was allocated for driver use along with this structure.  |

|                              |   |
|------------------------------|---|
| flags                        | hardware flags, see enum <code>ieee80211_hw_flags</code> .  |
| extra_tx_headroom            | headroom to reserve in each transmit skb for use by the driver (e.g. for transmit headers.)   |
| extra_beacon_tailroom        | tailroom to reserve in each beacon tx skb. Can be used by drivers to add extra IEs.   |
| vif_data_size                | size (in bytes) of the <code>drv_priv</code> data area within struct <code>ieee80211_vif</code> .   |
| sta_data_size                | size (in bytes) of the <code>drv_priv</code> data area within struct <code>ieee80211_sta</code> .   |
| chanctx_data_size            | size (in bytes) of the <code>drv_priv</code> data area within struct <code>ieee80211_chanctx_conf</code> .  |
| txq_data_size                | size (in bytes) of the <code>drv_priv</code> data area within struct <code>ieee80211_txq</code> .   |
| queues                       | number of available hardware transmit queues for data packets. WMM/QoS requires at least four, these queues need to have configurable access parameters.  |
| max_listen_interval          | max listen interval in units of beacon interval that HW supports  |
| max_signal                   | Maximum value for signal (rssi) in RX information, used only when <code>IEEE80211_HW_SIGNAL_UNSPEC</code> or <code>IEEE80211_HW_SIGNAL_DB</code>  |
| max_rates                    | maximum number of alternate rate retry stages the hw can handle.  |
| max_report_rates             | maximum number of alternate rate retry stages the hw can report back.   |
| max_rate_tries               | maximum number of tries for each stage  |
| max_rx_aggregation_subframes | maximum buffer size (number of sub-frames) to be used for A-MPDU block ack receiver aggregation. This is only relevant if the device has restrictions on the number of subframes, if it relies on mac80211 to do reordering it shouldn't be set.                                  |
| max_tx_aggregation_subframes | maximum number of subframes in an aggregate an HT driver will transmit, used by the peer as a hint to size its reorder buffer.  |
| offchannel_tx_hw_queue       | HW queue ID to use for offchannel TX (if <code>IEEE80211_HW_QUEUE_CONTROL</code> is set)  |
| radiotap_mcs_details         | lists which MCS information can the HW reports, by default it is set to <code>_MCS</code> , <code>_GI</code> and <code>_BW</code> but doesn't include <code>_FMT</code> . Use <code>IEEE80211_RADIOTAP_MCS_HAVE_*</code> values, only adding <code>_BW</code> is supported today. |
| radiotap_vht_details         | lists which VHT MCS information the HW reports, the default is <code>_GI</code>   <code>_BANDWIDTH</code> . Use the <code>IEEE80211_RADIOTAP_VHT_KNOWN_*</code> values.   |
| netdev_features              | netdev features to be set in each netdev created from this HW. Note only HW checksum features are currently compatible with mac80211. Other feature bits will be rejected.  |

|                    |  |
|--------------------|--|
| uapsd_queues       | This bitmap is included in (re)association frame to indicate for each access category if it is uAPSD trigger-enabled and delivery-enabled. Use IEEE80211_WMM_IE_STA_QOSINFO_AC_* to set this bitmap. Each bit corresponds to different AC. Value '1' in specific bit means that corresponding AC is both trigger- and delivery-enabled. '0' means neither enabled. |
| uapsd_max_sp_len   | maximum number of total buffered frames the WMM AP may deliver to a WMM STA during any Service Period triggered by the WMM STA. Use IEEE80211_WMM_IE_STA_QOSINFO_SP_* for correct values.  |
| n_cipher_schemes   | a size of an array of cipher schemes definitions.  |
| cipher_schemes     | a pointer to an array of cipher scheme definitions supported by HW.  |
| txq_ac_max_pending | maximum number of frames per AC pending in all txq entries for a vif.  |

## Description

This structure contains the configuration and hardware information for an 802.11 PHY.

## Name

enum ieee80211\_hw\_flags — hardware flags

## Synopsis

```
enum ieee80211_hw_flags {
    IEEE80211_HW_HAS_RATE_CONTROL,
    IEEE80211_HW_RX_INCLUDES_FCS,
    IEEE80211_HW_HOST_BROADCAST_PS_BUFFERING,
    IEEE80211_HW_2GHZ_SHORT_SLOT_INCAPABLE,
    IEEE80211_HW_2GHZ_SHORT_PREAMBLE_INCAPABLE,
    IEEE80211_HW_SIGNAL_UNSPEC,
    IEEE80211_HW_SIGNAL_DBM,
    IEEE80211_HW_NEED_DTIM_BEFORE_ASSOC,
    IEEE80211_HW_SPECTRUM_MGMT,
    IEEE80211_HW_AMPDU_AGGREGATION,
    IEEE80211_HW_SUPPORTS_PS,
    IEEE80211_HW_PS_NULLFUNC_STACK,
    IEEE80211_HW_SUPPORTS_DYNAMIC_PS,
    IEEE80211_HW_MFP_CAPABLE,
    IEEE80211_HW_WANT_MONITOR_VIF,
    IEEE80211_HW_NO_AUTO_VIF,
    IEEE80211_HW_SW_CRYPTO_CONTROL,
    IEEE80211_HW_REPORTS_TX_ACK_STATUS,
    IEEE80211_HW_CONNECTION_MONITOR,
    IEEE80211_HW_QUEUE_CONTROL,
    IEEE80211_HW_SUPPORTS_PER_STA_GTK,
    IEEE80211_HW_AP_LINK_PS,
    IEEE80211_HW_TX_AMPDU_SETUP_IN_HW,
    IEEE80211_HW_SUPPORTS_RC_TABLE,
    IEEE80211_HW_P2P_DEV_ADDR_FOR_INTF,
    IEEE80211_HW_TIMING_BEACON_ONLY,
    IEEE80211_HW_SUPPORTS_HT_CCK_RATES,
    IEEE80211_HW_CHANCTX_STA_CSA,
    IEEE80211_HW_SUPPORTS_CLONED_SKBS,
    IEEE80211_SINGLE_HW_SCAN_ON_ALL_BANDS
};
```

## Constants

**IEEE80211\_HW\_HAS\_RATE\_CONTROL** If hardware or firmware includes rate control, and cannot be controlled by the stack. As such, no rate control algorithm should be instantiated, and the TX rate reported to userspace will be taken from the TX status instead of the rate control algorithm. Note that this requires that the driver implement a number of callbacks so it has the correct information, it needs to have the *set\_rts\_threshold* callback and must look at the BSS config *use\_cts\_prot* for G/N protection, *use\_short\_slot* for slot timing in 2.4 GHz and *use\_short\_preamble* for preambles for CCK frames.

|  |  |
|--|--|
| IEEE80211_HW_RX_INCLUDES_FCS               | Indicates that received frames passed to the stack include the FCS at the end.   |
| IEEE80211_HW_HOST_BROADCAST_PS_BUFFERING   | Some chipsets buffer broadcast/multicast frames for power saving stations in the hardware/firmware and others rely on the host system for such buffering. This option is used to configure the IEEE 802.11 upper layer to buffer broadcast and multicast frames when there are power saving stations so that the driver can fetch them with <code>ieee80211_get_buffered_bc</code> . |
| IEEE80211_HW_2GHZ_SHORT_SLOT_INCAPABLE     | Hardware is not capable of short slot operation on the 2.4 GHz band.   |
| IEEE80211_HW_2GHZ_SHORT_PREAMBLE_INCAPABLE | Hardware is not capable of receiving frames with short preamble on the 2.4 GHz band.   |
| IEEE80211_HW_SIGNAL_UNSPEC                 | Hardware can provide signal values but we don't know its units. We expect values between 0 and <code>max_signal</code> . If possible please provide dB or dBm instead.   |
| IEEE80211_HW_SIGNAL_DBM                    | Hardware gives signal values in dBm, decibel difference from one milliwatt. This is the preferred method since it is standardized between different devices. <code>max_signal</code> does not need to be set.  |
| IEEE80211_HW_NEED_DTIM_BEFORE_ASSOC        | Driver needs to get data from beacon before association (i.e. <code>dtim_period</code> ).  |
| IEEE80211_HW_SPECTRUM_MGMT                 | Hardware supports spectrum management defined in 802.11h Measurement, Channel Switch, Quietening, TPC  |
| IEEE80211_HW_AMPDU_AGGREGATION             | Hardware supports 11n A-MPDU aggregation.  |
| IEEE80211_HW_SUPPORTS_PS                   | Hardware has power save support (i.e. can go to sleep).  |
| IEEE80211_HW_PS_NULLFUNC_STACK             | Hardware requires nullfunc frame handling in stack, implies stack support for dynamic PS.  |
| IEEE80211_HW_SUPPORTS_DYNAMIC_PS           | Hardware has support for dynamic PS.   |
| IEEE80211_HW_MFP_CAPABLE                   | Hardware supports management frame protection (MFP, IEEE 802.11w).   |
| IEEE80211_HW_WANT_MONITOR_VIF              | Driver would like to be informed of a virtual monitor interface when monitor interfaces are the only active interfaces.  |
| IEEE80211_HW_NO_AUTO_VIF                   | The driver would like for no wlanX to be created. It is expected user-space will create vifs as desired (and thus have them named as desired).   |
| IEEE80211_HW_SW_CRYPTO_CONTROL             | Driver wants to control which of the crypto algorithms can be done in software - so don't automatically try to fall back to it if hardware crypto fails, but do so only if the driver returns 1. This also forces the driver to advertise its supported cipher suites.   |
| IEEE80211_HW_REPORTS_TX_ACK_STATUS         | Hardware can provide ack status reports of Tx frames to the stack.   |
| IEEE80211_HW_CONNECTION_MONITOR            | Hardware performs its own connection monitoring, including periodic keep-alives to the AP and probing the AP on beacon loss.   |

|                                       |   |
|---------------------------------------|---|
| IEEE80211_HW_QUEUE_CONTROL            | The driver wants to control per-interface queue mapping in order to use different queues (not just one per AC) for different virtual interfaces. See the doc section on HW queue control for more details.  |
| IEEE80211_HW_SUPPORTS_PER_STA_GTK     | The GTK's crypto engine supports per-station GTKs as used by IBSS RSN or during fast transition. If the device doesn't support per-station GTKs, but can be asked not to decrypt group addressed frames, then IBSS RSN support is still possible but software crypto will be used. Advertise the wiphy flag only in that case.      |
| IEEE80211_HW_AP_LINK_PS               | When operating in AP mode the device autonomously manages the PS status of connected stations. When this flag is set mac80211 will not trigger PS mode for connected stations based on the PM bit of incoming frames. Use <code>ieee80211_start_ps/ieee80211_end_ps</code> to manually configure the PS mode of connected stations. |
| IEEE80211_HW_TX_AMPDU_SETUP_IN_HW     | The driver handles TX A-MPDU session setup strictly in HW. mac80211 should not attempt to do this in software.  |
| IEEE80211_HW_SUPPORTS_RC_TABLE        | The driver supports using a rate selection table provided by the rate control algorithm.  |
| IEEE80211_HW_P2P_DEV_ADDR_FOR_INTF    | For the P2P Device address for any P2P Interface. This will be honoured even if more than one interface is supported.   |
| IEEE80211_HW_TIMING_BEACON_USE_SYNC   | Use sync timing from beacon frames only, to allow getting TBTT of a DTIM beacon.  |
| IEEE80211_HW_SUPPORTS_HT_CCK_RATES    | Supports mixing HT/CCK rates and can cope with CCK rates in an aggregation session (e.g. by not using aggregation for such frames.)   |
| IEEE80211_HW_CHANCTX_STA_CSA          | Support 802.11h based channel-switch (CSA) for a single active channel while using channel contexts. When support is not enabled the default action is to disconnect when getting the CSA frame.  |
| IEEE80211_HW_SUPPORTS_CLONE_TX_SKBS   | The driver will never modify the payload or tailroom of TX skbs without copying them first.   |
| IEEE80211_SINGLE_HW_SCAN_ON_ALL_BANDS | The driver supports scanning on all bands in one command, mac80211 doesn't have to run separate scans per band.   |

## Description

These flags are used to indicate hardware capabilities to the stack. Generally, flags here should have their meaning done in a way that the simplest hardware doesn't need setting any particular flags. There are some exceptions to this rule, however, so you are advised to review these flags carefully.



## Name

SET\_IEEE80211\_DEV — set device for 802.11 hardware

## Synopsis

```
void SET_IEEE80211_DEV (struct ieee80211_hw * hw, struct device * dev);
```

## Arguments

*hw*     the struct ieee80211\_hw to set the device for

*dev*    the struct device of this 802.11 device

## Name

SET\_IEEE80211\_PERM\_ADDR — set the permanent MAC address for 802.11 hardware

## Synopsis

```
void SET_IEEE80211_PERM_ADDR (struct ieee80211_hw * hw, u8 * addr);
```

## Arguments

*hw* the struct ieee80211\_hw to set the MAC address for

*addr* the address to set

## Name

struct ieee80211\_ops — callbacks from mac80211 to the driver

## Synopsis

```
struct ieee80211_ops {
    void (* tx) (struct ieee80211_hw *hw, struct ieee80211_tx_control *control, struct ieee80211_tx_info *info);
    int (* start) (struct ieee80211_hw *hw);
    void (* stop) (struct ieee80211_hw *hw);
#ifdef CONFIG_PM
    int (* suspend) (struct ieee80211_hw *hw, struct cfg80211_wowlan *wowlan);
    int (* resume) (struct ieee80211_hw *hw);
    void (* set_wakeup) (struct ieee80211_hw *hw, bool enabled);
#endif
    int (* add_interface) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    int (* change_interface) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, enum ieee80211_if_type type);
    void (* remove_interface) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    int (* config) (struct ieee80211_hw *hw, u32 changed);
    void (* bss_info_changed) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_bss_info *bss, u32 changed);
    int (* start_ap) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    void (* stop_ap) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    u64 (* prepare_multicast) (struct ieee80211_hw *hw, struct netdev_hw_addr_list *mlist);
    void (* configure_filter) (struct ieee80211_hw *hw, unsigned int changed_flags, unsigned int *filter_flags);
    int (* set_tim) (struct ieee80211_hw *hw, struct ieee80211_sta *sta, bool set);
    int (* set_key) (struct ieee80211_hw *hw, enum set_key_cmd cmd, struct ieee80211_sta *sta, struct ieee80211_key_data *key_data);
    void (* update_tkip_key) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_key_data *key_data);
    void (* set_rekey_data) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_key_data *key_data);
    void (* set_default_unicast_key) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_key_data *key_data);
    int (* hw_scan) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_scan_request *req);
    void (* cancel_hw_scan) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    int (* sched_scan_start) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sched_scan_request *req);
    int (* sched_scan_stop) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    void (* sw_scan_start) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, const struct ieee80211_scan_request *req);
    void (* sw_scan_complete) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
    int (* get_stats) (struct ieee80211_hw *hw, struct ieee80211_low_level_stats *stats);
    void (* get_tkip_seq) (struct ieee80211_hw *hw, u8 hw_key_idx, u32 *iv32, u16 *iv48);
    int (* set_frag_threshold) (struct ieee80211_hw *hw, u32 value);
    int (* set_rts_threshold) (struct ieee80211_hw *hw, u32 value);
    int (* sta_add) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    int (* sta_remove) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
#ifdef CONFIG_MAC80211_DEBUGFS
    void (* sta_add_debugfs) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    void (* sta_remove_debugfs) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
#endif
    void (* sta_notify) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, enum ieee80211_sta_notify_type type, struct ieee80211_sta *sta);
    int (* sta_state) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    void (* sta_pre_rcu_remove) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    void (* sta_rc_update) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    void (* sta_rate_tbl_update) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    void (* sta_statistics) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, struct ieee80211_sta *sta);
    int (* conf_tx) (struct ieee80211_hw *hw, struct ieee80211_vif *vif, u16 ac, const struct ieee80211_tx_conf *conf);
    u64 (* get_tsf) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
};
```

---

```

void (* set_tsf) (struct ieee80211_hw *hw, struct ieee80211_vif *vif,u64 tsf);
void (* reset_tsf) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
int (* tx_last_beacon) (struct ieee80211_hw *hw);
int (* ampdu_action) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,enum ieee80211_ampdu_action);
int (* get_survey) (struct ieee80211_hw *hw, int idx,struct survey_info *survey);
void (* rfkill_poll) (struct ieee80211_hw *hw);
void (* set_coverage_class) (struct ieee80211_hw *hw, s16 coverage_class);
#ifdef CONFIG_NL80211_TESTMODE
int (* testmode_cmd) (struct ieee80211_hw *hw, struct ieee80211_vif *vif,void *data);
int (* testmode_dump) (struct ieee80211_hw *hw, struct sk_buff *skb,struct netlink_ext_ack *extack);
#endif
void (* flush) (struct ieee80211_hw *hw, struct ieee80211_vif *vif,u32 queues, bool flush_tx);
void (* channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_channel_switch *chsw);
int (* set_antenna) (struct ieee80211_hw *hw, u32 tx_ant, u32 rx_ant);
int (* get_antenna) (struct ieee80211_hw *hw, u32 *tx_ant, u32 *rx_ant);
int (* remain_on_channel) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_remain_on_channel_req *roch);
int (* cancel_remain_on_channel) (struct ieee80211_hw *hw);
int (* set_ringparam) (struct ieee80211_hw *hw, u32 tx, u32 rx);
void (* get_ringparam) (struct ieee80211_hw *hw,u32 *tx, u32 *tx_max, u32 *rx, u32 *rx_max);
bool (* tx_frames_pending) (struct ieee80211_hw *hw);
int (* set_bitrate_mask) (struct ieee80211_hw *hw, struct ieee80211_vif *vif,const ieee80211_supported_rates *rates);
void (* event_callback) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,const struct ieee80211_event *event);
void (* allow_buffered_frames) (struct ieee80211_hw *hw,struct ieee80211_sta *sta);
void (* release_buffered_frames) (struct ieee80211_hw *hw,struct ieee80211_sta *sta);
int (* get_et_sset_count) (struct ieee80211_hw *hw,struct ieee80211_vif *vif, int *count);
void (* get_et_stats) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_et_stats *stats);
void (* get_et_strings) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,u32 *count, char *strings);
void (* mgd_prepare_tx) (struct ieee80211_hw *hw,struct ieee80211_vif *vif);
void (* mgd_protect_tdlb_discover) (struct ieee80211_hw *hw,struct ieee80211_vif *vif);
int (* add_chanctx) (struct ieee80211_hw *hw,struct ieee80211_chanctx_conf *ctx);
void (* remove_chanctx) (struct ieee80211_hw *hw,struct ieee80211_chanctx_conf *ctx);
void (* change_chanctx) (struct ieee80211_hw *hw,struct ieee80211_chanctx_conf *ctx);
int (* assign_vif_chanctx) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_chanctx_conf *ctx);
void (* unassign_vif_chanctx) (struct ieee80211_hw *hw,struct ieee80211_vif *vif);
int (* switch_vif_chanctx) (struct ieee80211_hw *hw,struct ieee80211_vif_chanctx_conf *ctx);
void (* reconfig_complete) (struct ieee80211_hw *hw,enum ieee80211_reconfig_type type);
#ifdef IS_ENABLED(CONFIG_IPV6)
void (* ipv6_addr_change) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_ipv6_addr *addr);
#endif
void (* channel_switch_beacon) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_channel_switch *chsw);
int (* pre_channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_channel_switch *chsw);
int (* post_channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif);
int (* join_ibss) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
void (* leave_ibss) (struct ieee80211_hw *hw, struct ieee80211_vif *vif);
u32 (* get_expected_throughput) (struct ieee80211_sta *sta);
int (* get_txpower) (struct ieee80211_hw *hw, struct ieee80211_vif *vif,int *dbm);
int (* tdls_channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_tdls_chanctx *ctx);
void (* tdls_cancel_channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif);
void (* tdls_rcv_channel_switch) (struct ieee80211_hw *hw,struct ieee80211_vif *vif,struct ieee80211_tdls_chanctx *ctx);
void (* wake_tx_queue) (struct ieee80211_hw *hw,struct ieee80211_txq *txq);
};

```

---

## Members

|                  |   |
|------------------|---|
| tx               | Handler that 802.11 module calls for each transmitted frame. <code>skb</code> contains the buffer starting from the IEEE 802.11 header. The low-level driver should send the frame out based on configuration in the TX control data. This handler should, preferably, never fail and stop queues appropriately. Must be atomic.  |
| start            | Called before the first netdevice attached to the hardware is enabled. This should turn on the hardware and must turn on frame reception (for possibly enabled monitor interfaces.) Returns negative error codes, these may be seen in userspace, or zero. When the device is started it should not have a MAC address to avoid acknowledging frames before a non-monitor device is added. Must be implemented and can sleep.   |
| stop             | Called after last netdevice attached to the hardware is disabled. This should turn off the hardware (at least it must turn off frame reception.) May be called right after <code>add_interface</code> if that rejects an interface. If you added any work onto the <code>mac80211</code> workqueue you should ensure to cancel it on this callback. Must be implemented and can sleep.  |
| suspend          | Suspend the device; <code>mac80211</code> itself will quiesce before and stop transmitting and doing any other configuration, and then ask the device to suspend. This is only invoked when WoWLAN is configured, otherwise the device is deconfigured completely and reconfigured at resume time. The driver may also impose special conditions under which it wants to use the “normal” suspend (deconfigure), say if it only supports WoWLAN when the device is associated. In this case, it must return 1 from this function. |
| resume           | If WoWLAN was configured, this indicates that <code>mac80211</code> is now resuming its operation, after this the device must be fully functional again. If this returns an error, the only way out is to also unregister the device. If it returns 1, then <code>mac80211</code> will also go through the regular complete restart on resume.  |
| set_wakeup       | Enable or disable wakeup when WoWLAN configuration is modified. The reason is that <code>device_set_wakeup_enable</code> is supposed to be called when the configuration changes, not only in suspend.  |
| add_interface    | Called when a netdevice attached to the hardware is enabled. Because it is not called for monitor mode devices, <code>start</code> and <code>stop</code> must be implemented. The driver should perform any initialization it needs before the device can be enabled. The initial configuration for the interface is given in the <code>conf</code> parameter. The callback may refuse to add an interface by returning a negative error code (which will be seen in userspace.) Must be implemented and can sleep.               |
| change_interface | Called when a netdevice changes type. This callback is optional, but only if it is supported can interface types be switched while the  |

|                                |  |
|--------------------------------|--|
|                                | interface is UP. The callback may sleep. Note that while an interface is being switched, it will not be found by the interface iteration callbacks.  |
| <code>remove_interface</code>  | Notifies a driver that an interface is going down. The <i>stop</i> callback is called after this if it is the last interface and no monitor interfaces are present. When all interfaces are removed, the MAC address in the hardware must be cleared so the device no longer acknowledges packets, the <i>mac_addr</i> member of the <i>conf</i> structure is, however, set to the MAC address of the device going away. Hence, this callback must be implemented. It can sleep. |
| <code>config</code>            | Handler for configuration requests. IEEE 802.11 code calls this function to change hardware configuration, e.g., channel. This function should never fail but returns a negative error code if it does. The callback can sleep.  |
| <code>bss_info_changed</code>  | Handler for configuration requests related to BSS parameters that may vary during BSS's lifespan, and may affect low level driver (e.g. assoc/disassoc status, <i>erp</i> parameters). This function should not be used if no BSS has been set, unless for association indication. The <i>changed</i> parameter indicates which of the bss parameters has changed when a call is made. The callback can sleep.   |
| <code>start_ap</code>          | Start operation on the AP interface, this is called after all the information in <i>bss_conf</i> is set and beacon can be retrieved. A channel context is bound before this is called. Note that if the driver uses software scan or ROC, this (and <i>stop_ap</i> ) isn't called when the AP is just "paused" for scanning/ROC, which is indicated by the beacon being disabled/enabled via <i>bss_info_changed</i> .   |
| <code>stop_ap</code>           | Stop operation on the AP interface.  |
| <code>prepare_multicast</code> | Prepare for multicast filter configuration. This callback is optional, and its return value is passed to <i>configure_filter</i> . This callback must be atomic.   |
| <code>configure_filter</code>  | Configure the device's RX filter. See the section "Frame filtering" for more information. This callback must be implemented and can sleep.   |
| <code>set_tim</code>           | Set TIM bit. <i>mac80211</i> calls this function when a TIM bit must be set or cleared for a given STA. Must be atomic.  |
| <code>set_key</code>           | See the section "Hardware crypto acceleration" This callback is only called between <i>add_interface</i> and <i>remove_interface</i> calls, i.e. while the given virtual interface is enabled. Returns a negative error code if the key can't be added. The callback can sleep.  |
| <code>update_tkip_key</code>   | See the section "Hardware crypto acceleration" This callback will be called in the context of Rx. Called for drivers which set <i>IEEE80211_KEY_FLAG_TKIP_REQ_RX_P1_KEY</i> . The callback must be atomic.   |
| <code>set_rekey_data</code>    | If the device supports GTK rekeying, for example while the host is suspended, it can assign this callback to retrieve the  |

|                                      |  |
|--------------------------------------|--|
|                                      | data necessary to do GTK rekeying, this is the KEK, KCK and replay counter. After rekeying was done it should (for example during resume) notify userspace of the new replay counter using <code>ieee80211_gtk_rekey_notify</code> .   |
| <code>set_default_unicast_key</code> | Set the default (unicast) key index, useful for WEP when the device sends data packets autonomously, e.g. for ARP offloading. The index can be 0-3, or -1 for unsetting it.  |
| <code>hw_scan</code>                 | Ask the hardware to service the scan request, no need to start the scan state machine in stack. The scan must honour the channel configuration done by the regulatory agent in the wiphy's registered bands. The hardware (or the driver) needs to make sure that power save is disabled. The <code>req_ie/ie_len</code> members are rewritten by mac80211 to contain the entire IEs after the SSID, so that drivers need not look at these at all but just send them after the SSID -- mac80211 includes the (extended) supported rates and HT information (where applicable). When the scan finishes, <code>ieee80211_scan_completed</code> must be called; note that it also must be called when the scan cannot finish due to any error unless this callback returned a negative error code. The callback can sleep. |
| <code>cancel_hw_scan</code>          | Ask the low-level tp cancel the active hw scan. The driver should ask the hardware to cancel the scan (if possible), but the scan will be completed only after the driver will call <code>ieee80211_scan_completed</code> . This callback is needed for wowlan, to prevent enqueueing a new scan_work after the low-level driver was already suspended. The callback can sleep.  |
| <code>sched_scan_start</code>        | Ask the hardware to start scanning repeatedly at specific intervals. The driver must call the <code>ieee80211_sched_scan_results</code> function whenever it finds results. This process will continue until <code>sched_scan_stop</code> is called.   |
| <code>sched_scan_stop</code>         | Tell the hardware to stop an ongoing scheduled scan. In this case, <code>ieee80211_sched_scan_stopped</code> must not be called.   |
| <code>sw_scan_start</code>           | Notifier function that is called just before a software scan is started. Can be NULL, if the driver doesn't need this notification. The <code>mac_addr</code> parameter allows supporting NL80211_SCAN_FLAG_RANDOM_ADDR, the driver may set the NL80211_FEATURE_SCAN_RANDOM_MAC_ADDR flag if it can use this parameter. The callback can sleep.  |
| <code>sw_scan_complete</code>        | Notifier function that is called just after a software scan finished. Can be NULL, if the driver doesn't need this notification. The callback can sleep.   |
| <code>get_stats</code>               | Return low-level statistics. Returns zero if statistics are available. The callback can sleep.   |
| <code>get_tkip_seq</code>            | If your device implements TKIP encryption in hardware this callback should be provided to read the TKIP transmit IVs (both IV32 and IV16) for the given key from hardware. The callback must be atomic.  |

|                                  |   |
|----------------------------------|---|
| <code>set_frag_threshold</code>  | Configuration of fragmentation threshold. Assign this if the device does fragmentation by itself; if this callback is implemented then the stack will not do fragmentation. The callback can sleep.   |
| <code>set_rts_threshold</code>   | Configuration of RTS threshold (if device needs it) The callback can sleep.   |
| <code>sta_add</code>             | Notifies low level driver about addition of an associated station, AP, IBSS/WDS/mesh peer etc. This callback can sleep.   |
| <code>sta_remove</code>          | Notifies low level driver about removal of an associated station, AP, IBSS/WDS/mesh peer etc. Note that after the callback returns it isn't safe to use the pointer, not even RCU protected; no RCU grace period is guaranteed between returning here and freeing the station. See <i>sta_pre_rcu_remove</i> if needed. This callback can sleep.  |
| <code>sta_add_debugfs</code>     | Drivers can use this callback to add debugfs files when a station is added to mac80211's station list. This callback and <i>sta_remove_debugfs</i> should be within a CONFIG_MAC80211_DEBUGFS conditional. This callback can sleep.   |
| <code>sta_remove_debugfs</code>  | Remove the debugfs files which were added using <i>sta_add_debugfs</i> . This callback can sleep.   |
| <code>sta_notify</code>          | Notifies low level driver about power state transition of an associated station, AP, IBSS/WDS/mesh peer etc. For a VIF operating in AP mode, this callback will not be called when the flag IEEE80211_HW_AP_LINK_PS is set. Must be atomic.   |
| <code>sta_state</code>           | Notifies low level driver about state transition of a station (which can be the AP, a client, IBSS/WDS/mesh peer etc.) This callback is mutually exclusive with <i>sta_add/sta_remove</i> . It must not fail for down transitions but may fail for transitions up the list of states. Also note that after the callback returns it isn't safe to use the pointer, not even RCU protected - no RCU grace period is guaranteed between returning here and freeing the station. See <i>sta_pre_rcu_remove</i> if needed. The callback can sleep. |
| <code>sta_pre_rcu_remove</code>  | Notify driver about station removal before RCU synchronisation. This is useful if a driver needs to have station pointers protected using RCU, it can then use this call to clear the pointers instead of waiting for an RCU grace period to elapse in <i>sta_state</i> . The callback can sleep.   |
| <code>sta_rc_update</code>       | Notifies the driver of changes to the bitrates that can be used to transmit to the station. The changes are advertised with bits from enum <code>ieee80211_rate_control_changed</code> and the values are reflected in the station data. This callback should only be used when the driver uses hardware rate control ( <code>IEEE80211_HW_HAS_RATE_CONTROL</code> ) since otherwise the rate control algorithm is notified directly. Must be atomic.   |
| <code>sta_rate_tbl_update</code> | Notifies the driver that the rate table changed. This is only used if the configured rate control algorithm actually uses the new rate table API, and is therefore optional. Must be atomic.  |



|                    |  |
|--------------------|--|
| sta_statistics     | Get statistics for this station. For example with beacon filtering, the statistics kept by mac80211 might not be accurate, so let the driver pre-fill the statistics. The driver can fill most of the values (indicating which by setting the filled bitmap), but not all of them make sense - see the source for which ones are possible. Statistics that the driver doesn't fill will be filled by mac80211. The callback can sleep.   |
| conf_tx            | Configure TX queue parameters (EDCF (aifs, cw_min, cw_max), bursting) for a hardware TX queue. Returns a negative error code on failure. The callback can sleep.   |
| get_tsf            | Get the current TSF timer value from firmware/hardware. Currently, this is only used for IBSS mode BSSID merging and debugging. Is not a required function. The callback can sleep.  |
| set_tsf            | Set the TSF timer to the specified value in the firmware/hardware. Currently, this is only used for IBSS mode debugging. Is not a required function. The callback can sleep.   |
| reset_tsf          | Reset the TSF timer and allow firmware/hardware to synchronize with other STAs in the IBSS. This is only used in IBSS mode. This function is optional if the firmware/hardware takes full care of TSF synchronization. The callback can sleep.   |
| tx_last_beacon     | Determine whether the last IBSS beacon was sent by us. This is needed only for IBSS mode and the result of this function is used to determine whether to reply to Probe Requests. Returns non-zero if this device sent the last beacon. The callback can sleep.  |
| ampdu_action       | Perform a certain A-MPDU action The RA/TID combination determines the destination and TID we want the ampdu action to be performed for. The action is defined through ieee80211_ampdu_mlme_action. Starting sequence number ( <i>ssn</i> ) is the first frame we expect to perform the action on. Notice that TX/RX_STOP can pass NULL for this parameter. The <i>buf_size</i> parameter is only valid when the action is set to IEEE80211_AMPDU_TX_OPERATIONAL and indicates the peer's reorder buffer size (number of subframes) for this session -- the driver may neither send aggregates containing more subframes than this nor send aggregates in a way that lost frames would exceed the buffer size. If just limiting the aggregate size, this would be |
| get_survey         | Return per-channel survey information  |
| rkill_poll         | Poll rkill hardware state. If you need this, you also need to set wiphy->rkill_poll to true before registration, and need to call wiphy_rkill_set_hw_state in the callback. The callback can sleep.  |
| set_coverage_class | Set slot time for given coverage class as specified in IEEE 802.11-2007 section 17.3.8.6 and modify ACK timeout accordingly; coverage class equals to -1 to enable ACK timeout estimation algorithm (dynack). To disable dynack set valid value for coverage class. This callback is not required and may sleep.   |

|                          |  |
|--------------------------|--|
| testmode_cmd             | Implement a cfg80211 test mode command. The passed <i>vif</i> may be NULL. The callback can sleep.   |
| testmode_dump            | Implement a cfg80211 test mode dump. The callback can sleep.   |
| flush                    | Flush all pending frames from the hardware queue, making sure that the hardware queues are empty. The <i>queues</i> parameter is a bitmap of queues to flush, which is useful if different virtual interfaces use different hardware queues; it may also indicate all queues. If the parameter <i>drop</i> is set to <code>true</code> , pending frames may be dropped. Note that <i>vif</i> can be NULL. The callback can sleep.  |
| channel_switch           | Drivers that need (or want) to offload the channel switch operation for CSAs received from the AP may implement this callback. They must then call <code>ieee80211_chswitch_done</code> to indicate completion of the channel switch.  |
| set_antenna              | Set antenna configuration ( <i>tx_ant</i> , <i>rx_ant</i> ) on the device. Parameters are bitmaps of allowed antennas to use for TX/RX. Drivers may reject TX/RX mask combinations they cannot support by returning <code>-EINVAL</code> (also see <code>nl80211.h</code> <code>NL80211_ATTR_WIPHY_ANTENNA_TX</code> ).  |
| get_antenna              | Get current antenna configuration from device ( <i>tx_ant</i> , <i>rx_ant</i> ).   |
| remain_on_channel        | Starts an off-channel period on the given channel, must call back to <code>ieee80211_ready_on_channel</code> when on that channel. Note that normal channel traffic is not stopped as this is intended for hw offload. Frames to transmit on the off-channel channel are transmitted normally except for the <code>IEEE80211_TX_CTL_TX_OFFCHAN</code> flag. When the duration (which will always be non-zero) expires, the driver must call <code>ieee80211_remain_on_channel_expired</code> . Note that this callback may be called while the device is in IDLE and must be accepted in this case. This callback may sleep. |
| cancel_remain_on_channel | Requests that an ongoing off-channel period is aborted before it expires. This callback may sleep.   |
| set_ringparam            | Set tx and rx ring sizes.  |
| get_ringparam            | Get tx and rx ring current and maximum sizes.  |
| tx_frames_pending        | Check if there is any pending frame in the hardware queues before entering power save.   |
| set_bitrate_mask         | Set a mask of rates to be used for rate control selection when transmitting a frame. Currently only legacy rates are handled. The callback can sleep.  |
| event_callback           | Notify driver about any event in mac80211. See enum <code>ieee80211_event_type</code> for the different types. The callback can sleep.   |
| allow_buffered_frames    | Prepare device to allow the given number of frames to go out to the given station. The frames will be sent by mac80211 via the usual   |

TX path after this call. The TX information for frames released will also have the `IEEE80211_TX_CTL_NO_PS_BUFFER` flag set and the last one will also have `IEEE80211_TX_STATUS_EOSP` set. In case frames from multiple TIDs are released and the driver might reorder them between the TIDs, it must set the `IEEE80211_TX_STATUS_EOSP` flag on the last frame and clear it on all others and also handle the EOSP bit in the QoS header correctly. Alternatively, it can also call the `ieee80211_sta_eosp` function. The `tids` parameter is a bitmap and tells the driver which TIDs the frames will be on; it will at most have two bits set. This callback must be atomic.

`release_buffered_frames`

Release buffered frames according to the given parameters. In the case where the driver buffers some frames for sleeping stations `mac80211` will use this callback to tell the driver to release some frames, either for PS-poll or uAPSD. Note that if the `more_data` parameter is `false` the driver must check if there are more frames on the given TIDs, and if there are more than the frames being released then it must still set the more-data bit in the frame. If the `more_data` parameter is `true`, then of course the more-data bit must always be set. The `tids` parameter tells the driver which TIDs to release frames from, for PS-poll it will always have only a single bit set. In the case this is used for a PS-poll initiated release, the `num_frames` parameter will always be 1 so code can be shared. In this case the driver must also set `IEEE80211_TX_STATUS_EOSP` flag on the TX status (and must report TX status) so that the PS-poll period is properly ended. This is used to avoid sending multiple responses for a retried PS-poll frame. In the case this is used for uAPSD, the `num_frames` parameter may be bigger than one, but the driver may send fewer frames (it must send at least one, however). In this case it is also responsible for setting the EOSP flag in the QoS header of the frames. Also, when the service period ends, the driver must set `IEEE80211_TX_STATUS_EOSP` on the last frame in the SP. Alternatively, it may call the function `ieee80211_sta_eosp` to inform `mac80211` of the end of the SP. This callback must be atomic.

`get_et_sset_count`

Ethtool API to get string-set count.

`get_et_stats`

Ethtool API to get a set of u64 stats.

`get_et_strings`

Ethtool API to get a set of strings to describe stats and perhaps other supported types of ethtool data-sets.

`mgd_prepare_tx`

Prepare for transmitting a management frame for association before associated. In multi-channel scenarios, a virtual interface is bound to a channel before it is associated, but as it isn't associated yet it need not necessarily be given airtime, in particular since any transmission to a P2P GO needs to be synchronized against the GO's powersave state. `mac80211` will call this function before transmitting a management frame prior to having successfully associated to allow the driver to give it channel time for the transmission, to get a response and to be able to synchronize with the GO. The callback will be called before each transmission and

|  |   |
|--|---|
|  | upon return <code>mac80211</code> will transmit the frame right away. The callback is optional and can (should!) sleep.   |
| <code>mgd_protect_tdls_discover</code> | Protect a TDLS discovery session. After sending a TDLS discovery-request, we expect a reply to arrive on the AP's channel. We must stay on the channel (no PSM, scan, etc.), since a TDLS setup-response is a direct packet not buffered by the AP. <code>mac80211</code> will call this function just before the transmission of a TDLS discovery-request. The recommended period of protection is at least $2 * (DTIM \text{ period})$ . The callback is optional and can sleep.  |
| <code>add_chanctx</code>               | Notifies device driver about new channel context creation.  |
| <code>remove_chanctx</code>            | Notifies device driver about channel context destruction.   |
| <code>change_chanctx</code>            | Notifies device driver about channel context changes that may happen when combining different virtual interfaces on the same channel context with different settings  |
| <code>assign_vif_chanctx</code>        | Notifies device driver about channel context being bound to vif. Possible use is for hw queue remapping.  |
| <code>unassign_vif_chanctx</code>      | Notifies device driver about channel context being unbound from vif.  |
| <code>switch_vif_chanctx</code>        | switch a number of vifs from one chanctx to another, as specified in the list of <code>ieee80211_vif_chanctx_switch</code> passed to the driver, according to the mode defined in <code>ieee80211_chanctx_switch_mode</code> .  |
| <code>reconfig_complete</code>         | Called after a call to <code>ieee80211_restart_hw</code> and during resume, when the reconfiguration has completed. This can help the driver implement the reconfiguration step (and indicate <code>mac80211</code> is ready to receive frames). This callback may sleep.   |
| <code>ipv6_addr_change</code>          | IPv6 address assignment on the given interface changed. Currently, this is only called for managed or P2P client interfaces. This callback is optional; it must not sleep.  |
| <code>channel_switch_beacon</code>     | Starts a channel switch to a new channel. Beacons are modified to include CSA or EDSA IEs before calling this function. The corresponding count fields in these IEs must be decremented, and when they reach 1 the driver must call <code>ieee80211_csa_finish</code> . Drivers which use <code>ieee80211_beacon_get</code> get the csa counter decremented by <code>mac80211</code> , but must check if it is 1 using <code>ieee80211_csa_is_complete</code> after the beacon has been transmitted and then call <code>ieee80211_csa_finish</code> . If the CSA count starts as zero or 1, this function will not be called, since there won't be any time to beacon before the switch anyway. |
| <code>pre_channel_switch</code>        | This is an optional callback that is called before a channel switch procedure is started (ie. when a STA gets a CSA or an userspace initiated channel-switch), allowing the driver to prepare for the channel switch.   |

|   |   |
|---|---|
| <code>post_channel_switch</code>        | This is an optional callback that is called after a channel switch procedure is completed, allowing the driver to go back to a normal configuration.  |
| <code>join_ibss</code>                  | Join an IBSS (on an IBSS interface); this is called after all information in <code>bss_conf</code> is set up and the beacon can be retrieved. A channel context is bound before this is called.   |
| <code>leave_ibss</code>                 | Leave the IBSS again.   |
| <code>get_expected_throughput</code>    | extract the expected throughput towards the specified station. The returned value is expressed in Kbps. It returns 0 if the RC algorithm does not have proper data to provide.  |
| <code>get_txpower</code>                | get current maximum tx power (in dBm) based on configuration and hardware limits.   |
| <code>tdls_channel_switch</code>        | Start channel-switching with a TDLS peer. The driver is responsible for continually initiating channel-switching operations and returning to the base channel for communication with the AP. The driver receives a channel-switch request template and the location of the switch-timing IE within the template as part of the invocation. The template is valid only within the call, and the driver can optionally copy the skb for further re-use. |
| <code>tdls_cancel_channel_switch</code> | Stop channel-switching with a TDLS peer. Both peers must be on the base channel when the call completes.  |
| <code>tdls_recv_channel_switch</code>   | a TDLS channel-switch related frame (request or response) has been received from a remote peer. The driver gets parameters parsed from the incoming frame and may use them to continue an ongoing channel-switch operation. In addition, a channel-switch response template is provided, together with the location of the switch-timing IE within the template. The skb can only be used within the function call.                                   |
| <code>wake_tx_queue</code>              | Called when new packets have been added to the queue.   |

## Description

This structure contains various callbacks that the driver may handle or, in some cases, must handle, for example to configure the hardware to a new channel or to transmit a frame.

## possible with a `buf_size` of 8

- TX: 1.....7 - RX: 2....7 (lost frame #1) - TX: 8..1... which is invalid since #1 was now re-transmitted well past the buffer size of 8. Correct ways to retransmit #1 would be: - TX: 1 or 18 or 81 Even “189” would be wrong since 1 could be lost again.

Returns a negative error code on failure. The callback can sleep.

## Name

ieee80211\_alloc\_hw — Allocate a new hardware device

## Synopsis

```
struct ieee80211_hw * ieee80211_alloc_hw (size_t priv_data_len, const  
struct ieee80211_ops * ops);
```

## Arguments

*priv\_data\_len*    length of private data

*ops*                callbacks for this device

## Description

This must be called once for each hardware device. The returned pointer must be used to refer to this device when calling other functions. mac80211 allocates a private data area for the driver pointed to by *priv* in struct *ieee80211\_hw*, the size of this area is given as *priv\_data\_len*.

## Return

A pointer to the new hardware device, or NULL on error.

## Name

ieee80211\_register\_hw — Register hardware device

## Synopsis

```
int ieee80211_register_hw (struct ieee80211_hw * hw);
```

## Arguments

*hw* the device to register as returned by `ieee80211_alloc_hw`

## Description

You must call this function before any other functions in `mac80211`. Note that before a hardware can be registered, you need to fill the contained wiphy's information.

## Return

0 on success. An error code otherwise.

## Name

ieee80211\_unregister\_hw — Unregister a hardware device

## Synopsis

```
void ieee80211_unregister_hw (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to unregister

## Description

This function instructs mac80211 to free allocated resources and unregister netdevices from the networking subsystem.



## Name

ieee80211\_free\_hw — free hardware descriptor

## Synopsis

```
void ieee80211_free_hw (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to free

## Description

This function frees everything that was allocated, including the private data for the driver. You must call `ieee80211_unregister_hw` before calling this function.

---

# Chapter 2. PHY configuration

TBD

This chapter should describe PHY handling including start/stop callbacks and the various structures used.

## Name

struct ieee80211\_conf — configuration of the device

## Synopsis

```
struct ieee80211_conf {
    u32 flags;
    int power_level;
    int dynamic_ps_timeout;
    int max_sleep_period;
    u16 listen_interval;
    u8 ps_dtim_period;
    u8 long_frame_max_tx_count;
    u8 short_frame_max_tx_count;
    struct cfg80211_chan_def chandef;
    bool radar_enabled;
    enum ieee80211_smmps_mode smmps_mode;
};
```

## Members

|                          |  |
|--------------------------|--|
| flags                    | configuration flags defined above  |
| power_level              | requested transmit power (in dBm), backward compatibility value only that is set to the minimum of all interfaces  |
| dynamic_ps_timeout       | The dynamic powersave timeout (in ms), see the powersave documentation below. This variable is valid only when the CONF_PS flag is set.  |
| max_sleep_period         | the maximum number of beacon intervals to sleep for before checking the beacon for a TIM bit (managed mode only); this value will be only achievable between DTIM frames, the hardware needs to check for the multicast traffic bit in DTIM beacons. This variable is valid only when the CONF_PS flag is set. |
| listen_interval          | listen interval in units of beacon interval  |
| ps_dtim_period           | The DTIM period of the AP we're connected to, for use in power saving. Power saving will not be enabled until a beacon has been received and the DTIM period is known.   |
| long_frame_max_tx_count  | Maximum number of transmissions for a “long” frame (a frame not RTS protected), called “dot11LongRetryLimit” in 802.11, but actually means the number of transmissions not the number of retries   |
| short_frame_max_tx_count | Maximum number of transmissions for a “short” frame, called “dot11ShortRetryLimit” in 802.11, but actually means the number of transmissions not the number of retries   |
| chandef                  | the channel definition to tune to  |

|               |  |
|---------------|--|
| radar_enabled | whether radar detection is enabled   |
| smgs_mode     | spatial multiplexing powersave mode; note that IEEE80211_SMPS_STATIC is used when the device is not configured for an HT channel. Note that this is only valid if channel contexts are not used, otherwise each channel context has the number of chains listed. |

## Description

This struct indicates how the driver shall configure the hardware.

## Name

enum ieee80211\_conf\_flags — configuration flags

## Synopsis

```
enum ieee80211_conf_flags {  
    IEEE80211_CONF_MONITOR,  
    IEEE80211_CONF_PS,  
    IEEE80211_CONF_IDLE,  
    IEEE80211_CONF_OFFCHANNEL  
};
```

## Constants

|                           |  |
|---------------------------|--|
| IEEE80211_CONF_MONITOR    | there's a monitor interface present -- use this to determine for example whether to calculate timestamps for packets or not, do not use instead of filter flags!   |
| IEEE80211_CONF_PS         | Enable 802.11 power save mode (managed mode only). This is the power save mode defined by IEEE 802.11-2007 section 11.2, meaning that the hardware still wakes up for beacons, is able to transmit frames and receive the possible acknowledgment frames. Not to be confused with hardware specific wakeup/sleep states, driver is responsible for that. See the section “Powersave support” for more. |
| IEEE80211_CONF_IDLE       | The device is running, but idle; if the flag is set the driver should be prepared to handle configuration requests but may turn the device off as much as possible. Typically, this flag will be set when an interface is set UP but not associated or scanning, but it can also be unset in that case when monitor interfaces are active.   |
| IEEE80211_CONF_OFFCHANNEL | The device is currently not on its main operating channel.   |

## Description

Flags to define PHY configuration options

---

# Chapter 3. Virtual interfaces

TBD

This chapter should describe virtual interface basics that are relevant to the driver (VLANs, MGMT etc are not.) It should explain the use of the `add_iface/remove_iface` callbacks as well as the interface configuration callbacks.

Things related to AP mode should be discussed there.

Things related to supporting multiple interfaces should be in the appropriate chapter, a BIG FAT note should be here about this though and the recommendation to allow only a single interface in STA mode at first!

## Name

struct ieee80211\_vif — per-interface data

## Synopsis

```
struct ieee80211_vif {
    enum nl80211_iftype type;
    struct ieee80211_bss_conf bss_conf;
    u8 addr[ETH_ALEN];
    bool p2p;
    bool csa_active;
    u8 cab_queue;
    u8 hw_queue[IEEE80211_NUM_ACS];
    struct ieee80211_txq * txq;
    struct ieee80211_chanctx_conf __rcu * chanctx_conf;
    u32 driver_flags;
#ifdef CONFIG_MAC80211_DEBUGFS
    struct dentry * debugfs_dir;
#endif
    u8 drv_priv[0];
};
```

## Members

|                             |  |
|-----------------------------|--|
| type                        | type of this virtual interface   |
| bss_conf                    | BSS configuration for this interface, either our own or the BSS we're associated to  |
| addr[ETH_ALEN]              | address of this interface  |
| p2p                         | indicates whether this AP or STA interface is a p2p interface, i.e. a GO or p2p-sta respectively   |
| csa_active                  | marks whether a channel switch is going on. Internally it is write-protected by sdata_lock and local->mtx so holding either is fine for read access.   |
| cab_queue                   | content-after-beacon (DTIM beacon really) queue, AP mode only  |
| hw_queue[IEEE80211_NUM_ACS] | hardware queue for each AC   |
| txq                         | the multicast data TX queue (if driver uses the TXQ abstraction)   |
| chanctx_conf                | The channel context this interface is assigned to, or NULL when it is not assigned. This pointer is RCU-protected due to the TX path needing to access it; even though the netdev carrier will always be off when it is NULL there can still be races and packets could be processed after it switches back to NULL. |
| driver_flags                | flags/capabilities the driver has for this interface, these need to be set (or cleared) when the interface is added or, if supported by  |

|             |   |
|-------------|---|
|             | the driver, the interface type is changed at runtime, mac80211 will never touch this field  |
| debugfs_dir | debugfs dentry, can be used by drivers to create own per interface debug files. Note that it will be NULL for the virtual monitor interface (if that is requested.) |
| drv_priv[0] | data area for driver use, will always be aligned to sizeof(void *).   |

## Description

Data in this structure is continually present for driver use during the life of a virtual interface.



---

# Chapter 4. Receive and transmit processing

## what should be here

TBD

This should describe the receive and transmit paths in mac80211/the drivers as well as transmit status handling.

## Frame format

As a general rule, when frames are passed between mac80211 and the driver, they start with the IEEE 802.11 header and include the same octets that are sent over the air except for the FCS which should be calculated by the hardware.

There are, however, various exceptions to this rule for advanced features:

The first exception is for hardware encryption and decryption offload where the IV/ICV may or may not be generated in hardware.

Secondly, when the hardware handles fragmentation, the frame handed to the driver from mac80211 is the MSDU, not the MPDU.

## Packet alignment

Drivers always need to pass packets that are aligned to two-byte boundaries to the stack.

Additionally, should, if possible, align the payload data in a way that guarantees that the contained IP header is aligned to a four-byte boundary. In the case of regular frames, this simply means aligning the payload to a four-byte boundary (because either the IP header is directly contained, or IV/RFC1042 headers that have a length divisible by four are in front of it). If the payload data is not properly aligned and the architecture doesn't support efficient unaligned operations, mac80211 will align the data.

With A-MSDU frames, however, the payload data address must yield two modulo four because there are 14-byte 802.3 headers within the A-MSDU frames that push the IP header further back to a multiple of four again. Thankfully, the specs were sane enough this time around to require padding each A-MSDU subframe to a length that is a multiple of four.

Padding like Atheros hardware adds which is between the 802.11 header and the payload is not supported, the driver is required to move the 802.11 header to be directly in front of the payload in that case.

## Calling into mac80211 from interrupts

Only `ieee80211_tx_status_irqsafe` and `ieee80211_rx_irqsafe` can be called in hardware interrupt context. The low-level driver must not call any other functions in hardware interrupt

context. If there is a need for such call, the low-level driver should first ACK the interrupt and perform the IEEE 802.11 code call after this, e.g. from a scheduled workqueue or even tasklet function.

NOTE: If the driver opts to use the `_irqsafe` functions, it may not also use the non-IRQ-safe functions!

## **functions/definitions**

## Name

struct ieee80211\_rx\_status — receive status

## Synopsis

```
struct ieee80211_rx_status {
    u64 mactime;
    u32 device_timestamp;
    u32 ampdu_reference;
    u32 flag;
    u16 freq;
    u8 vht_flag;
    u8 rate_idx;
    u8 vht_nss;
    u8 rx_flags;
    u8 band;
    u8 antenna;
    s8 signal;
    u8 chains;
    s8 chain_signal[IEEE80211_MAX_CHAINS];
    u8 ampdu_delimiter_crc;
};
```

## Members

|                  |  |
|------------------|--|
| mactime          | value in microseconds of the 64-bit Time Synchronization Function (TSF) timer when the first data symbol (MPDU) arrived at the hardware.                       |
| device_timestamp | arbitrary timestamp for the device, mac80211 doesn't use it but can store it and pass it back to the driver for synchronisation                                |
| ampdu_reference  | A-MPDU reference number, must be a different value for each A-MPDU but the same for each subframe within one A-MPDU  |
| flag             | <code>RX_FLAG_*</code>   |
| freq             | frequency the radio was tuned to when receiving this frame, in MHz   |
| vht_flag         | <code>RX_VHT_FLAG_*</code>   |
| rate_idx         | index of data rate into band's supported rates or MCS index if HT or VHT is used ( <code>RX_FLAG_HT/RX_FLAG_VHT</code> )                                       |
| vht_nss          | number of streams (VHT only)   |
| rx_flags         | internal RX flags for mac80211   |
| band             | the active band when this frame was received   |
| antenna          | antenna used   |
| signal           | signal strength when receiving this frame, either in dBm, in dB or unspecified depending on the hardware capabilities flags <code>IEEE80211_HW_SIGNAL_*</code> |

|   |  |
|---|--|
| <code>chains</code>                             | bitmask of receive chains for which separate signal strength values were filled.               |
| <code>chain_signal[IEEE80211_MAX_CHAINS]</code> | chain signal strength, in dBm (unlike <i>signal</i> , doesn't support dB or unspecified units) |
| <code>ampdu_delimiter_crc</code>                | A-MPDU delimiter CRC   |

## Description

The low-level driver should provide this information (the subset supported by hardware) to the 802.11 code with each received frame, in the skb's control buffer (cb).

## Name

enum mac80211\_rx\_flags — receive flags

## Synopsis

```
enum mac80211_rx_flags {
    RX_FLAG_MMIC_ERROR,
    RX_FLAG_DECRYPTED,
    RX_FLAG_MMIC_STRIPPED,
    RX_FLAG_IV_STRIPPED,
    RX_FLAG_FAILED_FCS_CRC,
    RX_FLAG_FAILED_PLCP_CRC,
    RX_FLAG_MACTIME_START,
    RX_FLAG_SHORTPRE,
    RX_FLAG_HT,
    RX_FLAG_40MHZ,
    RX_FLAG_SHORT_GI,
    RX_FLAG_NO_SIGNAL_VAL,
    RX_FLAG_HT_GF,
    RX_FLAG_AMPDU_DETAILS,
    RX_FLAG_AMPDU_REPORT_ZEROLEN,
    RX_FLAG_AMPDU_IS_ZEROLEN,
    RX_FLAG_AMPDU_LAST_KNOWN,
    RX_FLAG_AMPDU_IS_LAST,
    RX_FLAG_AMPDU_DELIM_CRC_ERROR,
    RX_FLAG_AMPDU_DELIM_CRC_KNOWN,
    RX_FLAG_MACTIME_END,
    RX_FLAG_VHT,
    RX_FLAG_LDPC,
    RX_FLAG_STBC_MASK,
    RX_FLAG_10MHZ,
    RX_FLAG_5MHZ,
    RX_FLAG_AMSDU_MORE,
    RX_FLAG_RADIOTAP_VENDOR_DATA
};
```

## Constants

|                                      |   |
|--------------------------------------|---|
| <code>RX_FLAG_MMIC_ERROR</code>      | Michael MIC error was reported on this frame. Use together with <code>RX_FLAG_MMIC_STRIPPED</code> .  |
| <code>RX_FLAG_DECRYPTED</code>       | This frame was decrypted in hardware.   |
| <code>RX_FLAG_MMIC_STRIPPED</code>   | the Michael MIC is stripped off this frame, verification has been done by the hardware.   |
| <code>RX_FLAG_IV_STRIPPED</code>     | The IV/ICV are stripped from this frame. If this flag is set, the stack cannot do any replay detection hence the driver or hardware will have to do that. |
| <code>RX_FLAG_FAILED_FCS_CRC</code>  | Set this flag if the FCS check failed on the frame.   |
| <code>RX_FLAG_FAILED_PLCP_CRC</code> | Set this flag if the PCLP check failed on the frame.  |

|                               |  |
|-------------------------------|--|
| RX_FLAG_MACTIME_START         | The timestamp passed in the RX status ( <i>mactime</i> field) is valid and contains the time the first symbol of the MPDU was received. This is useful in monitor mode and for proper IBSS merging.  |
| RX_FLAG_SHORTPRE              | Short preamble was used for this frame   |
| RX_FLAG_HT                    | HT MCS was used and <i>rate_idx</i> is MCS index   |
| RX_FLAG_40MHZ                 | HT40 (40 MHz) was used   |
| RX_FLAG_SHORT_GI              | Short guard interval was used  |
| RX_FLAG_NO_SIGNAL_VAL         | The signal strength value is not present. Valid only for data frames (mainly A-MPDU)   |
| RX_FLAG_HT_GF                 | This frame was received in a HT-greenfield transmission, if the driver fills this value it should add <code>IEEE80211_RADIOTAP_MCS_HAVE_FMT</code> to <code>hw.radiotap_mcs_details</code> to advertise that fact  |
| RX_FLAG_AMPDU_DETAILS         | A-MPDU details are known, in particular the reference number ( <i>ampdu_reference</i> ) must be populated and be a distinct number for each A-MPDU   |
| RX_FLAG_AMPDU_REPORT_ZEROLEN  | Driver reports 0-length subframes  |
| RX_FLAG_AMPDU_IS_ZEROLEN      | This is a zero-length subframe, for monitoring purposes only   |
| RX_FLAG_AMPDU_LAST_KNOWN      | Last subframe is known, should be set on all subframes of a single A-MPDU  |
| RX_FLAG_AMPDU_IS_LAST         | this subframe is the last subframe of the A-MPDU   |
| RX_FLAG_AMPDU_DELIM_CRC_ERROR | Delimiter CRC error has been detected on this subframe   |
| RX_FLAG_AMPDU_DELIM_CRC_KNOWN | Delimiter CRC field is known (the CRC is stored in the <i>ampdu_delimiter_crc</i> field)   |
| RX_FLAG_MACTIME_END           | The timestamp passed in the RX status ( <i>mactime</i> field) is valid and contains the time the last symbol of the MPDU (including FCS) was received.   |
| RX_FLAG_VHT                   | VHT MCS was used and <i>rate_index</i> is MCS index  |
| RX_FLAG_LDPC                  | LDPC was used  |
| RX_FLAG_STBC_MASK             | STBC 2 bit bitmask. 1 - Nss=1, 2 - Nss=2, 3 - Nss=3  |
| RX_FLAG_10MHZ                 | 10 MHz (half channel) was used   |
| RX_FLAG_5MHZ                  | 5 MHz (quarter channel) was used   |
| RX_FLAG_AMSDU_MORE            | Some drivers may prefer to report separate A-MSDU subframes instead of a one huge frame for performance reasons. All, but the last MSDU from an A-MSDU should have this flag set. E.g. if an A-MSDU has 3 frames, the first 2 must have the flag set, while the 3rd (last) one must not have this flag set. The flag is used to deal |

with retransmission/duplication recovery properly since A-MSDU subframes share the same sequence number. Reported subframes can be either regular MSDU or singly A-MSDUs. Subframes must not be interleaved with other frames.

RX\_FLAG\_RADIOTAP\_VENDOR\_DATA A frame contains vendor-specific radiotap data in the `skb->data` (before the frame) as described by the struct `ieee80211_vendor_radiotap`.

## Description

These flags are used with the *flag* member of struct `ieee80211_rx_status`.

## Name

enum mac80211\_tx\_info\_flags — flags to describe transmission information/status

## Synopsis

```
enum mac80211_tx_info_flags {
    IEEE80211_TX_CTL_REQ_TX_STATUS,
    IEEE80211_TX_CTL_ASSIGN_SEQ,
    IEEE80211_TX_CTL_NO_ACK,
    IEEE80211_TX_CTL_CLEAR_PS_FILT,
    IEEE80211_TX_CTL_FIRST_FRAGMENT,
    IEEE80211_TX_CTL_SEND_AFTER_DTIM,
    IEEE80211_TX_CTL_AMPDU,
    IEEE80211_TX_CTL_INJECTED,
    IEEE80211_TX_STAT_TX_FILTERED,
    IEEE80211_TX_STAT_ACK,
    IEEE80211_TX_STAT_AMPDU,
    IEEE80211_TX_STAT_AMPDU_NO_BACK,
    IEEE80211_TX_CTL_RATE_CTRL_PROBE,
    IEEE80211_TX_INTFL_OFFCHAN_TX_OK,
    IEEE80211_TX_INTFL_NEED_TXPROCESSING,
    IEEE80211_TX_INTFL_RETRIED,
    IEEE80211_TX_INTFL_DONT_ENCRYPT,
    IEEE80211_TX_CTL_NO_PS_BUFFER,
    IEEE80211_TX_CTL_MORE_FRAMES,
    IEEE80211_TX_INTFL_RETRANSMISSION,
    IEEE80211_TX_INTFL_MLME_CONN_TX,
    IEEE80211_TX_INTFL_NL80211_FRAME_TX,
    IEEE80211_TX_CTL_LDPC,
    IEEE80211_TX_CTL_STBC,
    IEEE80211_TX_CTL_TX_OFFCHAN,
    IEEE80211_TX_INTFL_TKIP_MIC_FAILURE,
    IEEE80211_TX_CTL_NO_CCK_RATE,
    IEEE80211_TX_STATUS_EOSP,
    IEEE80211_TX_CTL_USE_MINRATE,
    IEEE80211_TX_CTL_DONTFRAG,
    IEEE80211_TX_STAT_NOACK_TRANSMITTED
};
```

## Constants

**IEEE80211\_TX\_CTL\_REQ\_TX\_STATUS** This is TX status callback for this frame.

**IEEE80211\_TX\_CTL\_ASSIGN\_SEQ** The driver has to assign a sequence number to this frame, taking care of not overwriting the fragment number and increasing the sequence number only when the **IEEE80211\_TX\_CTL\_FIRST\_FRAGMENT** flag is set. **mac80211** will properly assign sequence numbers to QoS-data frames but cannot do so correctly for non-QoS-data and management frames because beacons need them from that counter as well and **mac80211** cannot guarantee proper sequencing. If this flag is set, the driver should instruct the hardware to assign a sequence number to



the frame or assign one itself. Cf. IEEE 802.11-2007 7.1.3.4.1 paragraph 3. This flag will always be set for beacons and always be clear for frames without a sequence number field.

|                                      |   |
|--------------------------------------|---|
| IEEE80211_TX_CTL_NO_ACK              | tell the low level not to wait for an ack   |
| IEEE80211_TX_CTL_CLEAR_PS_FILTER     | clear powersave filter for destination station  |
| IEEE80211_TX_CTL_FIRST_FRAGMENT      | is a first fragment of the frame  |
| IEEE80211_TX_CTL_SEND_AFTER_DTIM     | send this frame after DTIM beacon   |
| IEEE80211_TX_CTL_AMPDU               | this frame should be sent as part of an A-MPDU  |
| IEEE80211_TX_CTL_INJECTED            | Frame was injected, internal to mac80211.   |
| IEEE80211_TX_STAT_TX_FILTERED        | The frame was not transmitted because the destination STA was in powersave mode. Note that to avoid race conditions, the filter must be set by the hardware or firmware upon receiving a frame that indicates that the station went to sleep (must be done on device to filter frames already on the queue) and may only be unset after mac80211 gives the OK for that by setting the IEEE80211_TX_CTL_CLEAR_PS_FILTER (see above), since only then is it guaranteed that no more frames are in the hardware queue. |
| IEEE80211_TX_STAT_ACK                | Frame was acknowledged  |
| IEEE80211_TX_STAT_AMPDU              | The frame was aggregated, so status is for the whole aggregation.   |
| IEEE80211_TX_STAT_AMPDU_NO_BACK      | Block ack was returned, so consider using block ack request (BAR).  |
| IEEE80211_TX_CTL_RATE_CTRL_PROBE     | Internal to mac80211, can be set by rate control algorithms to indicate probe rate, will be cleared for fragmented frames (except on the last fragment)   |
| IEEE80211_TX_INTFL_OFFCHAN_OK        | Internal to mac80211. Used to indicate that a frame can be transmitted while the queues are stopped for off-channel operation.  |
| IEEE80211_TX_INTFL_NEED_TXPROCESSING | Internal to mac80211, used to indicate that a pending frame requires TX processing before it can be sent out.   |
| IEEE80211_TX_INTFL_RETRIED           | completely internal to mac80211, used to indicate that a frame was already retried due to PS  |
| IEEE80211_TX_INTFL_DONT_ENCRYPT      | completely internal to mac80211, used to indicate frame should not be encrypted   |
| IEEE80211_TX_CTL_NO_PS_BUFFER        | This frame is a response to a poll frame (PS-Poll or uAPSD) or a non-bufferable MMPDU and must be sent although the station is in powersave mode.   |
| IEEE80211_TX_CTL_MORE_FRAMES         | More frames will be passed to the transmit function after the current frame, this can be used by drivers to kick the DMA queue only if unset or when the queue gets full.   |

|                                     |   |
|-------------------------------------|---|
| IEEE80211_TX_INTFL_RETRANSMISSION   | This frame is being retransmitted after TX status because the destination was asleep, it must not be modified again (no seqno assignment, crypto, etc.)   |
| IEEE80211_TX_INTFL_MLME_CONNECTED   | This frame was transmitted by the MLME code for connection establishment, this indicates that its status should kick the MLME state machine.  |
| IEEE80211_TX_INTFL_NL80211_FRAME_TX | Frame was requested through nl80211 MLME command (internal to mac80211 to figure out whether to send TX status to user space)   |
| IEEE80211_TX_CTL_LDPC               | tells the driver to use LDPC for this frame   |
| IEEE80211_TX_CTL_STBC               | Enables Space-Time Block Coding (STBC) for this frame and selects the maximum number of streams that it can use.  |
| IEEE80211_TX_CTL_TX_OFFCHANNEL      | Marks this packet to be transmitted on the off-channel channel when a remain-on-channel offload is done in hardware -- normal packets still flow and are expected to be handled properly by the device.   |
| IEEE80211_TX_INTFL_TKIP_MIC_FAILURE | Marks this packet to be used for TKIP testing. It will be sent out with incorrect Michael MIC key to allow TKIP countermeasures to be tested.   |
| IEEE80211_TX_CTL_NO_CCK_RATE        | This frame will be sent at non CCK rate. This flag is actually used for management frame especially for P2P frames not being sent at CCK rate in 2GHz band.   |
| IEEE80211_TX_STATUS_EOSP            | This packet marks the end of service period, when its status is reported the service period ends. For frames in an SP that mac80211 transmits, it is already set; for driver frames the driver may set this flag. It is also used to do the same for PS-Poll responses. |
| IEEE80211_TX_CTL_USE_MINRATE        | This frame will be sent at lowest rate. This flag is used to send nullfunc frame at minimum rate when the nullfunc is used for connection monitoring purpose.   |
| IEEE80211_TX_CTL_DONTFRAG           | Don't fragment this packet even if it would be fragmented by size (this is optional, only used for monitor injection).  |
| IEEE80211_TX_STAT_NOACK_TRANSMITTED | This frame was marked with IEEE80211_TX_CTL_NO_ACK and has been successfully transmitted without any errors (like issues specific to the driver/HW). This flag must not be set for frames that don't request no-ack behaviour with IEEE80211_TX_CTL_NO_ACK.             |

## Description

These flags are used with the *flags* member of *ieee80211\_tx\_info*.

## Note

If you have to add new flags to the enumeration, then don't forget to update `IEEE80211_TX_TEMPORARY_FLAGS` when necessary.

## Name

enum mac80211\_tx\_control\_flags — flags to describe transmit control

## Synopsis

```
enum mac80211_tx_control_flags {  
    IEEE80211_TX_CTRL_PORT_CTRL_PROTO,  
    IEEE80211_TX_CTRL_PS_RESPONSE  
};
```

## Constants

IEEE80211\_TX\_CTRL\_PORT\_CTRL\_PROTO is a port control protocol frame (e.g. EAP)

IEEE80211\_TX\_CTRL\_PS\_RESPONSE is a response to a poll frame (PS-Poll or uAPSD).

## Description

These flags are used in tx\_info->control.flags.

## Name

enum mac80211\_rate\_control\_flags — per-rate flags set by the Rate Control algorithm.

## Synopsis

```
enum mac80211_rate_control_flags {
    IEEE80211_TX_RC_USE_RTS_CTS,
    IEEE80211_TX_RC_USE_CTS_PROTECT,
    IEEE80211_TX_RC_USE_SHORT_PREAMBLE,
    IEEE80211_TX_RC_MCS,
    IEEE80211_TX_RC_GREEN_FIELD,
    IEEE80211_TX_RC_40_MHZ_WIDTH,
    IEEE80211_TX_RC_DUP_DATA,
    IEEE80211_TX_RC_SHORT_GI,
    IEEE80211_TX_RC_VHT_MCS,
    IEEE80211_TX_RC_80_MHZ_WIDTH,
    IEEE80211_TX_RC_160_MHZ_WIDTH
};
```

## Constants

IEEE80211\_TX\_RC\_USE\_RTS\_CTS Use RTS/CTS exchange for this rate.

IEEE80211\_TX\_RC\_USE\_CTS\_PROTECT To-self protection is required. This is set if the current BSS requires ERP protection.

IEEE80211\_TX\_RC\_USE\_SHORT\_PREAMBLE Short preamble.

IEEE80211\_TX\_RC\_MCS HT rate.

IEEE80211\_TX\_RC\_GREEN\_FIELD Indicates whether this rate should be used in Greenfield mode.

IEEE80211\_TX\_RC\_40\_MHZ\_WIDTH Indicates if the Channel Width should be 40 MHz.

IEEE80211\_TX\_RC\_DUP\_DATA The frame should be transmitted on both of the adjacent 20 MHz channels, if the current channel type is NL80211\_CHAN\_HT40MINUS or NL80211\_CHAN\_HT40PLUS.

IEEE80211\_TX\_RC\_SHORT\_GI Short Guard interval should be used for this rate.

IEEE80211\_TX\_RC\_VHT\_MCS VHT MCS rate, in this case the idx field is split into a higher 4 bits (Nss) and lower 4 bits (MCS number)

IEEE80211\_TX\_RC\_80\_MHZ\_WIDTH Indicates 80 MHz transmission

IEEE80211\_TX\_RC\_160\_MHZ\_WIDTH Indicates 160 MHz transmission (80+80 isn't supported yet)

## Description

These flags are set by the Rate control algorithm for each rate during tx, in the *flags* member of struct `ieee80211_tx_rate`.

## Name

struct ieee80211\_tx\_rate — rate selection/status

## Synopsis

```
struct ieee80211_tx_rate {
    s8 idx;
    u16 count:5;
    u16 flags:11;
};
```

## Members

|       |  |
|-------|--|
| idx   | rate index to attempt to send with                         |
| count | number of tries in this rate before going to the next rate |
| flags | rate control flags (enum mac80211_rate_control_flags)      |

## Description

A value of -1 for *idx* indicates an invalid rate and, if used in an array of retry rates, that no more rates should be tried.

When used for transmit status reporting, the driver should always report the rate along with the flags it used.

struct ieee80211\_tx\_info contains an array of these structs in the control information, and it will be filled by the rate control algorithm according to what should be sent. For example, if this array contains, in the format { <idx>, <count> } the information { 3, 2 }, { 2, 2 }, { 1, 4 }, { -1, 0 }, { -1, 0 } then this means that the frame should be transmitted up to twice at rate 3, up to twice at rate 2, and up to four times at rate 1 if it doesn't get acknowledged. Say it gets acknowledged by the peer after the fifth attempt, the status information should then contain { 3, 2 }, { 2, 2 }, { 1, 1 }, { -1, 0 } ... since it was transmitted twice at rate 3, twice at rate 2 and once at rate 1 after which we received an acknowledgement.

## Name

struct ieee80211\_tx\_info — skb transmit information

## Synopsis

```
struct ieee80211_tx_info {  
    u32 flags;  
    u8 band;  
    u8 hw_queue;  
    u16 ack_frame_id;  
    union {unnamed_union};  
};
```

## Members

|                 |   |
|-----------------|---|
| flags           | transmit info flags, defined above  |
| band            | the band to transmit on (use for checking for races)                          |
| hw_queue        | HW queue to put the frame on, <code>skb_get_queue_mapping</code> gives the AC |
| ack_frame_id    | internal frame ID for TX status, used internally                              |
| {unnamed_union} | anonymous   |

## Description

This structure is placed in `skb->cb` for three uses: (1) mac80211 TX control - mac80211 tells the driver what to do (2) driver internal use (if applicable) (3) TX status information - driver tells mac80211 what happened

## Name

ieee80211\_tx\_info\_clear\_status — clear TX status

## Synopsis

```
void ieee80211_tx_info_clear_status (struct ieee80211_tx_info * info);
```

## Arguments

*info* The struct ieee80211\_tx\_info to be cleared.

## Description

When the driver passes an skb back to mac80211, it must report a number of things in TX status. This function clears everything in the TX status but the rate control information (it does clear the count since you need to fill that in anyway).

## NOTE

You can only use this function if you do NOT use info->driver\_data! Use info->rate\_driver\_data instead if you need only the less space that allows.

## Name

ieee80211\_rx — receive frame

## Synopsis

```
void ieee80211_rx (struct ieee80211_hw * hw, struct sk_buff * skb);
```

## Arguments

*hw*    the hardware this frame came in on

*skb*   the buffer to receive, owned by mac80211 after this call

## Description

Use this function to hand received frames to mac80211. The receive buffer in *skb* must start with an IEEE 802.11 header. In case of a paged *skb* is used, the driver is recommended to put the ieee80211 header of the frame on the linear part of the *skb* to avoid memory allocation and/or memcpy by the stack.

This function may not be called in IRQ context. Calls to this function for a single hardware must be synchronized against each other. Calls to this function, `ieee80211_rx_ni` and `ieee80211_rx_irqsafe` may not be mixed for a single hardware. Must not run concurrently with `ieee80211_tx_status` or `ieee80211_tx_status_ni`.

In process context use instead `ieee80211_rx_ni`.



## Name

`ieee80211_rx_ni` — receive frame (in process context)

## Synopsis

```
void ieee80211_rx_ni (struct ieee80211_hw * hw, struct sk_buff * skb);
```

## Arguments

*hw*    the hardware this frame came in on

*skb*   the buffer to receive, owned by `mac80211` after this call

## Description

Like `ieee80211_rx` but can be called in process context (internally disables bottom halves).

Calls to this function, `ieee80211_rx` and `ieee80211_rx_irqsafe` may not be mixed for a single hardware. Must not run concurrently with `ieee80211_tx_status` or `ieee80211_tx_status_ni`.

## Name

ieee80211\_rx\_irqsafe — receive frame

## Synopsis

```
void ieee80211_rx_irqsafe (struct ieee80211_hw * hw, struct sk_buff *  
skb);
```

## Arguments

*hw*    the hardware this frame came in on

*skb*   the buffer to receive, owned by mac80211 after this call

## Description

Like `ieee80211_rx` but can be called in IRQ context (internally defers to a tasklet.)

Calls to this function, `ieee80211_rx` or `ieee80211_rx_ni` may not be mixed for a single hardware. Must not run concurrently with `ieee80211_tx_status` or `ieee80211_tx_status_ni`.

## Name

ieee80211\_tx\_status — transmit status callback

## Synopsis

```
void ieee80211_tx_status (struct ieee80211_hw * hw, struct sk_buff *  
skb);
```

## Arguments

*hw*    the hardware the frame was transmitted by

*skb*   the frame that was transmitted, owned by mac80211 after this call

## Description

Call this function for all transmitted frames after they have been transmitted. It is permissible to not call this function for multicast frames but this can affect statistics.

This function may not be called in IRQ context. Calls to this function for a single hardware must be synchronized against each other. Calls to this function, `ieee80211_tx_status_ni` and `ieee80211_tx_status_irqsafe` may not be mixed for a single hardware. Must not run concurrently with `ieee80211_rx` or `ieee80211_rx_ni`.

## Name

ieee80211\_tx\_status\_ni — transmit status callback (in process context)

## Synopsis

```
void ieee80211_tx_status_ni (struct ieee80211_hw * hw, struct sk_buff
* skb);
```

## Arguments

*hw* the hardware the frame was transmitted by

*skb* the frame that was transmitted, owned by mac80211 after this call

## Description

Like `ieee80211_tx_status` but can be called in process context.

Calls to this function, `ieee80211_tx_status` and `ieee80211_tx_status_irqsafe` may not be mixed for a single hardware.

## Name

ieee80211\_tx\_status\_irqsafe — IRQ-safe transmit status callback

## Synopsis

```
void ieee80211_tx_status_irqsafe (struct ieee80211_hw * hw, struct
sk_buff * skb);
```

## Arguments

*hw* the hardware the frame was transmitted by

*skb* the frame that was transmitted, owned by mac80211 after this call

## Description

Like `ieee80211_tx_status` but can be called in IRQ context (internally defers to a tasklet.)

Calls to this function, `ieee80211_tx_status` and `ieee80211_tx_status_ni` may not be mixed for a single hardware.

## Name

ieee80211\_rts\_get — RTS frame generation function

## Synopsis

```
void ieee80211_rts_get (struct ieee80211_hw * hw, struct ieee80211_vif *  
vif, const void * frame, size_t frame_len, const struct ieee80211_tx_info  
* frame_txctl, struct ieee80211_rts * rts);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>hw</i>          | pointer obtained from <code>ieee80211_alloc_hw</code> .                                 |
| <i>vif</i>         | struct <code>ieee80211_vif</code> pointer from the <code>add_interface</code> callback. |
| <i>frame</i>       | pointer to the frame that is going to be protected by the RTS.                          |
| <i>frame_len</i>   | the frame length (in octets).   |
| <i>frame_txctl</i> | struct <code>ieee80211_tx_info</code> of the frame.                                     |
| <i>rts</i>         | The buffer where to store the RTS frame.  |

## Description

If the RTS frames are generated by the host system (i.e., not in hardware/firmware), the low-level driver uses this function to receive the next RTS frame from the 802.11 code. The low-level is responsible for calling this function before and RTS frame is needed.

## Name

ieee80211\_rts\_duration — Get the duration field for an RTS frame

## Synopsis

```
__le16 ieee80211_rts_duration (struct ieee80211_hw * hw, struct
ieee80211_vif * vif, size_t frame_len, const struct ieee80211_tx_info
* frame_txctl);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>hw</i>          | pointer obtained from <code>ieee80211_alloc_hw</code> .                                 |
| <i>vif</i>         | struct <code>ieee80211_vif</code> pointer from the <code>add_interface</code> callback. |
| <i>frame_len</i>   | the length of the frame that is going to be protected by the RTS.                       |
| <i>frame_txctl</i> | struct <code>ieee80211_tx_info</code> of the frame.                                     |

## Description

If the RTS is generated in firmware, but the host system must provide the duration field, the low-level driver uses this function to receive the duration field value in little-endian byteorder.

## Return

The duration.

## Name

ieee80211\_ctstoself\_get — CTS-to-self frame generation function

## Synopsis

```
void ieee80211_ctstoself_get (struct ieee80211_hw * hw, struct
ieee80211_vif * vif, const void * frame, size_t frame_len, const struct
ieee80211_tx_info * frame_txctl, struct ieee80211_cts * cts);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>hw</i>          | pointer obtained from <code>ieee80211_alloc_hw</code> .                                 |
| <i>vif</i>         | struct <code>ieee80211_vif</code> pointer from the <code>add_interface</code> callback. |
| <i>frame</i>       | pointer to the frame that is going to be protected by the CTS-to-self.                  |
| <i>frame_len</i>   | the frame length (in octets).   |
| <i>frame_txctl</i> | struct <code>ieee80211_tx_info</code> of the frame.                                     |
| <i>cts</i>         | The buffer where to store the CTS-to-self frame.  |

## Description

If the CTS-to-self frames are generated by the host system (i.e., not in hardware/firmware), the low-level driver uses this function to receive the next CTS-to-self frame from the 802.11 code. The low-level is responsible for calling this function before and CTS-to-self frame is needed.



## Name

ieee80211\_ctstoself\_duration — Get the duration field for a CTS-to-self frame

## Synopsis

```
__le16 ieee80211_ctstoself_duration (struct ieee80211_hw * hw, struct
ieee80211_vif * vif, size_t frame_len, const struct ieee80211_tx_info
* frame_txctl);
```

## Arguments

|                    |   |
|--------------------|---|
| <i>hw</i>          | pointer obtained from ieee80211_alloc_hw.                                 |
| <i>vif</i>         | struct ieee80211_vif pointer from the add_interface callback.             |
| <i>frame_len</i>   | the length of the frame that is going to be protected by the CTS-to-self. |
| <i>frame_txctl</i> | struct ieee80211_tx_info of the frame.                                    |

## Description

If the CTS-to-self is generated in firmware, but the host system must provide the duration field, the low-level driver uses this function to receive the duration field value in little-endian byteorder.

## Return

The duration.

## Name

ieee80211\_generic\_frame\_duration — Calculate the duration field for a frame

## Synopsis

```
__le16 ieee80211_generic_frame_duration (struct ieee80211_hw * hw,  
struct ieee80211_vif * vif, enum ieee80211_band band, size_t frame_len,  
struct ieee80211_rate * rate);
```

## Arguments

|                  |   |
|------------------|---|
| <i>hw</i>        | pointer obtained from ieee80211_alloc_hw.                     |
| <i>vif</i>       | struct ieee80211_vif pointer from the add_interface callback. |
| <i>band</i>      | the band to calculate the frame duration on                   |
| <i>frame_len</i> | the length of the frame.                                      |
| <i>rate</i>      | the rate at which the frame is going to be transmitted.       |

## Description

Calculate the duration field of some generic frame, given its length and transmission rate (in 100kbps).

## Return

The duration.

## Name

ieee80211\_wake\_queue — wake specific queue

## Synopsis

```
void ieee80211_wake_queue (struct ieee80211_hw * hw, int queue);
```

## Arguments

*hw* pointer as obtained from ieee80211\_alloc\_hw.

*queue* queue number (counted from zero).

## Description

Drivers should use this function instead of netif\_wake\_queue.

## Name

ieee80211\_stop\_queue — stop specific queue

## Synopsis

```
void ieee80211_stop_queue (struct ieee80211_hw * hw, int queue);
```

## Arguments

*hw* pointer as obtained from ieee80211\_alloc\_hw.

*queue* queue number (counted from zero).

## Description

Drivers should use this function instead of netif\_stop\_queue.

## Name

ieee80211\_wake\_queues — wake all queues

## Synopsis

```
void ieee80211_wake_queues (struct ieee80211_hw * hw);
```

## Arguments

*hw* pointer as obtained from ieee80211\_alloc\_hw.

## Description

Drivers should use this function instead of netif\_wake\_queue.

## Name

ieee80211\_stop\_queues — stop all queues

## Synopsis

```
void ieee80211_stop_queues (struct ieee80211_hw * hw);
```

## Arguments

*hw* pointer as obtained from ieee80211\_alloc\_hw.

## Description

Drivers should use this function instead of netif\_stop\_queue.

## Name

ieee80211\_queue\_stopped — test status of the queue

## Synopsis

```
int ieee80211_queue_stopped (struct ieee80211_hw * hw, int queue);
```

## Arguments

*hw* pointer as obtained from ieee80211\_alloc\_hw.

*queue* queue number (counted from zero).

## Description

Drivers should use this function instead of netif\_stop\_queue.

## Return

true if the queue is stopped. false otherwise.

---

# Chapter 5. Frame filtering

mac80211 requires to see many management frames for proper operation, and users may want to see many more frames when in monitor mode. However, for best CPU usage and power consumption, having as few frames as possible percolate through the stack is desirable. Hence, the hardware should filter as much as possible.

To achieve this, mac80211 uses filter flags (see below) to tell the driver's `configure_filter` function which frames should be passed to mac80211 and which should be filtered out.

Before `configure_filter` is invoked, the `prepare_multicast` callback is invoked with the parameters `mc_count` and `mc_list` for the combined multicast address list of all virtual interfaces. Its use is optional, and it returns a u64 that is passed to `configure_filter`. Additionally, `configure_filter` has the arguments `changed_flags` telling which flags were changed and `total_flags` with the new flag states.

If your device has no multicast address filters your driver will need to check both the `FIF_ALLMULTI` flag and the `mc_count` parameter to see whether multicast frames should be accepted or dropped.

All unsupported flags in `total_flags` must be cleared. Hardware does not support a flag if it is incapable of `_passing_` the frame to the stack. Otherwise the driver must ignore the flag, but not clear it. You must `_only_` clear the flag (announce no support for the flag to mac80211) if you are not able to pass the packet type to the stack (so the hardware always filters it). So for example, you should clear `FIF_CONTROL`, if your hardware always filters control frames. If your hardware always passes control frames to the kernel and is incapable of filtering them, you do `_not_` clear the `FIF_CONTROL` flag. This rule applies to all other FIF flags as well.



## Name

enum ieee80211\_filter\_flags — hardware filter flags

## Synopsis

```
enum ieee80211_filter_flags {  
    FIF_PROMISC_IN_BSS,  
    FIF_ALLMULTI,  
    FIF_FCSFAIL,  
    FIF_PLCPFAIL,  
    FIF_BCN_PRBRESP_PROMISC,  
    FIF_CONTROL,  
    FIF_OTHER_BSS,  
    FIF_PSPOLL,  
    FIF_PROBE_REQ  
};
```

## Constants

|                         |  |
|-------------------------|--|
| FIF_PROMISC_IN_BSS      | promiscuous mode within your BSS, think of the BSS as your network segment and then this corresponds to the regular ethernet device promiscuous mode.  |
| FIF_ALLMULTI            | pass all multicast frames, this is used if requested by the user or if the hardware is not capable of filtering by multicast address.  |
| FIF_FCSFAIL             | pass frames with failed FCS (but you need to set the RX_FLAG_FAILED_FCS_CRC for them)  |
| FIF_PLCPFAIL            | pass frames with failed PLCP CRC (but you need to set the RX_FLAG_FAILED_PLCP_CRC for them)  |
| FIF_BCN_PRBRESP_PROMISC | This flag is set during scanning to indicate to the hardware that it should not filter beacons or probe responses by BSSID. Filtering them can greatly reduce the amount of processing mac80211 needs to do and the amount of CPU wakeups, so you should honour this flag if possible. |
| FIF_CONTROL             | pass control frames (except for PS Poll), if PROMISC_IN_BSS is not set then only those addressed to this station.  |
| FIF_OTHER_BSS           | pass frames destined to other BSSes  |
| FIF_PSPOLL              | pass PS Poll frames, if PROMISC_IN_BSS is not set then only those addressed to this station.   |
| FIF_PROBE_REQ           | pass probe request frames  |

## HW queue control

These flags determine what the filter in hardware should be programmed to let through and what should not be passed to the stack. It is always safe to pass more frames than requested, but this has negative impact on power consumption.

---

# Chapter 6. The mac80211 workqueue

mac80211 provides its own workqueue for drivers and internal mac80211 use. The workqueue is a single threaded workqueue and can only be accessed by helpers for sanity checking. Drivers must ensure all work added onto the mac80211 workqueue should be cancelled on the driver `stop` callback.

mac80211 will flushed the workqueue upon interface removal and during suspend.

All work performed on the mac80211 workqueue must not acquire the RTNL lock.

## Name

`ieee80211_queue_work` — add work onto the mac80211 workqueue

## Synopsis

```
void ieee80211_queue_work (struct ieee80211_hw * hw, struct work_struct  
* work);
```

## Arguments

*hw*      the hardware struct for the interface we are adding work for

*work*    the work we want to add onto the mac80211 workqueue

## Description

Drivers and mac80211 use this to add work onto the mac80211 workqueue. This helper ensures drivers are not queueing work when they should not be.

## Name

`ieee80211_queue_delayed_work` — add work onto the mac80211 workqueue

## Synopsis

```
void ieee80211_queue_delayed_work (struct ieee80211_hw * hw, struct  
delayed_work * dwork, unsigned long delay);
```

## Arguments

*hw* the hardware struct for the interface we are adding work for

*dwork* delayable work to queue onto the mac80211 workqueue

*delay* number of jiffies to wait before queueing

## Description

Drivers and mac80211 use this to queue delayed work onto the mac80211 workqueue.

---

# Part II. Advanced driver interface

Information contained within this part of the book is of interest only for advanced interaction of mac80211 with drivers to exploit more hardware capabilities and improve performance.

---

## Table of Contents

|  |     |
|--|-----|
| 7. LED support .....                             | 72  |
| ieee80211_get_tx_led_name .....                  | 73  |
| ieee80211_get_rx_led_name .....                  | 74  |
| ieee80211_get_assoc_led_name .....               | 75  |
| ieee80211_get_radio_led_name .....               | 76  |
| struct ieee80211_tpt_blink .....                 | 77  |
| enum ieee80211_tpt_led_trigger_flags .....       | 78  |
| ieee80211_create_tpt_led_trigger .....           | 79  |
| 8. Hardware crypto acceleration .....            | 80  |
| enum set_key_cmd .....                           | 81  |
| struct ieee80211_key_conf .....                  | 82  |
| enum ieee80211_key_flags .....                   | 83  |
| ieee80211_get_tkip_p1k .....                     | 85  |
| ieee80211_get_tkip_p1k_iv .....                  | 86  |
| ieee80211_get_tkip_p2k .....                     | 87  |
| 9. Powersave support .....                       | 88  |
| 10. Beacon filter support .....                  | 89  |
| ieee80211_beacon_loss .....                      | 90  |
| 11. Multiple queues and QoS support .....        | 91  |
| struct ieee80211_tx_queue_params .....           | 92  |
| 12. Access point mode support .....              | 93  |
| support for powersaving clients .....            | 93  |
| 13. Supporting multiple virtual interfaces ..... | 103 |
| ieee80211_iterate_active_interfaces .....        | 104 |
| ieee80211_iterate_active_interfaces_atomic ..... | 105 |
| 14. Station handling .....                       | 106 |
| struct ieee80211_sta .....                       | 107 |
| enum sta_notify_cmd .....                        | 109 |
| ieee80211_find_sta .....                         | 110 |
| ieee80211_find_sta_by_ifaddr .....               | 111 |
| 15. Hardware scan offload .....                  | 112 |
| ieee80211_scan_completed .....                   | 113 |
| 16. Aggregation .....                            | 114 |
| TX A-MPDU aggregation .....                      | 114 |
| RX A-MPDU aggregation .....                      | 114 |
| 17. Spatial Multiplexing Powersave (SMPS) .....  | 116 |
| ieee80211_request_smpps .....                    | 117 |
| enum ieee80211_smpps_mode .....                  | 118 |

---

# Chapter 7. LED support

Mac80211 supports various ways of blinking LEDs. Wherever possible, device LEDs should be exposed as LED class devices and hooked up to the appropriate trigger, which will then be triggered appropriately by mac80211.

## Name

ieee80211\_get\_tx\_led\_name — get name of TX LED

## Synopsis

```
char * ieee80211_get_tx_led_name (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to get the LED trigger name for

## Description

mac80211 creates a transmit LED trigger for each wireless hardware that can be used to drive LEDs if your driver registers a LED device. This function returns the name (or NULL if not configured for LEDs) of the trigger so you can automatically link the LED device.

## Return

The name of the LED trigger. NULL if not configured for LEDs.



## Name

ieee80211\_get\_rx\_led\_name — get name of RX LED

## Synopsis

```
char * ieee80211_get_rx_led_name (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to get the LED trigger name for

## Description

mac80211 creates a receive LED trigger for each wireless hardware that can be used to drive LEDs if your driver registers a LED device. This function returns the name (or NULL if not configured for LEDs) of the trigger so you can automatically link the LED device.

## Return

The name of the LED trigger. NULL if not configured for LEDs.

## Name

ieee80211\_get\_assoc\_led\_name — get name of association LED

## Synopsis

```
char * ieee80211_get_assoc_led_name (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to get the LED trigger name for

## Description

mac80211 creates a association LED trigger for each wireless hardware that can be used to drive LEDs if your driver registers a LED device. This function returns the name (or NULL if not configured for LEDs) of the trigger so you can automatically link the LED device.

## Return

The name of the LED trigger. NULL if not configured for LEDs.

## Name

ieee80211\_get\_radio\_led\_name — get name of radio LED

## Synopsis

```
char * ieee80211_get_radio_led_name (struct ieee80211_hw * hw);
```

## Arguments

*hw* the hardware to get the LED trigger name for

## Description

mac80211 creates a radio change LED trigger for each wireless hardware that can be used to drive LEDs if your driver registers a LED device. This function returns the name (or NULL if not configured for LEDs) of the trigger so you can automatically link the LED device.

## Return

The name of the LED trigger. NULL if not configured for LEDs.

## Name

struct ieee80211\_tpt\_blink — throughput blink description

## Synopsis

```
struct ieee80211_tpt_blink {  
    int throughput;  
    int blink_time;  
};
```

## Members

|            |  |
|------------|--|
| throughput | throughput in Kbit/sec   |
| blink_time | blink time in milliseconds (full cycle, ie. one off + one on period) |

## Name

enum ieee80211\_tpt\_led\_trigger\_flags — throughput trigger flags

## Synopsis

```
enum ieee80211_tpt_led_trigger_flags {  
    IEEE80211_TPT_LEDTRIG_FL_RADIO,  
    IEEE80211_TPT_LEDTRIG_FL_WORK,  
    IEEE80211_TPT_LEDTRIG_FL_CONNECTED  
};
```

## Constants

IEEE80211\_TPT\_LEDTRIG\_FL\_RADIO: LED blinking with radio

IEEE80211\_TPT\_LEDTRIG\_FL\_WORK: LED blinking when working

IEEE80211\_TPT\_LEDTRIG\_FL\_CONNECTED: LED blinking when at least one interface is connected in some way, including being an AP

## Name

ieee80211\_create\_tpt\_led\_trigger — create throughput LED trigger

## Synopsis

```
char * ieee80211_create_tpt_led_trigger (struct ieee80211_hw * hw,
unsigned int flags, const struct ieee80211_tpt_blink * blink_table,
unsigned int blink_table_len);
```

## Arguments

|                        |   |
|------------------------|---|
| <i>hw</i>              | the hardware to create the trigger for                  |
| <i>flags</i>           | trigger flags, see enum ieee80211_tpt_led_trigger_flags |
| <i>blink_table</i>     | the blink table -- needs to be ordered by throughput    |
| <i>blink_table_len</i> | size of the blink table                                 |

## Return

NULL (in case of error, or if no LED triggers are configured) or the name of the new trigger.

## Note

This function must be called before `ieee80211_register_hw`.

---

# Chapter 8. Hardware crypto acceleration

mac80211 is capable of taking advantage of many hardware acceleration designs for encryption and decryption operations.

The `set_key` callback in the struct `ieee80211_ops` for a given device is called to enable hardware acceleration of encryption and decryption. The callback takes a `sta` parameter that will be NULL for default keys or keys used for transmission only, or point to the station information for the peer for individual keys. Multiple transmission keys with the same key index may be used when VLANs are configured for an access point.

When transmitting, the TX control data will use the `hw_key_idx` selected by the driver by modifying the struct `ieee80211_key_conf` pointed to by the `key` parameter to the `set_key` function.

The `set_key` call for the `SET_KEY` command should return 0 if the key is now in use, `-EOPNOTSUPP` or `-ENOSPC` if it couldn't be added; if you return 0 then `hw_key_idx` must be assigned to the hardware key index, you are free to use the full u8 range.

Note that in the case that the `IEEE80211_HW_SW_CRYPTO_CONTROL` flag is set, mac80211 will not automatically fall back to software crypto if enabling hardware crypto failed. The `set_key` call may also return the value 1 to permit this specific key/algorithm to be done in software.

When the cmd is `DISABLE_KEY` then it must succeed.

Note that it is permissible to not decrypt a frame even if a key for it has been uploaded to hardware, the stack will not make any decision based on whether a key has been uploaded or not but rather based on the receive flags.

The struct `ieee80211_key_conf` structure pointed to by the `key` parameter is guaranteed to be valid until another call to `set_key` removes it, but it can only be used as a cookie to differentiate keys.

In TKIP some HW need to be provided a phase 1 key, for RX decryption acceleration (i.e. iwlwifi). Those drivers should provide `update_tkip_key` handler. The `update_tkip_key` call updates the driver with the new phase 1 key. This happens every time the iv16 wraps around (every 65536 packets). The `set_key` call will happen only once for each key (unless the AP did rekeying), it will not include a valid phase 1 key. The valid phase 1 key is provided by `update_tkip_key` only. The trigger that makes mac80211 call this handler is software decryption with wrap around of iv16.

The `set_default_unicast_key` call updates the default WEP key index configured to the hardware for WEP encryption type. This is required for devices that support offload of data packets (e.g. ARP responses).

## Name

enum set\_key\_cmd — key command

## Synopsis

```
enum set_key_cmd {  
    SET_KEY,  
    DISABLE_KEY  
};
```

## Constants

SET\_KEY            a key is set

DISABLE\_KEY    a key must be disabled

## Description

Used with the `set_key` callback in struct `ieee80211_ops`, this indicates whether a key is being removed or added.



## Name

struct ieee80211\_key\_conf — key information

## Synopsis

```
struct ieee80211_key_conf {  
    u32 cipher;  
    u8 icv_len;  
    u8 iv_len;  
    u8 hw_key_idx;  
    u8 flags;  
    s8 keyidx;  
    u8 keylen;  
    u8 key[0];  
};
```

## Members

|            |  |
|------------|--|
| cipher     | The key's cipher suite selector.   |
| icv_len    | The ICV length for this key type   |
| iv_len     | The IV length for this key type  |
| hw_key_idx | To be set by the driver, this is the key index the driver wants to be given when a frame is transmitted and needs to be encrypted in hardware. |
| flags      | key flags, see enum ieee80211_key_flags.   |
| keyidx     | the key index (0-3)  |
| keylen     | key material length  |
| key[0]     | key material. For ALG_TKIP the key is encoded as a 256-bit (32 byte)   |

## Description

This key information is given by mac80211 to the driver by the `set_key` callback in struct `ieee80211_ops`.

## data block

- Temporal Encryption Key (128 bits) - Temporal Authenticator Tx MIC Key (64 bits) - Temporal Authenticator Rx MIC Key (64 bits)

## Name

enum ieee80211\_key\_flags — key flags

## Synopsis

```
enum ieee80211_key_flags {
    IEEE80211_KEY_FLAG_GENERATE_IV_MGMT,
    IEEE80211_KEY_FLAG_GENERATE_IV,
    IEEE80211_KEY_FLAG_GENERATE_MMIC,
    IEEE80211_KEY_FLAG_PAIRWISE,
    IEEE80211_KEY_FLAG_SW_MGMT_TX,
    IEEE80211_KEY_FLAG_PUT_IV_SPACE,
    IEEE80211_KEY_FLAG_RX_MGMT,
    IEEE80211_KEY_FLAG_RESERVE_TAILROOM
};
```

## Constants

**IEEE80211\_KEY\_FLAG\_GENERATE\_IV\_MGMT** This flag should be set by the driver for a CCMP/GCMP key to indicate that it requires IV generation only for management frames (MFP).

**IEEE80211\_KEY\_FLAG\_GENERATE\_IV** This flag should be set by the driver to indicate that it requires IV generation for this particular key. Setting this flag does not necessarily mean that SKBs will have sufficient tailroom for ICV or MIC.

**IEEE80211\_KEY\_FLAG\_GENERATE\_MMIC** This flag should be set by the driver for a TKIP key if it requires Michael MIC generation in software.

**IEEE80211\_KEY\_FLAG\_PAIRWISE** Set by mac80211, this flag indicates that the key is pairwise rather than a shared key.

**IEEE80211\_KEY\_FLAG\_SW\_MGMT\_TX** This flag should be set by the driver for a CCMP/GCMP key if it requires CCMP/GCMP encryption of management frames (MFP) to be done in software.

**IEEE80211\_KEY\_FLAG\_PUT\_IV\_SPACE** This flag should be set by the driver if space should be prepared for the IV, but the IV itself should not be generated. Do not set together with *IEEE80211\_KEY\_FLAG\_GENERATE\_IV* on the same key. Setting this flag does not necessarily mean that SKBs will have sufficient tailroom for ICV or MIC.

**IEEE80211\_KEY\_FLAG\_RX\_MGMT** This key will be used to decrypt received management frames. The flag can help drivers that have a hardware crypto implementation that doesn't deal with management frames properly by allowing them to not upload the keys to hardware and fall back to software crypto. Note that this flag deals only with RX, if your crypto engine can't deal with TX you can also set the *IEEE80211\_KEY\_FLAG\_SW\_MGMT\_TX* flag to encrypt such frames in SW.

IEEE80211\_KEY\_FLAG\_RESERVE\_TAILROOM must be set by the driver for a key to indicate that sufficient tailroom must always be reserved for ICV or MIC, even when HW encryption is enabled.

## Description

These flags are used for communication about keys between the driver and mac80211, with the *flags* parameter of struct `ieee80211_key_conf`.

## Name

ieee80211\_get\_tkip\_plk — get a TKIP phase 1 key

## Synopsis

```
void ieee80211_get_tkip_plk (struct ieee80211_key_conf * keyconf, struct  
sk_buff * skb, u16 * plk);
```

## Arguments

*keyconf*    the parameter passed with the set key

*skb*        the packet to take the IV32 value from that will be encrypted with this P1K

*plk*        a buffer to which the key will be written, as 5 u16 values

## Description

This function returns the TKIP phase 1 key for the IV32 taken from the given packet.

## Name

ieee80211\_get\_tkip\_p1k\_iv — get a TKIP phase 1 key for IV32

## Synopsis

```
void ieee80211_get_tkip_p1k_iv (struct ieee80211_key_conf * keyconf,  
u32 iv32, u16 * p1k);
```

## Arguments

*keyconf* the parameter passed with the set key

*iv32* IV32 to get the P1K for

*p1k* a buffer to which the key will be written, as 5 u16 values

## Description

This function returns the TKIP phase 1 key for the given IV32.

## Name

ieee80211\_get\_tkip\_p2k — get a TKIP phase 2 key

## Synopsis

```
void ieee80211_get_tkip_p2k (struct ieee80211_key_conf * keyconf, struct  
sk_buff * skb, u8 * p2k);
```

## Arguments

*keyconf*    the parameter passed with the set key

*skb*        the packet to take the IV32/IV16 values from that will be encrypted with this key

*p2k*        a buffer to which the key will be written, 16 bytes

## Description

This function computes the TKIP RC4 key for the IV values in the packet.

---

# Chapter 9. Powersave support

mac80211 has support for various powersave implementations.

First, it can support hardware that handles all powersaving by itself, such hardware should simply set the `IEEE80211_HW_SUPPORTS_PS` hardware flag. In that case, it will be told about the desired powersave mode with the `IEEE80211_CONF_PS` flag depending on the association status. The hardware must take care of sending nullfunc frames when necessary, i.e. when entering and leaving powersave mode. The hardware is required to look at the AID in beacons and signal to the AP that it woke up when it finds traffic directed to it.

`IEEE80211_CONF_PS` flag enabled means that the powersave mode defined in IEEE 802.11-2007 section 11.2 is enabled. This is not to be confused with hardware wakeup and sleep states. Driver is responsible for waking up the hardware before issuing commands to the hardware and putting it back to sleep at appropriate times.

When PS is enabled, hardware needs to wakeup for beacons and receive the buffered multicast/broadcast frames after the beacon. Also it must be possible to send frames and receive the acknowledgment frame.

Other hardware designs cannot send nullfunc frames by themselves and also need software support for parsing the TIM bitmap. This is also supported by mac80211 by combining the `IEEE80211_HW_SUPPORTS_PS` and `IEEE80211_HW_PS_NULLFUNC_STACK` flags. The hardware is of course still required to pass up beacons. The hardware is still required to handle waking up for multicast traffic; if it cannot the driver must handle that as best as it can, mac80211 is too slow to do that.

Dynamic powersave is an extension to normal powersave in which the hardware stays awake for a user-specified period of time after sending a frame so that reply frames need not be buffered and therefore delayed to the next wakeup. It's compromise of getting good enough latency when there's data traffic and still saving significantly power in idle periods.

Dynamic powersave is simply supported by mac80211 enabling and disabling PS based on traffic. Driver needs to only set `IEEE80211_HW_SUPPORTS_PS` flag and mac80211 will handle everything automatically. Additionally, hardware having support for the dynamic PS feature may set the `IEEE80211_HW_SUPPORTS_DYNAMIC_PS` flag to indicate that it can support dynamic PS mode itself. The driver needs to look at the `dynamic_ps_timeout` hardware configuration value and use it that value whenever `IEEE80211_CONF_PS` is set. In this case mac80211 will disable dynamic PS feature in stack and will just keep `IEEE80211_CONF_PS` enabled whenever user has enabled powersave.

Driver informs U-APSD client support by enabling `IEEE80211_VIF_SUPPORTS_UAPSD` flag. The mode is configured through the `uapsd` parameter in `conf_tx` operation. Hardware needs to send the QoS Nullfunc frames and stay awake until the service period has ended. To utilize U-APSD, dynamic powersave is disabled for voip AC and all frames from that AC are transmitted with powersave enabled.

Note: U-APSD client mode is not yet supported with `IEEE80211_HW_PS_NULLFUNC_STACK`.

---

# Chapter 10. Beacon filter support

Some hardware have beacon filter support to reduce host cpu wakeups which will reduce system power consumption. It usually works so that the firmware creates a checksum of the beacon but omits all constantly changing elements (TSF, TIM etc). Whenever the checksum changes the beacon is forwarded to the host, otherwise it will be just dropped. That way the host will only receive beacons where some relevant information (for example ERP protection or WMM settings) have changed.

Beacon filter support is advertised with the `IEEE80211_VIF_BEACON_FILTER` interface capability. The driver needs to enable beacon filter support whenever power save is enabled, that is `IEEE80211_CONF_PS` is set. When power save is enabled, the stack will not check for beacon loss and the driver needs to notify about loss of beacons with `ieee80211_beacon_loss`.

The time (or number of beacons missed) until the firmware notifies the driver of a beacon loss event (which in turn causes the driver to call `ieee80211_beacon_loss`) should be configurable and will be controlled by `mac80211` and the roaming algorithm in the future.

Since there may be constantly changing information elements that nothing in the software stack cares about, we will, in the future, have `mac80211` tell the driver which information elements are interesting in the sense that we want to see changes in them. This will include - a list of information element IDs - a list of OUIs for the vendor information element

Ideally, the hardware would filter out any beacons without changes in the requested elements, but if it cannot support that it may, at the expense of some efficiency, filter out only a subset. For example, if the device doesn't support checking for OUIs it should pass up all changes in all vendor information elements.

Note that change, for the sake of simplification, also includes information elements appearing or disappearing from the beacon.

Some hardware supports an “ignore list” instead, just make sure nothing that was requested is on the ignore list, and include commonly changing information element IDs in the ignore list, for example 11 (BSS load) and the various vendor-assigned IEs with unknown contents (128, 129, 133-136, 149, 150, 155, 156, 173, 176, 178, 179, 219); for forward compatibility it could also include some currently unused IDs.

In addition to these capabilities, hardware should support notifying the host of changes in the beacon RSSI. This is relevant to implement roaming when no traffic is flowing (when traffic is flowing we see the RSSI of the received data packets). This can consist in notifying the host when the RSSI changes significantly or when it drops below or rises above configurable thresholds. In the future these thresholds will also be configured by `mac80211` (which gets them from userspace) to implement them as the roaming algorithm requires.

If the hardware cannot implement this, the driver should ask it to periodically pass beacon frames to the host so that software can do the signal strength threshold checking.



## Name

ieee80211\_beacon\_loss — inform hardware does not receive beacons

## Synopsis

```
void ieee80211_beacon_loss (struct ieee80211_vif * vif);
```

## Arguments

*vif* struct ieee80211\_vif pointer from the add\_interface callback.

## Description

When beacon filtering is enabled with IEEE80211\_VIF\_BEACON\_FILTER and IEEE80211\_CONF\_PS is set, the driver needs to inform whenever the hardware is not receiving beacons with this function.

---

# Chapter 11. Multiple queues and QoS support

TBD

## Name

struct ieee80211\_tx\_queue\_params — transmit queue configuration

## Synopsis

```
struct ieee80211_tx_queue_params {  
    u16 txop;  
    u16 cw_min;  
    u16 cw_max;  
    u8 aifs;  
    bool acm;  
    bool uapsd;  
};
```

## Members

|        |   |
|--------|---|
| txop   | maximum burst time in units of 32 usecs, 0 meaning disabled                   |
| cw_min | minimum contention window [a value of the form $2^n-1$ in the range 1..32767] |
| cw_max | maximum contention window [like <i>cw_min</i> ]                               |
| aifs   | arbitration interframe space [0..255]   |
| acm    | is mandatory admission control required for the access category               |
| uapsd  | is U-APSD mode enabled for the queue  |

## Description

The information provided in this structure is required for QoS transmit queue configuration. Cf. IEEE 802.11 7.3.2.29.

---

# Chapter 12. Access point mode support

TBD

Some parts of the `if_conf` should be discussed here instead

Insert notes about VLAN interfaces with hw crypto here or in the hw crypto chapter.

## support for powersaving clients

In order to implement AP and P2P GO modes, `mac80211` has support for client powersaving, both “legacy” PS (PS-Poll/null data) and uAPSD. There currently is no support for sAPSD.

There is one assumption that `mac80211` makes, namely that a client will not poll with PS-Poll and trigger with uAPSD at the same time. Both are supported, and both can be used by the same client, but they can't be used concurrently by the same client. This simplifies the driver code.

The first thing to keep in mind is that there is a flag for complete driver implementation: `IEEE80211_HW_AP_LINK_PS`. If this flag is set, `mac80211` expects the driver to handle most of the state machine for powersaving clients and will ignore the PM bit in incoming frames. Drivers then use `ieee80211_sta_ps_transition` to inform `mac80211` of stations' powersave transitions. In this mode, `mac80211` also doesn't handle PS-Poll/uAPSD.

In the mode without `IEEE80211_HW_AP_LINK_PS`, `mac80211` will check the PM bit in incoming frames for client powersave transitions. When a station goes to sleep, we will stop transmitting to it. There is, however, a race condition: a station might go to sleep while there is data buffered on hardware queues. If the device has support for this it will reject frames, and the driver should give the frames back to `mac80211` with the `IEEE80211_TX_STAT_TX_FILTERED` flag set which will cause `mac80211` to retry the frame when the station wakes up. The driver is also notified of powersave transitions by calling its `sta_notify` callback.

When the station is asleep, it has three choices: it can wake up, it can PS-Poll, or it can possibly start a uAPSD service period. Waking up is implemented by simply transmitting all buffered (and filtered) frames to the station. This is the easiest case. When the station sends a PS-Poll or a uAPSD trigger frame, `mac80211` will inform the driver of this with the `allow_buffered_frames` callback; this callback is optional. `mac80211` will then transmit the frames as usual and set the `IEEE80211_TX_CTL_NO_PS_BUFFER` on each frame. The last frame in the service period (or the only response to a PS-Poll) also has `IEEE80211_TX_STATUS_EOSP` set to indicate that it ends the service period; as this frame must have TX status report it also sets `IEEE80211_TX_CTL_REQ_TX_STATUS`. When TX status is reported for this frame, the service period is marked as having ended and a new one can be started by the peer.

Additionally, non-bufferable MMPDUs can also be transmitted by `mac80211` with the `IEEE80211_TX_CTL_NO_PS_BUFFER` set in them.

Another race condition can happen on some devices like `iwlwifi` when there are frames queued for the station and it wakes up or polls; the frames that are already queued could end up being transmitted first instead, causing reordering and/or wrong processing of the EOSP. The cause is that allowing frames to be transmitted to a certain station is out-of-band communication to the device. To allow this problem to be solved, the driver can call `ieee80211_sta_block_awake` if frames are buffered when it is notified

that the station went to sleep. When all these frames have been filtered (see above), it must call the function again to indicate that the station is no longer blocked.

If the driver buffers frames in the driver for aggregation in any way, it must use the `ieee80211_sta_set_buffered` call when it is notified of the station going to sleep to inform mac80211 of any TIDs that have frames buffered. Note that when a station wakes up this information is reset (hence the requirement to call it when informed of the station going to sleep). Then, when a service period starts for any reason, `release_buffered_frames` is called with the number of frames to be released and which TIDs they are to come from. In this case, the driver is responsible for setting the EOSP (for uAPSD) and MORE\_DATA bits in the released frames, to help the `more_data` parameter is passed to tell the driver if there is more data on other TIDs -- the TIDs to release frames from are ignored since mac80211 doesn't know how many frames the buffers for those TIDs contain.

If the driver also implement GO mode, where absence periods may shorten service periods (or abort PS-Poll responses), it must filter those response frames except in the case of frames that are buffered in the driver -- those must remain buffered to avoid reordering. Because it is possible that no frames are released in this case, the driver must call `ieee80211_sta_eosp` to indicate to mac80211 that the service period ended anyway.

Finally, if frames from multiple TIDs are released from mac80211 but the driver might reorder them, it must clear & set the flags appropriately (only the last frame may have `IEEE80211_TX_STATUS_EOSP`) and also take care of the EOSP and MORE\_DATA bits in the frame. The driver may also use `ieee80211_sta_eosp` in this case.

Note that if the driver ever buffers frames other than QoS-data frames, it must take care to never send a non-QoS-data frame as the last frame in a service period, adding a QoS-nulldata frame after a non-QoS-data frame if needed.

## Name

`ieee80211_get_buffered_bc` — accessing buffered broadcast and multicast frames

## Synopsis

```
struct sk_buff * ieee80211_get_buffered_bc (struct ieee80211_hw * hw,  
struct ieee80211_vif * vif);
```

## Arguments

*hw* pointer as obtained from `ieee80211_alloc_hw`.

*vif* struct `ieee80211_vif` pointer from the `add_interface` callback.

## Description

Function for accessing buffered broadcast and multicast frames. If hardware/firmware does not implement buffering of broadcast/multicast frames when power saving is used, 802.11 code buffers them in the host memory. The low-level driver uses this function to fetch next buffered frame. In most cases, this is used when generating beacon frame.

## Return

A pointer to the next buffered skb or NULL if no more buffered frames are available.

## Note

buffered frames are returned only after DTIM beacon frame was generated with `ieee80211_beacon_get` and the low-level driver must thus call `ieee80211_beacon_get` first. `ieee80211_get_buffered_bc` returns NULL if the previous generated beacon was not DTIM, so the low-level driver does not need to check for DTIM beacons separately and should be able to use common code for all beacons.

## Name

ieee80211\_beacon\_get — beacon generation function

## Synopsis

```
struct sk_buff * ieee80211_beacon_get (struct ieee80211_hw * hw, struct
ieee80211_vif * vif);
```

## Arguments

*hw* pointer obtained from ieee80211\_alloc\_hw.

*vif* struct ieee80211\_vif pointer from the add\_interface callback.

## Description

See ieee80211\_beacon\_get\_tim.

## Return

See ieee80211\_beacon\_get\_tim.

## Name

ieee80211\_sta\_eosp — notify mac80211 about end of SP

## Synopsis

```
void ieee80211_sta_eosp (struct ieee80211_sta * pubsta);
```

## Arguments

*pubsta* the station

## Description

When a device transmits frames in a way that it can't tell mac80211 in the TX status about the EOSP, it must clear the IEEE80211\_TX\_STATUS\_EOSP bit and call this function instead. This applies for PS-Poll as well as uAPSD.

Note that just like with `_tx_status` and `_rx` drivers must not mix calls to irqsafe/non-irqsafe versions, this function must not be mixed with those either. Use the all irqsafe, or all non-irqsafe, don't mix!

## NB

the `_irqsafe` version of this function doesn't exist, no driver needs it right now. Don't call this function if you'd need the `_irqsafe` version, look at the git history and restore the `_irqsafe` version!



## Name

enum ieee80211\_frame\_release\_type — frame release reason

## Synopsis

```
enum ieee80211_frame_release_type {  
    IEEE80211_FRAME_RELEASE_PSPOLL,  
    IEEE80211_FRAME_RELEASE_UAPSD  
};
```

## Constants

IEEE80211\_FRAME\_RELEASE\_PSPOLL — frame released for PS-Poll

IEEE80211\_FRAME\_RELEASE\_UAPSD — frame(s) released due to frame received on trigger-enabled AC

## Name

ieee80211\_sta\_ps\_transition — PS transition for connected sta

## Synopsis

```
int ieee80211_sta_ps_transition (struct ieee80211_sta * sta, bool
start);
```

## Arguments

*sta* currently connected sta

*start* start or stop PS

## Description

When operating in AP mode with the IEEE80211\_HW\_AP\_LINK\_PS flag set, use this function to inform mac80211 about a connected station entering/leaving PS mode.

This function may not be called in IRQ context or with softirqs enabled.

Calls to this function for a single hardware must be synchronized against each other.

## Return

0 on success. -EINVAL when the requested PS mode is already set.

## Name

`ieee80211_sta_ps_transition_ni` — PS transition for connected sta (in process context)

## Synopsis

```
int ieee80211_sta_ps_transition_ni (struct ieee80211_sta * sta, bool
start);
```

## Arguments

*sta*      currently connected sta

*start*    start or stop PS

## Description

Like `ieee80211_sta_ps_transition` but can be called in process context (internally disables bottom halves). Concurrent call restriction still applies.

## Return

Like `ieee80211_sta_ps_transition`.

## Name

ieee80211\_sta\_set\_buffered — inform mac80211 about driver-buffered frames

## Synopsis

```
void ieee80211_sta_set_buffered (struct ieee80211_sta * sta, u8 tid,  
    bool buffered);
```

## Arguments

|                 |   |
|-----------------|---|
| <i>sta</i>      | struct ieee80211_sta pointer for the sleeping station     |
| <i>tid</i>      | the TID that has buffered frames                          |
| <i>buffered</i> | indicates whether or not frames are buffered for this TID |

## Description

If a driver buffers frames for a powersave station instead of passing them back to mac80211 for retransmission, the station may still need to be told that there are buffered frames via the TIM bit.

This function informs mac80211 whether or not there are frames that are buffered in the driver for a given TID; mac80211 can then use this data to set the TIM bit (NOTE: This may call back into the driver's set\_tim call! Beware of the locking!)

If all frames are released to the station (due to PS-poll or uAPSD) then the driver needs to inform mac80211 that there no longer are frames buffered. However, when the station wakes up mac80211 assumes that all buffered frames will be transmitted and clears this data, drivers need to make sure they inform mac80211 about all buffered frames on the sleep transition (sta\_notify with STA\_NOTIFY\_SLEEP).

Note that technically mac80211 only needs to know this per AC, not per TID, but since driver buffering will inevitably happen per TID (since it is related to aggregation) it is easier to make mac80211 map the TID to the AC as required instead of keeping track in all drivers that use this API.

## Name

ieee80211\_sta\_block\_awake — block station from waking up

## Synopsis

```
void ieee80211_sta_block_awake (struct ieee80211_hw * hw, struct
ieee80211_sta * pubsta, bool block);
```

## Arguments

*hw*            the hardware

*pubsta*       the station

*block*        whether to block or unblock

## Description

Some devices require that all frames that are on the queues for a specific station that went to sleep are flushed before a poll response or frames after the station woke up can be delivered to that it. Note that such frames must be rejected by the driver as filtered, with the appropriate status flag.

This function allows implementing this mode in a race-free manner.

To do this, a driver must keep track of the number of frames still enqueued for a specific station. If this number is not zero when the station goes to sleep, the driver must call this function to force mac80211 to consider the station to be asleep regardless of the station's actual state. Once the number of outstanding frames reaches zero, the driver must call this function again to unblock the station. That will cause mac80211 to be able to send ps-poll responses, and if the station queried in the meantime then frames will also be sent out as a result of this. Additionally, the driver will be notified that the station woke up some time after it is unblocked, regardless of whether the station actually woke up while blocked or not.

---

# Chapter 13. Supporting multiple virtual interfaces

TBD

Note: WDS with identical MAC address should almost always be OK

Insert notes about having multiple virtual interfaces with different MAC addresses here, note which configurations are supported by mac80211, add notes about supporting hw crypto with it.

## Name

ieee80211\_iterate\_active\_interfaces — iterate active interfaces

## Synopsis

```
void ieee80211_iterate_active_interfaces (struct ieee80211_hw * hw, u32
iter_flags, void (*iterator) (void *data, u8 *mac, struct ieee80211_vif
*vif), void * data);
```

## Arguments

|                   |  |
|-------------------|--|
| <i>hw</i>         | the hardware struct of which the interfaces should be iterated over        |
| <i>iter_flags</i> | iteration flags, see enum <code>ieee80211_interface_iteration_flags</code> |
| <i>iterator</i>   | the iterator function to call  |
| <i>data</i>       | first argument of the iterator function                                    |

## Description

This function iterates over the interfaces associated with a given hardware that are currently active and calls the callback for them. This function allows the iterator function to sleep, when the iterator function is atomic `ieee80211_iterate_active_interfaces_atomic` can be used. Does not iterate over a new interface during `add_interface`.

## Name

ieee80211\_iterate\_active\_interfaces\_atomic — iterate active interfaces

## Synopsis

```
void ieee80211_iterate_active_interfaces_atomic (struct ieee80211_hw *  
hw, u32 iter_flags, void (*iterator) (void *data, u8 *mac, struct  
ieee80211_vif *vif), void * data);
```

## Arguments

|                   |  |
|-------------------|--|
| <i>hw</i>         | the hardware struct of which the interfaces should be iterated over        |
| <i>iter_flags</i> | iteration flags, see enum <code>ieee80211_interface_iteration_flags</code> |
| <i>iterator</i>   | the iterator function to call, cannot sleep                                |
| <i>data</i>       | first argument of the iterator function                                    |

## Description

This function iterates over the interfaces associated with a given hardware that are currently active and calls the callback for them. This function requires the iterator callback function to be atomic, if that is not desired, use `ieee80211_iterate_active_interfaces` instead. Does not iterate over a new interface during `add_interface`.



---

# Chapter 14. Station handling

TODO

## Name

struct ieee80211\_sta — station table entry

## Synopsis

```
struct ieee80211_sta {
    u32 supp_rates[IEEE80211_NUM_BANDS];
    u8 addr[ETH_ALEN];
    u16 aid;
    struct ieee80211_sta_ht_cap ht_cap;
    struct ieee80211_sta_vht_cap vht_cap;
    bool wme;
    u8 uapsd_queues;
    u8 max_sp;
    u8 rx_nss;
    enum ieee80211_sta_rx_bandwidth bandwidth;
    enum ieee80211_smmps_mode smmps_mode;
    struct ieee80211_sta_rates __rcu * rates;
    bool tdls;
    bool tdls_initiator;
    bool mfp;
    struct ieee80211_txq * txq[IEEE80211_NUM_TIDS];
    u8 drv_priv[0];
};
```

## Members

|                                 |  |
|---------------------------------|--|
| supp_rates[IEEE80211_NUM_BANDS] | map of supported rates (per band)  |
| addr[ETH_ALEN]                  | MAC address  |
| aid                             | AID we assigned to the station if we're an AP  |
| ht_cap                          | HT capabilities of this STA; restricted to our own capabilities  |
| vht_cap                         | VHT capabilities of this STA; restricted to our own capabilities   |
| wme                             | indicates whether the STA supports QoS/WME (if local devices does, otherwise always false)   |
| uapsd_queues                    | bitmap of queues configured for uapsd. Only valid if wme is supported.   |
| max_sp                          | max Service Period. Only valid if wme is supported.  |
| rx_nss                          | in HT/VHT, the maximum number of spatial streams the station can receive at the moment, changed by operating mode notifications and capabilities. The value is only valid after the station moves to associated state. |
| bandwidth                       | current bandwidth the station can receive with   |
| smmps_mode                      | current SMPS mode (off, static or dynamic)   |

|                                      |   |
|--------------------------------------|---|
| <code>rates</code>                   | rate control selection table  |
| <code>tdls</code>                    | indicates whether the STA is a TDLS peer  |
| <code>tdls_initiator</code>          | indicates the STA is an initiator of the TDLS link. Only valid if the STA is a TDLS peer in the first place.            |
| <code>mfp</code>                     | indicates whether the STA uses management frame protection or not.  |
| <code>txq[IEEE80211_NUM_TIDS]</code> | per-TID data TX queues (if driver uses the TXQ abstraction)   |
| <code>drv_priv[0]</code>             | data area for driver use, will always be aligned to <code>sizeof(void *)</code> , size is determined in hw information. |

## Description

A station table entry represents a station we are possibly communicating with. Since stations are RCU-managed in `mac80211`, any `ieee80211_sta` pointer you get access to must either be protected by `rcu_read_lock` explicitly or implicitly, or you must take good care to not use such a pointer after a call to your `sta_remove` callback that removed it.

## Name

enum sta\_notify\_cmd — sta notify command

## Synopsis

```
enum sta_notify_cmd {  
    STA_NOTIFY_SLEEP,  
    STA_NOTIFY_AWAKE  
};
```

## Constants

STA\_NOTIFY\_SLEEP    a station is now sleeping

STA\_NOTIFY\_AWAKE   a sleeping station woke up

## Description

Used with the `sta_notify` callback in struct `ieee80211_ops`, this indicates if an associated station made a power state transition.

## Name

`ieee80211_find_sta` — find a station

## Synopsis

```
struct ieee80211_sta * ieee80211_find_sta (struct ieee80211_vif * vif,  
const u8 * addr);
```

## Arguments

*vif*    virtual interface to look for station on

*addr*   station's address

## Return

The station, if found. NULL otherwise.

## Note

This function must be called under RCU lock and the resulting pointer is only valid under RCU lock as well.

## Name

`ieee80211_find_sta_by_ifaddr` — find a station on hardware

## Synopsis

```
struct ieee80211_sta * ieee80211_find_sta_by_ifaddr (struct
ieee80211_hw * hw, const u8 * addr, const u8 * localaddr);
```

## Arguments

*hw* pointer as obtained from `ieee80211_alloc_hw`

*addr* remote station's address

*localaddr* local address (`vif->sdata->vif.addr`). Use NULL for 'any'.

## Return

The station, if found. NULL otherwise.

## Note

This function must be called under RCU lock and the resulting pointer is only valid under RCU lock as well.

## NOTE

You may pass NULL for `localaddr`, but then you will just get the first STA that matches the remote address 'addr'. We can have multiple STA associated with multiple logical stations (e.g. consider a station connecting to another BSSID on the same AP hardware without disconnecting first). In this case, the result of this method with `localaddr` NULL is not reliable.

DO NOT USE THIS FUNCTION with `localaddr` NULL if at all possible.

---

# Chapter 15. Hardware scan offload

TBD

## Name

ieee80211\_scan\_completed — completed hardware scan

## Synopsis

```
void ieee80211_scan_completed (struct ieee80211_hw * hw, bool aborted);
```

## Arguments

*hw*            the hardware that finished the scan

*aborted*    set to true if scan was aborted

## Description

When hardware scan offload is used (i.e. the `hw_scan` callback is assigned) this function needs to be called by the driver to notify mac80211 that the scan finished. This function can be called from any context, including hardirq context.



---

# Chapter 16. Aggregation

## TX A-MPDU aggregation

Aggregation on the TX side requires setting the hardware flag `IEEE80211_HW_AMPDU_AGGREGATION`. The driver will then be handed packets with a flag indicating A-MPDU aggregation. The driver or device is responsible for actually aggregating the frames, as well as deciding how many and which to aggregate.

When TX aggregation is started by some subsystem (usually the rate control algorithm would be appropriate) by calling the `ieee80211_start_tx_ba_session` function, the driver will be notified via its `ampdu_action` function, with the `IEEE80211_AMPDU_TX_START` action.

In response to that, the driver is later required to call the `ieee80211_start_tx_ba_cb_irqsafe` function, which will really start the aggregation session after the peer has also responded. If the peer responds negatively, the session will be stopped again right away. Note that it is possible for the aggregation session to be stopped before the driver has indicated that it is done setting it up, in which case it must not indicate the setup completion.

Also note that, since we also need to wait for a response from the peer, the driver is notified of the completion of the handshake by the `IEEE80211_AMPDU_TX_OPERATIONAL` action to the `ampdu_action` callback.

Similarly, when the aggregation session is stopped by the peer or something calling `ieee80211_stop_tx_ba_session`, the driver's `ampdu_action` function will be called with the action `IEEE80211_AMPDU_TX_STOP`. In this case, the call must not fail, and the driver must later call `ieee80211_stop_tx_ba_cb_irqsafe`. Note that the sta can get destroyed before the BA tear down is complete.

## RX A-MPDU aggregation

Aggregation on the RX side requires only implementing the `ampdu_action` callback that is invoked to start/stop any block-ack sessions for RX aggregation.

When RX aggregation is started by the peer, the driver is notified via `ampdu_action` function, with the `IEEE80211_AMPDU_RX_START` action, and may reject the request in which case a negative response is sent to the peer, if it accepts it a positive response is sent.

While the session is active, the device/driver are required to de-aggregate frames and pass them up one by one to `mac80211`, which will handle the reorder buffer.

When the aggregation session is stopped again by the peer or ourselves, the driver's `ampdu_action` function will be called with the action `IEEE80211_AMPDU_RX_STOP`. In this case, the call must not fail.

## Name

enum ieee80211\_ampdu\_mlme\_action — A-MPDU actions

## Synopsis

```
enum ieee80211_ampdu_mlme_action {
    IEEE80211_AMPDU_RX_START,
    IEEE80211_AMPDU_RX_STOP,
    IEEE80211_AMPDU_TX_START,
    IEEE80211_AMPDU_TX_STOP_CONT,
    IEEE80211_AMPDU_TX_STOP_FLUSH,
    IEEE80211_AMPDU_TX_STOP_FLUSH_CONT,
    IEEE80211_AMPDU_TX_OPERATIONAL
};
```

## Constants

IEEE80211\_AMPDU\_RX\_START    start RX aggregation

IEEE80211\_AMPDU\_RX\_STOP    stop RX aggregation

IEEE80211\_AMPDU\_TX\_START    start TX aggregation

IEEE80211\_AMPDU\_TX\_STOP\_CONT    stop TX aggregation but continue transmitting queued packets, now unaggregated. After all packets are transmitted the driver has to call `ieee80211_stop_tx_ba_cb_irqsafe`.

IEEE80211\_AMPDU\_TX\_STOP\_FLUSH    stop TX aggregation and flush all packets, called when the station is removed. There's no need or reason to call `ieee80211_stop_tx_ba_cb_irqsafe` in this case as `mac80211` assumes the session is gone and removes the station.

IEEE80211\_AMPDU\_TX\_STOP\_FLUSH\_CONT    stop TX aggregation is stopped but the driver hasn't called `ieee80211_stop_tx_ba_cb_irqsafe` yet and now the connection is dropped and the station will be removed. Drivers should clean up and drop remaining packets when this is called.

IEEE80211\_AMPDU\_TX\_OPERATIONAL    aggregation has become operational

## Description

These flags are used with the `ampdu_action` callback in struct `ieee80211_ops` to indicate which action is needed.

Note that drivers **MUST** be able to deal with a TX aggregation session being stopped even before they OK'ed starting it by calling `ieee80211_start_tx_ba_cb_irqsafe`, because the peer might receive the addBA frame and send a delBA right away!

---

# Chapter 17. Spatial Multiplexing Powersave (SMPS)

SMPS (Spatial multiplexing power save) is a mechanism to conserve power in an 802.11n implementation. For details on the mechanism and rationale, please refer to 802.11 (as amended by 802.11n-2009) “11.2.3 SM power save”.

The mac80211 implementation is capable of sending action frames to update the AP about the station's SMPS mode, and will instruct the driver to enter the specific mode. It will also announce the requested SMPS mode during the association handshake. Hardware support for this feature is required, and can be indicated by hardware flags.

The default mode will be “automatic”, which nl80211/cfg80211 defines to be dynamic SMPS in (regular) powersave, and SMPS turned off otherwise.

To support this feature, the driver must set the appropriate hardware support flags, and handle the SMPS flag to the `config` operation. It will then with this mechanism be instructed to enter the requested SMPS mode while associated to an HT AP.

## Name

ieee80211\_request\_smcs — request SM PS transition

## Synopsis

```
void ieee80211_request_smcs (struct ieee80211_vif * vif, enum  
ieee80211_smcs_mode smcs_mode);
```

## Arguments

*vif* struct ieee80211\_vif pointer from the add\_interface callback.

*smcs\_mode* new SM PS mode

## Description

This allows the driver to request an SM PS transition in managed mode. This is useful when the driver has more information than the stack about possible interference, for example by bluetooth.

## Name

enum ieee80211\_smeps\_mode — spatial multiplexing power save mode

## Synopsis

```
enum ieee80211_smeps_mode {  
    IEEE80211_SMPS_AUTOMATIC,  
    IEEE80211_SMPS_OFF,  
    IEEE80211_SMPS_STATIC,  
    IEEE80211_SMPS_DYNAMIC,  
    IEEE80211_SMPS_NUM_MODES  
};
```

## Constants

|                          |                     |
|--------------------------|---------------------|
| IEEE80211_SMPS_AUTOMATIC | automatic           |
| IEEE80211_SMPS_OFF       | off                 |
| IEEE80211_SMPS_STATIC    | static              |
| IEEE80211_SMPS_DYNAMIC   | dynamic             |
| IEEE80211_SMPS_NUM_MODES | internal, don't use |

---

# Part III. Rate control interface

TBD

This part of the book describes the rate control algorithm interface and how it relates to mac80211 and drivers.

---

## Table of Contents

|   |     |
|---|-----|
| 18. Rate Control API .....                | 121 |
| ieee80211_start_tx_ba_session .....       | 122 |
| ieee80211_start_tx_ba_cb_irqsafe .....    | 123 |
| ieee80211_stop_tx_ba_session .....        | 124 |
| ieee80211_stop_tx_ba_cb_irqsafe .....     | 125 |
| enum ieee80211_rate_control_changed ..... | 126 |
| struct ieee80211_tx_rate_control .....    | 127 |
| rate_control_send_low .....               | 128 |

---

# Chapter 18. Rate Control API

TBD



## Name

ieee80211\_start\_tx\_ba\_session — Start a tx Block Ack session.

## Synopsis

```
int ieee80211_start_tx_ba_session (struct ieee80211_sta * sta, u16 tid,  
u16 timeout);
```

## Arguments

*sta*            the station for which to start a BA session

*tid*            the TID to BA on.

*timeout*       session timeout value (in TUs)

## Return

success if addBA request was sent, failure otherwise

Although mac80211/low level driver/user space application can estimate the need to start aggregation on a certain RA/TID, the session level will be managed by the mac80211.

## Name

ieee80211\_start\_tx\_ba\_cb\_irqsafe — low level driver ready to aggregate.

## Synopsis

```
void ieee80211_start_tx_ba_cb_irqsafe (struct ieee80211_vif * vif, const  
u8 * ra, u16 tid);
```

## Arguments

*vif* struct ieee80211\_vif pointer from the add\_interface callback

*ra* receiver address of the BA session recipient.

*tid* the TID to BA on.

## Description

This function must be called by low level driver once it has finished with preparations for the BA session. It can be called from any context.

## Name

ieee80211\_stop\_tx\_ba\_session — Stop a Block Ack session.

## Synopsis

```
int ieee80211_stop_tx_ba_session (struct ieee80211_sta * sta, u16 tid);
```

## Arguments

*sta* the station whose BA session to stop

*tid* the TID to stop BA.

## Return

negative error if the TID is invalid, or no aggregation active

Although mac80211/low level driver/user space application can estimate the need to stop aggregation on a certain RA/TID, the session level will be managed by the mac80211.

## Name

ieee80211\_stop\_tx\_ba\_cb\_irqsafe — low level driver ready to stop aggregate.

## Synopsis

```
void ieee80211_stop_tx_ba_cb_irqsafe (struct ieee80211_vif * vif, const
u8 * ra, u16 tid);
```

## Arguments

*vif* struct ieee80211\_vif pointer from the add\_interface callback

*ra* receiver address of the BA session recipient.

*tid* the desired TID to BA on.

## Description

This function must be called by low level driver once it has finished with preparations for the BA session tear down. It can be called from any context.

## Name

enum ieee80211\_rate\_control\_changed — flags to indicate what changed

## Synopsis

```
enum ieee80211_rate_control_changed {  
    IEEE80211_RC_BW_CHANGED,  
    IEEE80211_RC_SMPS_CHANGED,  
    IEEE80211_RC_SUPP_RATES_CHANGED,  
    IEEE80211_RC_NSS_CHANGED  
};
```

## Constants

**IEEE80211\_RC\_BW\_CHANGED** The bandwidth that can be used to transmit to this station changed. The actual bandwidth is in the station information -- for HT20/40 the IEEE80211\_HT\_CAP\_SUP\_WIDTH\_20\_40 flag changes, for HT and VHT the bandwidth field changes.

**IEEE80211\_RC\_SMPS\_CHANGED** The SMPS state of the station changed.

**IEEE80211\_RC\_SUPP\_RATES\_CHANGED** The supported rate set of this peer changed (in IBSS mode) due to discovering more information about the peer.

**IEEE80211\_RC\_NSS\_CHANGED** N\_SS (number of spatial streams) was changed by the peer

## Name

struct ieee80211\_tx\_rate\_control — rate control information for/from RC algo

## Synopsis

```
struct ieee80211_tx_rate_control {
    struct ieee80211_hw * hw;
    struct ieee80211_supported_band * sband;
    struct ieee80211_bss_conf * bss_conf;
    struct sk_buff * skb;
    struct ieee80211_tx_rate reported_rate;
    bool rts;
    bool short_preamble;
    u8 max_rate_idx;
    u32 rate_idx_mask;
    u8 * rate_idx_mcs_mask;
    bool bss;
};
```

## Members

|                   |  |
|-------------------|--|
| hw                | The hardware the algorithm is invoked for.   |
| sband             | The band this frame is being transmitted on.   |
| bss_conf          | the current BSS configuration  |
| skb               | the skb that will be transmitted, the control information in it needs to be filled in  |
| reported_rate     | The rate control algorithm can fill this in to indicate which rate should be reported to userspace as the current rate and used for rate calculations in the mesh network. |
| rts               | whether RTS will be used for this frame because it is longer than the RTS threshold  |
| short_preamble    | whether mac80211 will request short-preamble transmission if the selected rate supports it   |
| max_rate_idx      | user-requested maximum (legacy) rate (deprecated; this will be removed once drivers get updated to use rate_idx_mask)  |
| rate_idx_mask     | user-requested (legacy) rate mask  |
| rate_idx_mcs_mask | user-requested MCS rate mask (NULL if not in use)  |
| bss               | whether this frame is sent out in AP or IBSS mode  |

## Name

`rate_control_send_low` — helper for drivers for management/no-ack frames

## Synopsis

```
bool rate_control_send_low (struct ieee80211_sta * sta, void * priv_sta,  
struct ieee80211_tx_rate_control * txrc);
```

## Arguments

*sta*            struct ieee80211\_sta pointer to the target destination. Note that this may be null.

*priv\_sta*      private rate control structure. This may be null.

*txrc*          rate control information we should populate for mac80211.

## Description

Rate control algorithms that agree to use the lowest rate to send management frames and NO\_ACK data with the respective hw retries should use this in the beginning of their mac80211 `get_rate` callback. If true is returned the rate control can simply return. If false is returned we guarantee that *sta* and *priv\_sta* is not null.

Rate control algorithms wishing to do more intelligent selection of rate for multicast/broadcast frames may choose to not use this.

---

# Part IV. Internals

TBD

This part of the book describes mac80211 internals.



---

## Table of Contents

|                                      |     |
|--------------------------------------|-----|
| 19. Key handling .....               | 131 |
| Key handling basics .....            | 131 |
| MORE TBD .....                       | 131 |
| 20. Receive processing .....         | 132 |
| 21. Transmit processing .....        | 133 |
| 22. Station info handling .....      | 134 |
| Programming information .....        | 134 |
| STA information lifetime rules ..... | 141 |
| 23. Aggregation .....                | 143 |
| struct sta_ampdu_mlme .....          | 144 |
| struct tid_ampdu_tx .....            | 145 |
| struct tid_ampdu_rx .....            | 147 |
| 24. Synchronisation .....            | 149 |

---

# Chapter 19. Key handling

## Key handling basics

Key handling in mac80211 is done based on per-interface (`sub_if_data`) keys and per-station keys. Since each station belongs to an interface, each station key also belongs to that interface.

Hardware acceleration is done on a best-effort basis for algorithms that are implemented in software, for each key the hardware is asked to enable that key for offloading but if it cannot do that the key is simply kept for software encryption (unless it is for an algorithm that isn't implemented in software). There is currently no way of knowing whether a key is handled in SW or HW except by looking into debugfs.

All key management is internally protected by a mutex. Within all other parts of mac80211, key references are, just as STA structure references, protected by RCU. Note, however, that some things are unprotected, namely the `key->sta` dereferences within the hardware acceleration functions. This means that `sta_info_destroy` must remove the key which waits for an RCU grace period.

## MORE TBD

TBD

---

# Chapter 20. Receive processing

TBD

---

# Chapter 21. Transmit processing

TBD

---

# **Chapter 22. Station info handling**

## **Programming information**

## Name

struct sta\_info — STA information

## Synopsis

```
struct sta_info {
    struct list_head list;
    struct list_head free_list;
    struct rcu_head rcu_head;
    struct rhash_head hash_node;
    struct ieee80211_local * local;
    struct ieee80211_sub_if_data * sdata;
    struct ieee80211_key __rcu * gtk[NUM_DEFAULT_KEYS + NUM_DEFAULT_MGMT_KEYS];
    struct ieee80211_key __rcu * ptk[NUM_DEFAULT_KEYS];
    u8 gtk_idx;
    u8 ptk_idx;
    struct rate_control_ref * rate_ctrl;
    void * rate_ctrl_priv;
    spinlock_t lock;
    struct work_struct drv_deliver_wk;
    u16 listen_interval;
    bool dead;
    bool uploaded;
    enum ieee80211_sta_state sta_state;
    unsigned long _flags;
    spinlock_t ps_lock;
    struct sk_buff_head ps_tx_buf[IEEE80211_NUM_ACS];
    struct sk_buff_head tx_filtered[IEEE80211_NUM_ACS];
    unsigned long driver_buffered_tids;
    unsigned long txq_buffered_tids;
    unsigned long rx_packets;
    u64 rx_bytes;
    unsigned long last_rx;
    long last_connected;
    unsigned long num_duplicates;
    unsigned long rx_fragments;
    unsigned long rx_dropped;
    int last_signal;
    struct ewma avg_signal;
    int last_ack_signal;
    u8 chains;
    s8 chain_signal_last[IEEE80211_MAX_CHAINS];
    struct ewma chain_signal_avg[IEEE80211_MAX_CHAINS];
    __le16 last_seq_ctrl[IEEE80211_NUM_TIDS + 1];
    unsigned long tx_filtered_count;
    unsigned long tx_retry_failed;
    unsigned long tx_retry_count;
    unsigned int fail_avg;
    u32 tx_fragments;
    u64 tx_packets[IEEE80211_NUM_ACS];
    u64 tx_bytes[IEEE80211_NUM_ACS];
    struct ieee80211_tx_rate last_tx_rate;
```

```
int last_rx_rate_idx;
u32 last_rx_rate_flag;
u32 last_rx_rate_vht_flag;
u8 last_rx_rate_vht_nss;
u16 tid_seq[IEEE80211_QOS_CTL_TID_MASK + 1];
u64 tx_msdu[IEEE80211_NUM_TIDS + 1];
u64 tx_msdu_retries[IEEE80211_NUM_TIDS + 1];
u64 tx_msdu_failed[IEEE80211_NUM_TIDS + 1];
u64 rx_msdu[IEEE80211_NUM_TIDS + 1];
struct sta_ampdu_mlme ampdu_mlme;
u8 timer_to_tid[IEEE80211_NUM_TIDS];
#ifdef CONFIG_MAC80211_MESH
    u16 llid;
    u16 plid;
    u16 reason;
    u8 plink_retries;
    enum nl80211_plink_state plink_state;
    u32 plink_timeout;
    struct timer_list plink_timer;
    s64 t_offset;
    s64 t_offset_setpoint;
    enum nl80211_mesh_power_mode local_pm;
    enum nl80211_mesh_power_mode peer_pm;
    enum nl80211_mesh_power_mode nonpeer_pm;
#endif
#ifdef CONFIG_MAC80211_DEBUGFS
    struct sta_info_debugfsdentries debugfs;
#endif
enum ieee80211_sta_rx_bandwidth cur_max_bandwidth;
unsigned int lost_packets;
unsigned int beacon_loss_count;
enum ieee80211_smps_mode known_smps_mode;
const struct ieee80211_cipher_scheme * cipher_scheme;
unsigned long last_tdls_pkt_time;
u8 reserved_tid;
struct ieee80211_sta sta;
};
```

## Members

|  |  |
|--|--|
| list   | global linked list entry                         |
| free_list  | list entry for keeping track of stations to free |
| rcu_head   | RCU head used for freeing this station struct    |
| hash_node  | hash node for rhashtable                         |
| local  | pointer to the global information                |
| sdata  | virtual interface this station belongs to        |
| gtk[NUM_DEFAULT_KEYS +<br>NUM_DEFAULT_MGMT_KEYS] | group keys negotiated with this station, if any  |
| ptk[NUM_DEFAULT_KEYS]                            | peer keys negotiated with this station, if any   |

|                                |  |
|--------------------------------|--|
| gtk_idx                        | last installed group key index   |
| ptk_idx                        | last installed peer key index  |
| rate_ctrl                      | rate control algorithm reference   |
| rate_ctrl_priv                 | rate control private per-STA pointer   |
| lock                           | used for locking all fields that require locking, see comments in the header file.   |
| drv_deliver_wk                 | used for delivering frames after driver PS unblocking  |
| listen_interval                | listen interval of this station, when we're acting as AP   |
| dead                           | set to true when sta is unlinked   |
| uploaded                       | set to true when sta is uploaded to the driver   |
| sta_state                      | duplicates information about station state (for debug)   |
| _flags                         | STA flags, see enum ieee80211_sta_info_flags, do not use directly  |
| ps_lock                        | used for powersave (when mac80211 is the AP) related locking   |
| ps_tx_buf[IEEE80211_NUM_ACS]   | buffers (per AC) of frames to transmit to this station when it leaves power saving state or polls  |
| tx_filtered[IEEE80211_NUM_ACS] | buffers (per AC) of frames we already tried to transmit but were filtered by hardware due to STA having entered power saving state, these are also delivered to the station when it leaves powersave or polls for frames |
| driver_buffered_tids           | bitmap of TIDs the driver has data buffered on   |
| txq_buffered_tids              | bitmap of TIDs that mac80211 has txq data buffered on  |
| rx_packets                     | Number of MSDUs received from this STA   |
| rx_bytes                       | Number of bytes received from this STA   |
| last_rx                        | time (in jiffies) when last frame was received from this STA   |
| last_connected                 | time (in seconds) when a station got connected   |
| num_duplicates                 | number of duplicate frames received from this STA  |
| rx_fragments                   | number of received MPDUs   |
| rx_dropped                     | number of dropped MPDUs from this STA  |
| last_signal                    | signal of last received frame from this STA  |
| avg_signal                     | moving average of signal of received frames from this STA  |
| last_ack_signal                | signal of last received Ack frame from this STA  |
| chains                         | chains ever used for RX from this station  |

---



|   |  |
|---|--|
| chain_signal_last[IEEE80211_MAX_CHAINS] | chain signal (per chain)   |
| chain_signal_avg[IEEE80211_MAX_CHAINS]  | chain signal average (per chain)   |
| last_seq_ctrl[IEEE80211_NUM_TIDS + 1]   | last received seq/frag number from this STA (per RX queue)   |
| tx_filtered_count                       | number of frames the hardware filtered for this STA  |
| tx_retry_failed                         | number of frames that failed retry   |
| tx_retry_count                          | total number of retries for frames to this STA   |
| fail_avg                                | moving percentage of failed MSDUs  |
| tx_fragments                            | number of transmitted MPDUs  |
| tx_packets[IEEE80211_NUM_ACS]           | number of RX/TX MSDUs  |
| tx_bytes[IEEE80211_NUM_ACS]             | number of bytes transmitted to this STA  |
| last_tx_rate                            | rate used for last transmit, to report to userspace as “the” transmit rate                           |
| last_rx_rate_idx                        | rx status rate index of the last data packet   |
| last_rx_rate_flag                       | rx status flag of the last data packet   |
| last_rx_rate_vht_flag                   | rx status vht flag of the last data packet   |
| last_rx_rate_vht_nss                    | rx status nss of last data packet  |
| tid_seq[IEEE80211_QOS_CTL_TID_MASK + 1] | sequence numbers for sending to this STA   |
| tx_msdu[IEEE80211_NUM_TIDS + 1]         | MSDUs transmitted to this station, using IEEE80211_NUM_TID entry for non-QoS frames                  |
| tx_msdu_retries[IEEE80211_NUM_TIDS + 1] | MSDU retries for transmissions to to this station, using IEEE80211_NUM_TID entry for non-QoS frames  |
| tx_msdu_failed[IEEE80211_NUM_TIDS + 1]  | MSDU failures for transmissions to to this station, using IEEE80211_NUM_TID entry for non-QoS frames |
| rx_msdu[IEEE80211_NUM_TIDS + 1]         | MSDUs received from this station, using IEEE80211_NUM_TID entry for non-QoS frames                   |
| ampdu_mlme                              | A-MPDU state machine state   |
| timer_to_tid[IEEE80211_NUM_TIDS]        | identity mapping to ID timers  |
| llid                                    | Local link ID  |
| plid                                    | Peer link ID   |
| reason                                  | Cancel reason on PLINK_HOLDING state   |
| plink_retries                           | Retries in establishment   |

|                    |   |
|--------------------|---|
| plink_state        | peer link state   |
| plink_timeout      | timeout of peer link  |
| plink_timer        | peer link watch timer   |
| t_offset           | timing offset relative to this host   |
| t_offset_setpoint  | reference timing offset of this sta to be used when calculating clockdrift  |
| local_pm           | local link-specific power save mode   |
| peer_pm            | peer-specific power save mode towards local STA   |
| nonpeer_pm         | STA power save mode towards non-peer neighbors  |
| debugfs            | debug filesystem info   |
| cur_max_bandwidth  | maximum bandwidth to use for TX to the station, taken from HT/VHT capabilities or VHT operating mode notification |
| lost_packets       | number of consecutive lost packets  |
| beacon_loss_count  | number of times beacon loss has triggered   |
| known_smps_mode    | the smps_mode the client thinks we are in. Relevant for AP only.  |
| cipher_scheme      | optional cipher scheme for this station   |
| last_tlds_pkt_time | holds the time in jiffies of last TDLS pkt ACKed  |
| reserved_tid       | reserved TID (if any, otherwise IEEE80211_TID_UNRESERVED)   |
| sta                | station information we share with the driver  |

## Description

This structure collects information about a station that mac80211 is communicating with.

## Name

enum ieee80211\_sta\_info\_flags — Stations flags

## Synopsis

```
enum ieee80211_sta_info_flags {
    WLAN_STA_AUTH,
    WLAN_STA_ASSOC,
    WLAN_STA_PS_STA,
    WLAN_STA_AUTHORIZED,
    WLAN_STA_SHORT_PREAMBLE,
    WLAN_STA_WDS,
    WLAN_STA_CLEAR_PS_FILT,
    WLAN_STA_MFP,
    WLAN_STA_BLOCK_BA,
    WLAN_STA_PS_DRIVER,
    WLAN_STA_PSPOLL,
    WLAN_STA_TDLS_PEER,
    WLAN_STA_TDLS_PEER_AUTH,
    WLAN_STA_TDLS_INITIATOR,
    WLAN_STA_TDLS_CHAN_SWITCH,
    WLAN_STA_TDLS_OFF_CHANNEL,
    WLAN_STA_UAPSD,
    WLAN_STA_SP,
    WLAN_STA_4ADDR_EVENT,
    WLAN_STA_INSERTED,
    WLAN_STA_RATE_CONTROL,
    WLAN_STA_TOFFSET_KNOWN,
    WLAN_STA_MPSP_OWNER,
    WLAN_STA_MPSP_RECIPIENT,
    WLAN_STA_PS_DELIVER
};
```

## Constants

|                         |  |
|-------------------------|--|
| WLAN_STA_AUTH           | Station is authenticated.  |
| WLAN_STA_ASSOC          | Station is associated.   |
| WLAN_STA_PS_STA         | Station is in power-save mode  |
| WLAN_STA_AUTHORIZED     | Station is authorized to send/receive traffic. This bit is always checked so needs to be enabled for all stations when virtual port control is not in use. |
| WLAN_STA_SHORT_PREAMBLE | Station is capable of receiving short-preamble frames.   |
| WLAN_STA_WDS            | Station is one of our WDS peers.   |
| WLAN_STA_CLEAR_PS_FILT  | Clear PS filter in hardware (using the IEEE80211_TX_CTL_CLEAR_PS_FILT control flag) when the next frame to this station is transmitted.                    |
| WLAN_STA_MFP            | Management frame protection is used with this STA.   |

|                           |   |
|---------------------------|---|
| WLAN_STA_BLOCK_BA         | Used to deny ADDBA requests (both TX and RX) during suspend/resume and station removal.   |
| WLAN_STA_PS_DRIVER        | driver requires keeping this station in power-save mode logically to flush frames that might still be in the queues               |
| WLAN_STA_PSPOLL           | Station sent PS-poll while driver was keeping station in power-save mode, reply when the driver unblocks.                         |
| WLAN_STA_TDLS_PEER        | Station is a TDLS peer.   |
| WLAN_STA_TDLS_PEER_AUTH   | This TDLS peer is authorized to send direct packets. This means the link is enabled.  |
| WLAN_STA_TDLS_INITIATOR   | We are the initiator of the TDLS link with this station.  |
| WLAN_STA_TDLS_CHAN_SWITCH | This TDLS peer supports TDLS channel-switching  |
| WLAN_STA_TDLS_OFF_CHANNEL | The local STA is currently off-channel with this TDLS peer  |
| WLAN_STA_UAPSD            | Station requested unscheduled SP while driver was keeping station in power-save mode, reply when the driver unblocks the station. |
| WLAN_STA_SP               | Station is in a service period, so don't try to reply to other uAPSD trigger frames or PS-Poll.                                   |
| WLAN_STA_4ADDR_EVENT      | 4-addr event was already sent for this frame.   |
| WLAN_STA_INSERTED         | This station is inserted into the hash table.   |
| WLAN_STA_RATE_CONTROL     | rate control was initialized for this station.  |
| WLAN_STA_TOFFSET_KNOWN    | toffset calculated for this station is valid.   |
| WLAN_STA_MPSP_OWNER       | local STA is owner of a mesh Peer Service Period.   |
| WLAN_STA_MPSP_RECIPIENT   | local STA is recipient of a MPSP.   |
| WLAN_STA_PS_DELIVER       | station woke up, but we're still blocking TX until pending frames are delivered   |

## Description

These flags are used with struct `sta_info`'s `flags` member, but only indirectly with `set_sta_flag` and friends.

## STA information lifetime rules

STA info structures (struct `sta_info`) are managed in a hash table for faster lookup and a list for iteration. They are managed using RCU, i.e. access to the list and hash table is protected by RCU.

Upon allocating a STA info structure with `sta_info_alloc`, the caller owns that structure. It must then insert it into the hash table using either `sta_info_insert` or `sta_info_insert_rcu`; only in the latter case (which acquires an rcu read section but must not be called from within one) will the pointer

still be valid after the call. Note that the caller may not do much with the STA info before inserting it, in particular, it may not start any mesh peer link management or add encryption keys.

When the insertion fails (`sta_info_insert`) returns non-zero), the structure will have been freed by `sta_info_insert`!

Station entries are added by `mac80211` when you establish a link with a peer. This means different things for the different type of interfaces we support. For a regular station this mean we add the AP sta when we receive an association response from the AP. For IBSS this occurs when get to know about a peer on the same IBSS. For WDS we add the sta for the peer immediately upon device open. When using AP mode we add stations for each respective station upon request from userspace through `nl80211`.

In order to remove a STA info structure, various `sta_info_destroy_*`() calls are available.

There is no concept of ownership on a STA entry, each structure is owned by the global hash table/list until it is removed. All users of the structure need to be RCU protected so that the structure won't be freed before they are done using it.

---

## Chapter 23. Aggregation

## Name

struct sta\_ampdu\_mlme — STA aggregation information.

## Synopsis

```
struct sta_ampdu_mlme {
    struct mutex mtx;
    struct tid_ampdu_rx __rcu * tid_rx[IEEE80211_NUM_TIDS];
    unsigned long tid_rx_timer_expired[BITS_TO_LONGS(IEEE80211_NUM_TIDS)];
    unsigned long tid_rx_stop_requested[BITS_TO_LONGS(IEEE80211_NUM_TIDS)];
    struct work_struct work;
    struct tid_ampdu_tx __rcu * tid_tx[IEEE80211_NUM_TIDS];
    struct tid_ampdu_tx * tid_start_tx[IEEE80211_NUM_TIDS];
    unsigned long last_addba_req_time[IEEE80211_NUM_TIDS];
    u8 addba_req_num[IEEE80211_NUM_TIDS];
    u8 dialog_token_allocator;
};
```

## Members

|  |   |
|--|---|
| mtx  | mutex to protect all TX data (except non-NULL assignments to tid_tx[idx], which are protected by the sta spinlock) tid_start_tx is also protected by sta->lock. |
| tid_rx[IEEE80211_NUM_TIDS]                               | aggregation info for Rx per TID -- RCU protected  |
| tid_rx_timer_expired[BITS_TO_LONGS(IEEE80211_NUM_TIDS)]  | On stop, indicating how many TIDs the RX timer expired until the work for it runs   |
| tid_rx_stop_requested[BITS_TO_LONGS(IEEE80211_NUM_TIDS)] | On stop, indicating how many TIDs sessions per TID the driver requested to close until the work for it runs   |
| work   | work struct for starting/stopping aggregation   |
| tid_tx[IEEE80211_NUM_TIDS]                               | aggregation info for Tx per TID   |
| tid_start_tx[IEEE80211_NUM_TIDS]                         | sessions where start was requested  |
| last_addba_req_time[IEEE80211_NUM_TIDS]                  | timestamp of the last addBA request.  |
| addba_req_num[IEEE80211_NUM_TIDS]                        | number of times addBA request has been sent.  |
| dialog_token_allocator                                   | dialog token enumerator for each new session;   |

## Name

struct tid\_ampdu\_tx — TID aggregation information (Tx).

## Synopsis

```
struct tid_ampdu_tx {
    struct rcu_head rcu_head;
    struct timer_list session_timer;
    struct timer_list addba_resp_timer;
    struct sk_buff_head pending;
    unsigned long state;
    unsigned long last_tx;
    u16 timeout;
    u8 dialog_token;
    u8 stop_initiator;
    bool tx_stop;
    u8 buf_size;
    u16 failed_bar_ssn;
    bool bar_pending;
};
```

## Members

|                  |   |
|------------------|---|
| rcu_head         | rcu head for freeing structure                        |
| session_timer    | check if we keep Tx-ing on the TID (by timeout value) |
| addba_resp_timer | timer for peer's response to addba request            |
| pending          | pending frames queue -- use sta's spinlock to protect |
| state            | session state (see above)                             |
| last_tx          | jiffies of last tx activity                           |
| timeout          | session timeout value to be filled in ADDBA requests  |
| dialog_token     | dialog token for aggregation session                  |
| stop_initiator   | initiator of a session stop                           |
| tx_stop          | TX DelBA frame when stopping                          |
| buf_size         | reorder buffer size at receiver                       |
| failed_bar_ssn   | ssn of the last failed BAR tx attempt                 |
| bar_pending      | BAR needs to be re-sent                               |

## Description

This structure's lifetime is managed by RCU, assignments to the array holding it must hold the aggregation mutex.



The TX path can access it under RCU lock-free if, and only if, the state has the flag `HT_AGG_STATE_OPERATIONAL` set. Otherwise, the TX path must also acquire the spinlock and re-check the state, see comments in the tx code touching it.

## Name

struct tid\_ampdu\_rx — TID aggregation information (Rx).

## Synopsis

```
struct tid_ampdu_rx {
    struct rcu_head rcu_head;
    spinlock_t reorder_lock;
    struct sk_buff_head * reorder_buf;
    unsigned long * reorder_time;
    struct timer_list session_timer;
    struct timer_list reorder_timer;
    unsigned long last_rx;
    u16 head_seq_num;
    u16 stored_mpdu_num;
    u16 ssn;
    u16 buf_size;
    u16 timeout;
    u8 dialog_token;
    bool auto_seq;
    bool removed;
};
```

## Members

|                 |   |
|-----------------|---|
| rcu_head        | RCU head used for freeing this struct   |
| reorder_lock    | serializes access to reorder buffer, see below.   |
| reorder_buf     | buffer to reorder incoming aggregated MPDUs. An MPDU may be an A-MSDU with individually reported subframes. |
| reorder_time    | jiffies when skb was added  |
| session_timer   | check if peer keeps Tx-ing on the TID (by timeout value)  |
| reorder_timer   | releases expired frames from the reorder buffer.  |
| last_rx         | jiffies of last rx activity   |
| head_seq_num    | head sequence number in reordering buffer.  |
| stored_mpdu_num | number of MPDUs in reordering buffer  |
| ssn             | Starting Sequence Number expected to be aggregated.   |
| buf_size        | buffer size for incoming A-MPDUs  |
| timeout         | reset timer value (in TUs).   |
| dialog_token    | dialog token for aggregation session  |
| auto_seq        | used for offloaded BA sessions to automatically pick head_seq_and and ssn.                                  |

removed

this session is removed (but might have been found due to RCU)

## Description

This structure's lifetime is managed by RCU, assignments to the array holding it must hold the aggregation mutex.

The *reorder\_lock* is used to protect the members of this struct, except for *timeout*, *buf\_size* and *dialog\_token*, which are constant across the lifetime of the struct (the dialog token being used only for debugging).

---

# Chapter 24. Synchronisation

TBD

Locking, lots of RCU